



杰 · 曼 · 科 · 技

GM9907-LD

User's Manual

110608030005

V01.01.15

©2020, Shenzhen General Measure Technology Co., Ltd. All rights reserved.

Without Shenzhen General Measure Technology Co., Ltd.'s permission, any company or person have no responsibility to copy, transmit, transcribe or translate to any language version.

Our company's products are under continually improvement and updating so we reserved the right to modify this manual at any time without notice. For this reason, please visit our website regularly to update newest information.

Company Website [http:// www.gmweighing.com](http://www.gmweighing.com)

Product Performance Standards: GB / T 7724-2008



Contents

| | | |
|-------|---|--------|
| 1. | Outline..... | - 1 - |
| 1.1 | Functions and Features..... | - 1 - |
| 1.2 | Front Panel Description..... | - 1 - |
| 1.3 | Rear Panel Description..... | - 2 - |
| 1.4 | Technical Specifications..... | - 3 - |
| 2. | Installation..... | - 4 - |
| 2.1 | General principle..... | - 4 - |
| 2.2 | Load Cell Connection..... | - 4 - |
| 2.3 | I/O Port Connection..... | - 4 - |
| 2.4 | Power Supply Connection..... | - 5 - |
| 2.5 | Serial Port Connection..... | - 5 - |
| 2.5.1 | Troubleshooting Serial Port Faults..... | - 6 - |
| 2.6 | Network port connection..... | - 6 - |
| 2.6.1 | Troubleshooting Network Port Faults..... | - 7 - |
| 2.7 | Touch Screen Calibration..... | - 7 - |
| 3. | User Permission Description..... | - 8 - |
| 4. | Menu..... | - 9 - |
| 4.1 | Calibration..... | - 10 - |
| 4.2 | Recipe Parameter..... | - 11 - |
| 4.3 | Weigh Format Parameter..... | - 16 - |
| 4.4 | Maintenance..... | - 17 - |
| 4.4.1 | Scale Structure..... | - 18 - |
| 4.4.2 | Peripheral ON/OFF..... | - 21 - |
| 4.4.3 | Communication Setting..... | - 22 - |
| 4.4.4 | User Logic Program..... | - 22 - |
| 4.4.5 | Reset..... | - 26 - |
| 4.4.6 | Hardware Test..... | - 27 - |
| 4.4.7 | Display Style..... | - 27 - |
| 4.5 | Peripheral Parameter..... | - 27 - |
| 4.6 | Motor Parameter..... | - 31 - |
| 4.7 | Statistic..... | - 34 - |
| 4.8 | I/O Module..... | - 35 - |
| 4.8.1 | Output port & input port definition..... | - 37 - |
| 4.9 | COM Master mode..... | - 46 - |
| 5. | Function Description..... | - 47 - |
| 5.1 | Setting the operating mode..... | - 47 - |
| 5.2 | Batch..... | - 47 - |
| 5.3 | Filling Level Control..... | - 47 - |
| 5.3.1 | Dual Supplement..... | - 47 - |
| 5.3.2 | Single Supplement..... | - 48 - |
| 5.4 | Quick Setup..... | - 48 - |
| 5.5 | U disk update software..... | - 48 - |
| 5.5.1 | Foreground update process..... | - 48 - |
| 5.5.2 | Background update process..... | - 48 - |
| 5.6 | U disk update boot interface..... | - 48 - |
| 5.7 | Sewing control..... | - 49 - |
| 5.8 | DISC Shaking..... | - 49 - |
| 5.9 | Overtime Alarm of filling and discharge function..... | - 50 - |
| 5.10 | Auxiliary pulse function..... | - 50 - |

| | |
|--|------|
| 5.11 Adaptive function | 50 - |
| 5.12 Hanger up control function..... | 51 - |
| 5.13 DISC interlock function | 51 - |
| 5.14 Binyes multi-scale function..... | 51 - |
| 5.15 Conveyor 3 level function | 52 - |
| 6. Serial port communication | 54 - |
| 6.1 Printing method..... | 54 - |
| 6.1.1 Auto Print | 54 - |
| 6.1.2 Total ACUM print..... | 55 - |
| 6.1.3 Recipe ACUM print..... | 56 - |
| 6.1.4 User ACUM print..... | 56 - |
| 6.2 Continuous mode..... | 56 - |
| 6.2.1 Continuous mode data frame format is as follows: | 56 - |
| 6.3 Modbus-RTU protocol | 57 - |
| 6.3.1 Function code and abnormal code..... | 57 - |
| 6.3.2 MODBUS transmission mode..... | 57 - |
| 6.3.3 MODBUS address assignment..... | 57 - |
| 6.4 Re-ContA/B protocol | 83 - |
| 7. Auto packaging process | 85 - |
| 7.1 Dual scale with hopper mode packaging..... | 85 - |
| 7.2 Scale A with hopper mode packing | 87 - |
| 7.3 Scale B with hopper mode packing..... | 87 - |
| 7.4 Dual hopper dual clampe bag AB separate packing mode | 88 - |
| 7.5 Dual hopper dual clip bag AB Comb packing mode..... | 89 - |
| 7.6 Dual scale no hopper mode packing..... | 90 - |
| 7.7 Dual scale no hopper individual packing | 91 - |
| 7.8 Bulk accumulation process..... | 91 - |
| 8. Motor Work Process..... | 93 - |
| 8.1 Motor Filling Portion | 93 - |
| 8.1.1 Step Motor Drive Filling | 93 - |
| 8.1.2 Motor Drive Filling | 93 - |
| 8.2 Motor lock Bag Portion..... | 94 - |
| 8.2.1 Step Motor Drive lock/unlock bag | 94 - |
| 8.2.2 Motor Drive Dual-Limit lock/unlock bag | 94 - |
| 8.2.3 Motor Drive Single-Limit lock/unlock bag | 94 - |
| 8.3 Motor Discharge Portion..... | 95 - |
| 8.3.1 Step Motor Drive Discharge..... | 95 - |
| 8.3.2 Motor Drive Single-Limit Discharge | 95 - |
| 8.3.3 Motor Drive Dual-Limit Discharge..... | 96 - |
| 8.3.4 Motor Drive Rotating Discharge | 96 - |
| 8.4 Motor Debug Function | 96 - |
| 9. Dimension (mm) | 98 - |


1. Outline

GM9907 bagging controller is a new weighing controller specially developed for automatic quantitative packing scale with double scale increment method. The controller adopts the English touch screen display interface, the operation is intuitive and simple; The new algorithm makes the weighing control faster and more accurate. USB interface and dual serial port make the device easier to system interconnection. Can be widely used in feed, chemical, food and other industries that need quantitative packaging equipment.

1.1 Functions and Features

- Full English display interface, make the operation more intuitive and easy
- Three optional weigher mode: With hopper mode, no hopper mode and bulk scale.
- 28 ON/OFF input and output control (12 in /16 out); input and output port location can be customized.
- I/O test functions, and convenient packaging weighers debugging
- Three levels speed automatic control filling, with optional slow jogging.
- It can store 40 kinds of recipes for different range of materials
- Convenient USB port to input and output of various types parameters
- fill control functions, convenient packing scale with the front filling device of control
- Multiple digital filter function
- Automatic drop correction function
- Multiple digital filtering function
- Batch number setting function
- Patting bag function for packing powder materials
- Automatic zero tracking function
- Time / date function
- User permission identity settings
- Dual serial ports to connect with printer, computer, Secondary display.

1.2 Front Panel Description



Interface Description:

- ① User info: Show user ID, recipe ID, system time, total ACUM and batch.
- ② Weight status: Weight value display, weight unit display, 9 digit display and output I/O module shortcut.
- ③ Shortcut: Fill, DISC, ZERO, Adapt shortcuts for scale A and scale B.
- ④ Packaging info: show current ACUM info, shortcut setting, batch and target value.
- ⑤ Function parameters: Controller menu parameter and setting.

Shortcut setting
recipe parameter

Packing history
record

The screenshot shows the 'Filling Test' interface. At the top, it displays 'A Stopped' and 'B Stopped' with '0 g' weight values. Below this, there are sections for 'Total Target' (0g) and 'Near Zero Band' (0g). The main area is divided into two columns for Scale A and Scale B, each with parameters for 'Co-F Remain', 'Me-F Remain', and 'Free Fall', each with an 'Inhibit Timer' of 0 ms. Below the parameters are buttons for 'A-Fill', 'A-DISC', 'A-ZERO', 'Adapt A', 'Lock Bag', 'B-Fill', 'B-DISC', 'B-ZERO', and 'Adapt B'. At the bottom, there is a table for 'Packing history record' with columns: NO., Time, Scale, Co-F Time, Me-F Time, Fi-F Time, Wait Time, DISC Time, Fill Time, Target, and Result. The bottom navigation bar includes icons for Home, Statistic, Filling Test, Recipe, Peripherals, E-Stop, and Start.


Debug interface description :

- ① Shortcut setting recipe parameter: Can promptly setting recipe parameter, debug controller easily.
- ② Packing history record: Can view the current packaging history data directly, easy to compare.

Indicator light Description :

Right one: power light;

1.3 Rear Panel Description



1.4 Technical Specifications

| General specifications | | Digital part | |
|------------------------|--------------------------------------|------------------------------|---|
| Power supply | 24V | Display | 7 inch resistance touch screen |
| Power filter | Included | Negative display | “—” |
| Operating temperature | -10~40°C | Overload Indication | weight over range/low signal of load cell |
| Maximum humidity | 90% RH without dew | | |
| Power consumption | 15W | Decimal point position | 5 options |
| Dimensions | 199mm × 133mm × 46.7mm | | |
| Analog part | | | |
| Load cell power supply | DC5V 125mA (MAX) | Input impedance | 10MΩ |
| Zero adjustment range | 0.002~15mV (when load cell is 3mV/V) | Input sensitivity | 0.02uV/d |
| Input range | 0.02~15mV | Conversion | Sigma- Delta |
| A/D Conversion rate | 120、240、480、960 Times/second | Non-linear | 0.01% F.S |
| Gain drift | 10PPM/°C | The maximum display accuracy | 1/100000 |


2. Installation

2.1 General principle

- 1) Make appropriate installation holes on the control box, (size: 181mm ×115mm)
 - 2) Install the GM9907-LD into a control box.
 - 3) Remove the fixing plates on both sides of GM9907-LD, fix it with the fixing plates and lock them with M3*10 screws.
- ※Suggested torque for side strip screws: 3-5Kg.

2.2 Load Cell Connection


The GM9907-LD packaging controller can be connected to two resistance strain bridge sensors. When you chose the six-wired load cells, you must bridge the SN+ with EX+ and bridge the SN- with EX-.




EX+: Excitation+ EX-: Excitation- SN+: Sense+ SN-: Sense- SIG+: Signal+ SIG-: Signal-

2.3 I/O Port Connection

GM9907-LD bagging controller controls 28 lines I/O (12 input and 16 output). It uses optoelectronic isolation technology to transfer data. The I/O signal input is low level effective, and the output is open-collector mode. The driving current can reach 500mA and the full load current is up to 3A, and Terminal connection is shown as below:



I/O Module Input port diagram




I/O Module output connection diagram

I/O module value of **GM9907** is user-defined to facilitate wiring and some special applications. Please refer to section 4.8 for I/O module.

2.4 Power Supply Connection

GM9907 bagging controller use 24V DC power supply. The connection is shown in the figure below:




Power terminal diagram

24V+ connect DC+, 24V- connect DC-.


Note: this product use 24V DC power supply, use 220V AC power supply will permanently damage the controller and cause danger.

2.5 Serial Port Connection


GM9907-LD can provide two serial ports. It is depicted below. One for **RS-232** (Port **TX**, **RX**, **GND**); the other is **RS-485**, (Port **A**, **B**, **GND**). serial ports support: **MODBUS** mode, Cont mode, Print, **Re-ContA** and **Re-ContB** protocol



Controller and computer connection diagram:



Connection between GM9907-LD and a host computer (RS-232):



Connection between GM9907-LD and a Host Computer (RS-485)

2.5.1 Troubleshooting Serial Port Faults

If the serial port fails to communicate, check:

- Check the connection by serial port connection; Make sure the connection is correct.

The RS232 interface must be connected to all three wires (Rx, Tx, and GND).

The RS485 port must be connected to cables A and B.

- Ensure that the connection port parameters are consistent with those of the host.

Slave ID, baud rate, data format and communication protocol must be consistent with the host computer and PLC.

2.6 Network port connection

GM9907 provides two RJ45 interfaces and supports Modbus TCP communication. Under

dual network ports, the network port is equipped with a built-in switch for easy cascading of instruments. The network port parameters can be set through the "System Maintenance" - "Communication Settings" parameter, and the corresponding Modbus communication address can refer to the Modbus address allocation in the [chapter 6.3.3.3 modbus address assignment](#) for details.

2.6.1 Troubleshooting Network Port Faults

If the network port cannot communicate, check:

- Check network port indicators.


The hardware connection is normal, and the internal communication light is steady on. The network cable is properly connected and the connection indicator is blinking.

- Check whether the communication protocol is consistent with the host computer and PLC.

○ Check that the meter can be pinged from the network. If not, check the hardware interface.

- Check whether IP conflict occurs.

- Restart the meter.



2.7 Touch Screen Calibration

The touch screen needs to be calibrated during the first use or after prolonged storage of the new product. Touch screen calibration method:

Power on GM9907 and long press any point on the touch screen. You can enter the touch screen calibration interface through the touch button set by the system parameters or by holding down the blank space for 3 seconds. The interface displays a cross cursor. Place your finger accurately at the center point of the cross cursor and hold it for at least 1 second to automatically enter the next calibration point. Long press and hold the center point of the crosshair in sequence, following the changes in its position, until all five points have been calibrated. Click on "Confirm calibration" to return to the system settings interface, and then click on "Enter Operating Environment" to enter the startup login interface.

3. User Permission Description

In order to prevent wrong operation causing **GM9907-LD** working improperly, it provides three rights (operators, Technician and Administrators): System administrator can perform all operations (not open to users). The operator and technician rights restrictions are as follows:


| Permission | Operation |
|------------|--|
| Operator | Can check all the parameters. |
| | Can set receipt parameter's value parameters and time parameters, I/O module test. |
| | Can set batch in main menu, and the total quantity of dispatching. |
| Technician | All operator privileges are available. |
| | Can calibration, start over/under, Free Fall correction and Adaptive function, set weight parameters, I/O module define, set language and time, correct computer mode parameter. |
| | Can modify opened Peripherals parameters |

Permission description:

- ◆ Controller default operator log on.
- ◆ Swift permission, can click the parameter item that needs permission, and enter the password of the corresponding technician (**Password:0000**) or administrator (**Password:000000**) in the pop-up box to log in successfully.
- ◆ Click the parameter item that needs permission, and the current user's password can be modified in the pop-up box
- ◆ In the **【Display Style】** parameter of **【Maintenance】**, set the permission exit time, which is used to limit the login duration of technicians and system administrators. When the permission exit time reaches, the privileges of the current technicians or system administrator will be returned to the operator privileges
- ◆ Multi-user login function description: In the **【Display Style】** parameter of **【Maintenance】**, the multi-user login function is enabled, set the number of users to log in, and select users to log in when power on.

4. Menu

Click the menu to check or revise parameters. The menu is shown as follows.



- ◆ Click each parameter item to view and set the home parameter information under the current parameter item.
- ◆ Click top left of interface to exit the current interface and return to the previous page.

| Parameter | Parameter list | Description |
|---------------------|------------------------------------|---|
| Calibration | Weight calibration | Use weight to calibrate |
| | A material Calibration | Use material to calibrate |
| | B material Calibration | |
| Weighing parameters | Zeroing range/Filter level setting | Set weight relevant parameters, such as zeroing range, stable parameters etc. |
| I/O Module | Input definition | Input port definition. |
| | Output definition | Output port definition. |
| | IO Test | Quickly access the hardware testing interface. |
| Time and language | Language setting | Default English, Mandarin and English optional |
| | Time setting | Screen time setting |
| COM Master | Master | Write Data To Others |
| | Fill Gate Driver | Fill Gate Driver parameters setting |
| | Clamper mode | Clamper motor parameter setting |

| | | |
|---|--------------------|---|
| Motor(Scale Structure setting motor mode) | DISC Parameter | DISC motor Parameter setting |
| Maintenance | Scale Structure | Scale Structure, Working Mode etc relevant setting |
| | Peripherals Select | Peripherals Select ON/OFF setting |
| | Communication | Serial ports, ethernet, print etc setting |
| | Logic Program | Aux.logic parameter, 6 group output logic parameter setting |
| | Reset | All parameters reset to factory setting |
| | Hardware Test | To test all input and output connection. |
| | Display Style | Display time setting |
| | Firmware Update | Firmware Update |
| | System Info. | Check calibration times and check code |

4.1 Calibration

Calibration should be done when a GM9907-LD controller is used at the first time, or the preset parameters can't meet the user's demand due to change any part of the weighing/bagging system.

To enter calibration parameter need to input correct password as it is protected by password per International Standard. Calibration password can be modified by clicking any parameter requiring permission. (Initial password: **0000**)

Calibration interface, provide two kinds of calibration methods: weight calibration and material calibration. The calibration steps are as follows:

| Calibration parameter | Item parameter | Description |
|-----------------------|---|---|
| | 1. Unit | Initial value: kg . Option: g/kg/t/lb . |
| | 2. Decimal point | Initial value: 0.00 . Option: 0~0.0000. |
| | 3 Minimum division | Initial value: 1 . Option: 1/2/5/10/20/50 . |
| | 4 Full capacity | Initial value: 100.00 ; full capacity \leq minimum division * 100000 |
| Weight Calibration | <p>Calibration function is the calibration method using weights in site. The calibration steps for the weights of A and B are as follows</p> <p>Step 1: According to the demand to choose units, decimal point, indexing value and other weighing parameters.</p> <p>Step 2: Calibrate scale A and scale B separately. Empty the bucket and click 【Empty scale calibration】. This step is the zero point of calibration, requirements are: the bucket is empty, the scale body is stable.</p> <p>Step 3: Put the weights on the weighing table, and when the weighing table is stable, click 【Weight Calibration】, input the weight of the weights in the bullet frame, and click 【OK】 to complete the calibration of the weights.</p> | |

| | |
|--------------------------|--|
| A.B material calibration | <p>Material calibration function is in the site is not convenient to use the weight calibration method. Steps as follow:</p> <p>Step1: Clear the scale table, wait for the mV to stabilize, then click 【Empty scale calibration】 . At this moment, the number on the right is the current millivolt display.This step is to zero point of calibration, requirements are: bucket is empty, the scale body is stable.</p> <p>Step2:Click 【Manual Feeding】 , then the feeding door opens, add some materials to the metering bucket, click 【Manual Feeding】 again, close the feeding door.(Note: if the manual feeding time (Step2 time setting is manual feeding time) is not set to 0, the feeding door will be automatically closed after the manual feeding time is up).</p> <p>Step3: Click 【Record】 to display the gain millivolts after manual Feeding.</p> <p>Step4:Click 【Discharge】 .When the discharge door opens, the background will record the current relative millivolt.Weighing the discharge material with electronic scale and recording the data.</p> <p>Step5:Click 【Calibrate】 to input the weighing data and click OK.Material calibration is finished.</p> |
|--------------------------|--|

4.2 Recipe Parameter

Click the formula on the main interface to enter the 40 formula selection interface, which displays the recipe number, name and target value.

- ◆ Click the recipe number button on the right to switch the recipe number.
- ◆ Click on each recipe bar to enter the corresponding recipe parameter interface.
- ◆ Click the upper left to return to the upper interface

| Parameter | | Description |
|---|------------------|---|
| Filling parameters (used to set parameters related to packaging weight values) | | |
| 1. Individual Target Mode | | Optional on and off.when is on, the target values of A and B are set respectively; when is off, sets the total target value.Initial value: off.(Valid in hopper scale and None-hopper scale mode) |
| 2. Total target value | | “Individual Target Mode” When turn to off is valid. (Valid in hopper scale and None-hopper scale mode) |
| 3. Zero zone value | | In quantitative process, if the weighing value \leq Near Zero Band, starts discharge delay timer. |
| 4.Scale A | a.A.Target value | “Individual Target Mode” When turn on is valid |
| | b. Co-Fi Remain | In quantitative process, if the weighing value \geq target value – Coarse Flow leading quantity, closing Coarse Flow fill. |
| | c. Me-Fi Remain | In quantitative process, if the weighing value \geq target value – Medium Flow leading quantity, closing Medium Flow. |
| | d. Free Fall | In quantitative process, if the weighing value \geq target - free fall value, closing Fine Flow. |
| 5.Scale B | a.B.Target value | “Individual Target Mode” When turn on is valid |
| | b. Co-Fi Remain | In quantitative process, if the weighing value \geq target value – Coarse Flow leading quantity, closing Coarse Flow fill. |
| | c. Me-Fi Remain | In quantitative process, if the weighing value \geq target value |

| | | |
|--|---|--|
| | | – Medium Flow leading quantity, closing Medium Flow. |
| | d. Free Fall | In quantitative process, if the weighing value \geq target - free fall value, closing Fine Flow. |
| Filling Timers (used to set time - related parameters in the feeding process) | | |
| 1.A.COMP. Inhibit Timer(Co-F) | At the beginning of the quantification, the coarse feeding has been effective during this time to avoid overshooting without weight judgment Initial value: 900; range: 0~9999 (ms) | |
| 2.A. COMP. Inhibit Timer(Me-F) | After the end of coarse feeding, in this period of time, in order to avoid overcharging without weight judgment, adding has been effective. Initial value: 900; range: 0~9999 (ms) | |
| 3.A. COMP. Inhibit Timer(Fi-F) | After the end of the Medium feeding, in this period of time, in order to avoid overshoot without weight judgment, fine feeding has been effective. Initial value: 900; range: 0~9999 (ms) | |
| 4.B. COMP. Inhibit Timer(Co-F) | At the beginning of the quantification, the coarse feeding has been effective during this time to avoid overshooting without weight judgment Initial value: 900; range: 0~9999 (ms) | |
| 5.B. COMP. Inhibit Timer(Me-F) | After the end of coarse feeding, in this period of time, in order to avoid overcharging without weight judgment, adding has been effective. Initial value: 900; range: 0~9999 (ms) | |
| 6.B. COMP. Inhibit Timer(Fi-F) | After the end of the Medium feeding, in this period of time, in order to avoid overshoot without weight judgment, fine feeding has been effective. Initial value: 900; range: 0~9999 (ms) | |
| 7. Filling Start Delay | In the with bucket mode, at the beginning of the quantitative process, after this delay time, the controller will conduct stability assessment and zero clearance (if it does not meet the conditions of zero clearance interval, then it will not be stable and zero clearance), and then start the feeding process; Without bucket mode, after the bag clamping is completed, after this delay time, the controller is stabilized and peeled Initial value: 0.5 ; range: 0.0~99.9 (s) | |
| 8.Result Waiting Timer | When the waiting mode is selected as " Time Delay ", fine feeding is turned off (or the over/under is turned on and the over/under alarm is over), and the setting is started. After this holding time, the setting is considered to be over and the next process is entered. Initial value: 1.0 ; range: 0.0~99.9 (s) | |
| 9. Discharge Delay Timer | In the discharge process, when the weight value of the scale bucket is less than the zero zone value, the delay is started, and the discharge signal is closed after the delay. Initial value: 0.5 ; range: 0.0~99.9 (s) | |
| 10. DISC Interlock Timer | In the bucket combination mode, the discharge interval time value of balance A and B. | |

| | |
|--|--|
| | Initial value: 0.5 ; range: 0.0~99.9 (s) |
| 11. Hanger Up Delay Timer | In the no-bucket mode, the delay is executed after the rise signal is issued. Initial value: 0.0 ; range: 0.0~99.9 (s) |
| 12. Hanger Down Delay Timer | In no-bucket mode, the waiting delay is started after the end of the delay Initial value: 0.0 ; range: 0.0~99.9 (s) |
| 13. Bag Locked&Unlocked after Delay Timer | After giving the bag clamping signal, after this delay, the controller determines that the bag clamping action is completed. After clamping/loosening the bag, it is not allowed to clamp/loosen the bag again during this time. Initial value: 0.5 ; range: 0.0~99.9 (s) |
| 14. Unlock Bag Pre-Delay Timer | After the discharge of bucket mode is finished, the unlock bag signal is output after this delay time. After the completion of the no-bucket mode setting (patting the bag), the unlock bag signal is output after this delay. Initial value: 0.5 ; range: 0.0~99.9 (s) |
| 15. Supplement Empty On Timer | No hopper mode is effective. Scale A detects that the feeding level is effective after the bag is clamped, and then scale B also clamps the bag within this time. In this case, even if the feeding level is invalid, then scale B should also start feeding Initial value: 4.0 ; range: 0.0~99.9 (s) |
| 16. DISC Completed Delay Timer | In the bucket scale and bulk scale modes, after the unloading delay ends, the unloading completion signal will output the time. Initial value: 0.0 ; range: 0.0~99.9 (s) |
| Over/Under alarm parameter setting(Used to set parameters related to over/under tolerance alarm reminders) | |
| 1. Over/Under detection ON/OFF | ON/OFF. Set to ON,Judge over/under when in quantition process. |
| 2.Over/Under pause ON/OFF | ON/OFF. If set ON, the controller will stop if over or under. Input emergency stop and return to stop status, clear alarm information. Or input clearing alarm, press ENTER to procees quantitation. |
| 3. Over/Under detection Timer | When the function of over/under is turned on, the time is started for over detection after the material feeding of each scale is finished. After the delay, the controller will stabilize and output over/under Initial value: 1.0 . Range: 0 ~ 99.9s. (s) |
| 4.Over value | In value process, if the weighing value \geq target value+ OverLimit Value, judged as OverLimit. Initial value: 0 . |
| 5. Under value | In value process, if the weighing value \leq target value- UnderLimit Value, judged as UnderLimit. Initial value: 0 . |
| 6.Supplement material ON/OFF | Supplement material judgement ON/OFF. ON: Slow jogging of material when under. (According to supplementary times). OFF: Not supplement materials. |
| 7.Effective supplement time | Effective jogging time within a cycle period. Initial value: 0.5 . Range: 0.0 ~ 99.9s . |

| | |
|---|--|
| 8. Ineffective supplement time | Ineffective jogging time within a cycle period. Initial value: 0.5 . Range: 0.0 ~ 99.9s . |
| 9. Supplement material times | If under, start to supplement materials as per setting times. Initial value: 1 . Range: 1~99 . |
| Free fall (Used to set parameters related to automatic adjustment of free fall) | |
| 1. Free fall correction ON/OFF | Correct according to actual falling materials. |
| 2. Correction sampling times | Catch the average of free fall value and set as correction basis. Initial value: 1 . Range: 1~99 . |
| 3. Free fall correction range | When this drop value exceeds the set range, it will not be included in the arithmetic average range. Initial value: 2.0 . Range: 0.0 ~ 9.9 (Percent of the target) |
| 4. Free fall correction magnitude | Every fall correction magnitude; Option: 100%, 50%, 25% . Initial value: 50% . |
| Adaptive | |
| 1. Adaptive ON/OFF | Adaptive function, open the switch after the operation process automatically adjust the controller coarse, fine, increase the amount of advance and stop time. Optional, Off, Double speed, Three speed. Initial value: Off. (Note: 1. Free fall correction and adaptive function cannot be turned on at the same time. If the adaptive function is enabled, the fall correction function must be turned off. 2. When the first scale adapts to start, it must ensure that the scale body is stable and the current weight is zero.) |
| 2. Adaptive Level | The lower the grade, the faster the feeding speed, the relatively lower the accuracy. Initial value: 3 ; range: 1~5 |
| 3. Parameters update ON/OFF | When opened, the change value of coarse, medium and fine plus advance quantity will be updated to the value of quantitative parameter; When off, quantitative parameter values cannot be updated. |
| Other | |
| Multiple scales with buckets parameters | |
| 1. Binyes Multi-Scale ON/OFF | (Currently, only supports dual scales with bucket AB, separate scale A, and separate scale B with bucket. The target value needs to be set to be greater than the maximum capacity of a single bucket for this parameter to be visible.) Initial value: OFF. |
| 2. Return valve method | Close Return Valve After Fill: After the unloading delay, the output of the return valve is invalid. Close Return Valve After Unlock Bag: After loosening the bag, the return valve output is invalid. Initial value: Close Return Valve After Unlock Bag |
| 3. Blowing Mode | Air Blow Before Up Delay: Measure the bracket upwards and blow air simultaneously for output. Air Blow After Up Delay: After the delay time of walking up the |

| | |
|---|---|
| | <p>bracket, blow air. Initial value: Air Blow Before Up Delay</p> |
| 4. Air Blow Timer | <p>Blower blowing output time. Initial value: 0.5; Range: 0.1~99.9. (Unit: s)</p> |
| 5. Lifting Hook Reset Delay | <p>During operation, if the hanging bag output is invalid for a certain period of time, it will continue to output effectively. Initial value: 0.0; Range: 0.0~99.9. (Unit: s) Note: When the parameter is not set to 0, the hanging bag output will remain invalid for this time and continue to be valid. (The first scale of the instrument needs to manually give a hanging bag signal for operation) When the parameter is set to 0, the instrument requires a bag hanging signal before starting to feed each time.</p> |
| 6. Hanger Rise PreDelay Time | <p>In the mode of multiple scales with buckets, this delay is executed after the rising signal is sent out. Initial value: 0.0; Range: 0.0~99.9. (Unit: s).</p> |
| 7. Hanger Drop PreDelay Time | <p>In the mode of multiple scales with buckets, the delay will be activated after the quantitative delay ends. Initial value: 0.0; Range: 0.0~99.9. (Unit: s)</p> |
| 8. Hook Up For Release | <p>ON: Open the decoupling up switch. OFF: Decoupling up switch closed. Initial value: OFF</p> |
| 9. Pre-delay Of Hook Up | <p>After decoupling, it is necessary to delay the time frame for the effective output of the uplink support. Initial value: 0.0s Range: 0.0~99.9. (Unit: s)</p> |
| 10. Hook Up Time | <p>After decoupling and executing the upward movement, the output of the upward bracket needs to continue for this time. Initial value: 0.0s Range: 0.0~99.9. (Unit: s)</p> |
| 11. Hook Up Pause Time | <p>After the decoupling execution is completed, it is necessary to wait for this time before descending (the bracket output is invalid). Initial value: 0.0s Range: 0.0~99.9. (Unit: s)</p> |
| Fast Mode Parameters (Parameters can be set under the structure of the scale body with or without a bucket scale) | |
| 1. Fast Mode ON/OFF | <p>"ON/OFF" is optional, and setting it to "On" will activate the instrument panel's fast mode function. Initial value: OFF.</p> |
| 2. Fast Mode Timer | <p>Fast mode deadline. Initial value: 50; Range: 0~1000. (Unit: ms)</p> |
| 3. Fast Mode Weight A | <p>Fast mode cut-off weight value A. Range: 0~Full Capacity, Initial value: 0</p> |
| 4. Fast Mode Weight B | <p>Fast mode cut-off weight value B. Range: 0~ Full Capacity, Initial value: 0</p> |
| 5. Fast Mode Correction | <p>Automatically adjust the number of times using fast mode. Initial value: 5; Range: 0~10.</p> |
| 6. Stabilization Timer | <p>After activating the fast mode function, the instrument will stabilize the weighing time.</p> |

| | |
|--|--|
| | Initial value: 100 ; Range: 0~1000 。(Unit: ms) |
|--|--|


4.3 Weigh Format Parameter

In the menu interface, click the **【Weighing】** menu to enter the current parameter item to view and set the home parameter information.

| Parameter | | Description |
|--------------------------|-----------------------|---|
| 1. Zero Range | | Zero Range Initial value: 50%; range: 1~99 (Percentage of full scale) |
| 2. STAB Range/Timer | | In the time of stability, the weight change range within this setting value is judged to be stable by the controller Stable Range initial value: 2; range: 0~99(d). Stable Timer initial value: 0.3; range: 0.1~9.9 (s) |
| 3. TrZero Range/Time | | Weight values within this range, the controller automatically displays zero.Is 0, zero tracking is not performed. TrZero Range initial value: 0; range: 0~9(d). TrZero Time initial value: 2.0; range: 0.1~99.9 (s) |
| 4. PWR-ON Zero | | On/off is optional. When "on", the controller will automatically perform zero clearing operation (the weight in the scale bucket meets the zero clearing range).Initial value: Off. |
| 5. Result Check Mode | | Wait STAB: After the fine feeding is closed, the weight is stable and the value setting process is completed Time Delay: After the slow feeding is closed, the valuing process is completed after the fixed value holding time initial value: Time Delay |
| 6. PreFill Zero Interval | | The number of times the packaging process is completed and a zero clearance is carried out.When entering the running state, the controller is not reset during the first packaging process. initial value: 0; range: 0~99. (Note: This parameter is only valid for bucket packing mode and bulk scale mode) |
| 7. Manual DISC To ACUM | | Optional on/off;Set to "on", manual discharge weight value is included in the cumulative value.Initial value: (Note: This parameter is only valid for bucket packing mode and bulk scale mode) |
| 8. Sample Rate | | A/D Sample Rate, 120 times/s, 240 times/s, 480 times/s, 960 times/s optional, initial value: 240 times/s. |
| 9. D-Filter Strength | | AD Digital filtering parameters: 0: no filtering;9: The filtering effect is strongest.Initial value: 7.Range: 0 ~ 9 |
| 10. Vib-Filter | | secondary filtering based on digital filtering. Initial value: 0.Range: 0 ~ 9 |
| 11. Dynamic Filter | Dynamic Filter ON/OFF | In the packaging process, whether to carry out filtering operation switch and set "on", the following parameters are valid;Initial value: on. |

| | | |
|----------------------|---------------------|--|
| ter parameters | Filling Filter | Filtering parameters in the feeding process: 9: The strongest filtering effect. Initial value: 4; Range: 0 ~ 9. |
| | Result Check Filter | Filtering parameters in the feeding process: 9: The strongest filtering effect. Initial value: 7; Range: 0~9 |
| | Discharge Filter | Filtering parameters in the discharge process: 9: The strongest filtering effect Initial value: 3; Range: 0~9. |
| 12. Result Hold | | Optional on/off;Set to "on", the weight of the controller is fixed at the weight of the fixed value after the fixed value, and the real-time weight will be displayed when the weight of the discharge (loose bag) is lower than half of the target value.Initial value: OFF. |
| 13.Run Zero Num | | Activate the reset count, this parameter only takes effect when the reset interval is set to 0. During operation, each scale performs a reset before adding material. After completing the set number of times, the reset before adding material will no longer be performed. If the value is set to 0, it means that the function is not enabled. Note: When entering the first quantitative process in operation, the instrument will not reset before adding material, starting from the second scale . Initial value: 0, Range 0~9. |
| 14.Delay Before Zero | | Delay before resetting: In the running state, after completing the "pre feeding delay", if it is necessary to reset (when the automatic reset interval is reached or reset is started), this delay is added before the reset is determined to be stable. Initial value: 0.0s, Range :0.0~9.9s. |

4.4 Maintenance



4.4.1 Scale Structure

| Item parameter | Description |
|----------------------------------|---|
| 1. With hopper parameter setting | a. Scale Structure Net Weigher; Optional:Net Weigher/Gross Weigher / Bulk scale mode. Set corresponding parameters according to different scale structures. |
| | b. Working mode A bucket is optional: A bucket AB double scale, A bucket alone A scale, A bucket alone B scale, double bucket double clip bag AB independent, double bucket double clip bag AB combination; Initial value: a bucket AB double scale. |
| | c. Filling control method Single Ctrl/Combo Ctrl is optional; Initial value: Combo Ctrl. Combo Ctrl: fast feeding large, medium and small feeding port at the same time; Add medium and small feeding port at the same time feeding; Slow time small feeding port feeding. Single Ctrl: fast and large feeding port feeding; Add when the feeding port feeding; Slow time small feeding port feeding. |
| | d. Fill Gate Driver 0 Air Drived mode; 1 Step motor 2. Motor mode |
| | e. Clamper Driver 0 Air Drived mode; 1 Step motor; 2、 Normal Motor(Two Pos. Signal); 3 Normal Motor(One Pos. Signal) Default value: 0 Air Drived |
| | f. Discharge mode 0 Air Drived mode; 1 Step motor; 2 Normal Motor(One Pos. Signal) 3 Normal Motor(Two Pos. Signal); 4 Normal Motor Rotating Default value: 0 Air Drived |
| | g. Manual Unlock Bag Optional on/off; Set to "on", in operation, need to manually control unlock bag. Initial value: off. |
| | h. Hopper Capacity The bucket mode is effective. The Hopper Capacity is weighed and the number of discharging times is calculated with the target value. |
| | i. Bag Lock Required (Manual DISC) In the bucket mode stop state, set to "on", manual unloading, the bag clamping signal switch should be judged, after the bag clamping is allowed to discharge.Initial value: off. Note: In the dual bucket and double clip bag AB independent and double bucket and double clip bag AB combination mode, manual unloading can judge the loose bag switch is on. During unloading, the clip bag status of scale A and scale B will be detected respectively. |
| | l.No Position Signal For Fill Gate In stepper motor mode, on/off is optional; Set to "on", after the switch is turned on, there is no need for a signal to close the feeding door. |
| | m. No Position Signal For Clamper In stepper motor mode, on/off is optional; Set to 'on', after the switch is turned on, the loose bag does not require a signal to be in place. |

| | | |
|-------------------------------------|---|---|
| | n. No Position Signal DISC Gate | In stepper motor mode, on/off is optional; Set to "on", after the switch is turned on, the unloading door does not require a signal to be in place. |
| | o. Double scale loose bag mode (Note: double hopper double clamp bag AB combination mode has this parameter) | <p>Double scale loose bag mode Optional: Close, simultaneous bag loosening Normal mode, simultaneous bag loosening fast mode. Initial value: Off.</p> <p>1, loose bag normal mode One scale has completed the discharging, the other scale has not yet completed the discharging, waiting for the completion of the other two scales, then loose bag at the same time.</p> <p>2, loose bag fast mode In this mode, the default A scale is in the front and B scale is in the back. When the discharging of A scale is completed, it will release the bag directly without judging whether B is completed. After the completion of discharging, B should wait for the completion of discharging on scale A, and the two scales will loosen the bag at the same time.</p> <p>Note: After this switch is turned on, if the conveyor is also turned on, the controller will not control the conveyor start and stop. The external conveyor is always in run status. (This function is included in the Turkish version)</p> |
| 2. Without hopper parameter setting | a. Scale structure | Gross Weigher; Optional: Net Weigher/Gross Weigher / Bulk scale mode. Set corresponding parameters according to different scale structures. |
| | b. Working mode | Single A scale Without hopper, Single B scale Without hopper, A/B NoneHopper, A+B NoneHopper |
| | c. Filling control method | Single Ctrl/Combo Ctrl is optional; Initial value: Combo Ctrl. Combo Ctrl: fast feeding large, medium and small feeding port at the same time; Add medium and small feeding port at the same time feeding; Slow time small feeding port feeding. Single Ctrl: fast and large feeding port feeding; Add when the feeding port feeding; Slow time small feeding port feeding. |
| | d. Filling mode | 0 Air Driven mode; 1 Step motor feeding; 2 Motor mode |
| | e. Clamper Driver | 0 Air Driven; 1 Step motor; 2 Normal Motor(Two Pos. Signal); 3 Normal Motor(One Pos. Signal) Default value: 0 Air Driven |
| | f. Manual Unlock Bag | Optional on/off; Set to "on", in operation, need to manually control loose bag.(Note: in the combinatorial mode of AB without bucket, this parameter and the allowable loose bag switch in operation cannot be opened at the same time) Initial value: off. |
| | g. G/N Packing | Gross/Net mode is optional; In the net weight packaging mode, the tare weight is |

| | | |
|--|---|---|
| | | cleared at the beginning of quantification, and the quantitative packaging process is carried out with the net weight value. Initial value: Net Mode. |
| | h. Unlock Bag(None Hopper) | Loosen bag mode optional: Asynchronous,Synchronize,Simi-. Synchronize .Initial value: Asynchronous (Note: Only the combinatorial mode without bucket AB has this parameter) 1. Synchronize (Loose bag normal mode) For example, one scale has finished feeding another scale has not finished feeding, waiting for the completion of another scale at the same time after the two loose bags. If a scale has finished feeding, the other scale is not in the bag (feeding) state, then do not wait for another scale, this scale directly loose bag. 2. Simi-. Synchronize(loose bag fast mode) In this mode, scale A is placed in front of scale B.For example, scale A will directly loosen the bag without judging whether B is finished after feeding. After the completion of feeding, B shall judge whether A is in the state of bag clamping (feeding). If A is feeding, B shall wait for A to loosen the bag after the completion of feeding.If A is not feeding, B will loosen the bag without waiting. |
| | i. Disable Unlock Bag When Running | Optional on/off; Set to "on", no bucket mode, feeding, need to manually control loose bag. Initial value: off. (Note: In the combinatorial mode of AB without bucket, this parameter and manual loose bag switch cannot be opened at the same time.) |
| | l.No Position Signal For Fill Gate | In stepper motor mode, on/off is optional; Set to "on", after the switch is turned on, there is no need for a signal to close the feeding door. |
| | m. No Position Signal For Clamper | In stepper motor mode, on/off is optional; Set to 'on', after the switch is turned on, the loose bag does not require a signal to be in place. |
| 3.Bulk scale mode parameter setting | a. Scale structure | Bulk scale: Optional:Net Weigher/Gross Weigher / Bulk scale mode. Set corresponding parameters according to different scale structures. |
| | b. Working mode | Bulk is optional: Bulk single hopper A , Bulk single hopper B, Bulk scale AB independent, Bulk scale AB Interlock; Initial value: Bulk scale AB independent. |
| | c. Filling control method | Single Ctrl/Combo Ctrl is optional; Initial value: Combo Ctrl. Combo Ctrl: fast feeding large, medium and small feeding port at the same time; Add medium and small feeding port at the same time feeding; Slow time small feeding port feeding. Single Ctrl: fast and large feeding port feeding; Add when the feeding port feeding; Slow time small feeding port feeding. |
| | d. Filling mode | 0 Air Drived mode; 1 Step motor feeding; 2 Motor mode |

| | |
|------------------------------------|--|
| e. Discharge mode | 0 Air Drived mode; 1 Step motor; 2 Normal Motor(One Pos. Signal) 3 Normal Motor(Two Pos. Signal); 4 Normal Motor Rotating Default value: 0 Air Drived |
| f. Hopper Capacity | The bucket mode is effective. The Hopper Capacity is weighed and the number of discharging times is calculated with the target value. |
| g.Flow window length | Sampled times is used to calculate the current flow value. Initial value: 5 ; range: 1~6 . |
| h.No Position Signal For Fill Gate | In stepper motor mode, on/off is optional; Set to "on", after the switch is turned on, there is no need for a signal to close the feeding door. |
| i. No Position Signal DISC Gate | In stepper motor mode, on/off is optional; Set to "on", after the switch is turned on, the unloading door does not require a signal to be in place. |

4.4.2 Peripheral ON/OFF

This parameter sets the switch of instrument peripheral. If set on, peripheral parameters of the main interface can be set. Refer to [Chapter 4.5](#) for specific peripheral parameters. Patting bag, sewing machines, conveyors, and coding are invalid in bulk material mode.

| Item parameter | Description |
|-------------------|--|
| Patting Mode | Patting bag mode selection: Initial value: Disable. Optional: Bucket mode: Disable/When Hold(patting bag after fixed value) is optional When the multi scale switch is turned on, Disable and When Filling is optional; No bucket mode: Disable /When Filling (after fixed value beat bag)/All Time(feeding in the bag/feeding in the bag after fixed value all patting bag) |
| Sewing ON/OFF | Whether to turn on the function of the sewing machine.On and OFF are optional. When turn to ON, the peripheral device can start to sew the bag, and the parameters of the sew machine can be set. |
| Conveyor ON/OFF | Whether to activate the conveyor function. Initial value: close; Close, 1 Conveyor, 2 Conveyor, and 3 Conveyor are optional. When it is a level 1 conveyor/level 2 conveyor/level 3 conveyor, the external equipment starts the conveyor function, and the conveyor parameters in the external equipment can be set. (Note: The use of level 2 and level 3 conveyors is only allowed when the bucket weighing function is turned on, otherwise only level 1 conveyor is allowed.) |
| Coding ON/OFF | Whether to enable the coding function.On and off are optional. When on, the peripheral starts coding function, and the coding parameters can be set. |
| DISC Shaking Mode | Whether to open the discharge shaking switch.Optional :Close,Individual Shaking ,DISC Shaking. When not turned off, the external device enables the unloading vibration function, and the unloading vibration parameters can be set. |
| Auxiliary Pulse | Whether to enable auxiliary pulse function.On and off are optional. When |

| | |
|-------------------|--|
| ON/OFF | on, this function is enabled by peripherals and auxiliary pulse parameters can be set. |
| Fill&DISC Monitor | Whether to turn on the Fill&DISC Monitor.On and off are optional. When on, the peripheral enables this function, and the timeout alarm parameter can be set. |

4.4.3 Communication Setting

GM9907 provides two serial communication interface; See [Section 2.5](#) for the definition of serial port output; Correct setting of port parameters can be used for communication.

| Item Parameters | Description |
|---|---|
| Serial port parameters (Serial port 1(RS232), Serial port 2(RS485)) | |
| 1. ID No. | Initial value: 1. Option: 1~99. |
| 2. Communication mode | Initial value: Modbus-RTU.Modbus-RTU / Print / Continuous mode/ Re-ContA/Re-ContB |
| 3. Baud rate | Initial value: 38400; 9600/19200/38400/57600/115200 |
| 4. Data format | Initial value: 8-E-1 (8 data bits - even parity -1 stop bit). Option: 8-E-1/8-N-1/7-E-1/7-N-1. |
| 5. Modbus Hi-Lo | Modbus communication mode: Initial value: AB-CD (High word first). Option: AB-CD (High word first) / CD-AB (Low word first). |
| Ethernet parameters | |
| 1. Communication Mode | Fixed: Modbus-TCP |
| 2.modbus-TCP Hi-Lo | Initial value AB-CD . Range: AB-CD (Hi ahead) / CD-AB (Low word first) |
| 3. port number | Initial value :502, Range 1~65535 |
| 4.IP | Initial value :192, Range 0~255 |
| | Initial value :168 ,Range 0~255 |
| | Initial value :101, Range 0~255 |
| | Initial value :246, Range 0~255 |
| 5.MAC | BC.66.41.9x.xx.xx |
| Print parameters | |
| 1. Auto Print | Optional on/off;When "Open" is selected, the packaging result will be automatically printed out each time the packaging is completed (the serial port is required to select "Print") Initial value: off. |
| 2. Printer Format | Initial value: 24 columns to print; 24 columns to print / 32 columns to print |
| 3. Printing Language | Initial value: Chinese print; Chinese/English printing is optional |
| 4. Print Empty Line Nos. | Number of lines of paper after printing, initial value: 3; Optional 0 ~ 9. |

4.4.4 User Logic Program

Auxiliary logic programming function, can define up to 6 sets of auxiliary logic trigger signals, and can set the effective time and output port after the auxiliary logic signal is triggered, can configure simple logic signal output for the control of other auxiliary equipment, 6 sets of auxiliary logic signals can also control each other.

| Auxiliary logic | Parameter | Descriptions |
|-----------------|-----------|--------------|
|-----------------|-----------|--------------|

| | | |
|-----------------------------|--------------------------------------|--|
| programming parameter 1~6 | | |
| 1. User Logic type (1~6) | OFF (default) | Select the type of auxiliary logic programming signal based on the logic to be implemented. |
| | Delay ON | |
| | Delay OFF | |
| | Delay ON&OFF | |
| | ON Edge Trigger | |
| | OFF Edge Trigger | |
| 2. Logic (1~6) Trigger Type | By Trigger Function (default) | After any one of the 1-12 channels is set as the trigger signal, the input port will be fixed as the trigger signal. |
| | >=or<=weight trigger | After setting the trigger condition, the current weight value is compared with the set weight threshold, and the output is triggered when the condition is met. |
| | IN port 1~12 | If any path in the input port from 1 to 12 is set as the trigger signal, the input can be either the trigger signal or the function signal of the input port. |
| | I/O Module output define | After the trigger signal is set as "an internal function signal", the output is triggered according to the function signal. |
| 3. Trigger Function(IN) | IN1~12 | Initial value: None Select the input port of the ON/OFF corresponding to the function signal. The input port "0 undefined" means that the function is not defined. |
| 4. Trigger Function(OUT) | OUT1~16 | Initial value: None Select the output port of the ON/OFF corresponding to the function signal. The output port "0 undefined" means that the function is not defined. |
| 5. Delay ON Time | Unit:s | Initial value: 0.0; Range: 0.0~99.9s After the trigger signal is valid, the logic output signal is valid only after the delay. |
| 6. Delay OFF Time | Unit:s | Initial value: 0.0; Range: 0.0~99.9s After the trigger signal is invalid, the logic output signal will be invalid after the delay. |
| 7. Output ON Timer | Unit:s | Initial value: 0.0; Range: 0.0~99.9 s The duration after the logic output signal outputs a valid signal becomes invalid at the end of time. |
| 8. Logic Trigger Weight | Consistent with the calibration unit | Initial value: 0.0; Range: 0.0~Maximum range Set the weight value, compare the current weight with the threshold weight, and trigger when the weight value trigger condition is met.(valid when the trigger signal selects ">= or <= weight value") |

Delay ON

- When selected to delay connection **【By Trigger Function】**, the operation is as follows,
 1. Set parameters and I/O Module: type select **【Delay ON】**, if choose **【By Trigger Function】** trigger input port is defined as "1" (I/O Module input port 1 is shown as "auxiliary

logic trigger input 1"), logic output port is defined as "1" (I/O Module output port 1 is shown as "auxiliary logic output 1"), set **【Delay ON Time】** for 2 seconds.

2. Operation: trigger signal input 1 valid, start the delay on time, and continue to be valid until the delay on time 2s ends, the logic output signal port 1 outputs valid, until the trigger signal input 1 is invalid, the logic output signal port 1 also becomes invalid. Refer to diagram below

● When selected to delay on **【Input Port 1-12】**, operation is as follows,

1. Set parameters and I/O Module: trigger signal choose "input port 1 "(can see I/O Module input port 1 is shown as " the definition of the original unchanged", assuming the original definition is started, the function of the input port 1 can be" started "or" signals trigger"), logic output port is defined as 1 (can see the I/O Module output port 1 is shown as " auxiliary logic output 1 "), set the **【Delay ON Time】** as 2 seconds.

2. Operation: trigger signal input 1 valid (start is also valid, the output of the controller operation is valid), start the delay connection time, and continue to be valid until the end of the delay connection time 2s, the logic output signal port 1 is valid, until the trigger signal input 1 is invalid, the logical output signal port 1 is also invalid. The controller will continue to run until an emergency stop signal is given.

● When select delay on I/O Module output define, operation is as follows,


1. Set parameters and I/O Module: trigger signal is "run" (I/O Module output can be defined or not), the logic output port is defined as 1 (can see the I/O Module output port 1 is shown as auxiliary logic output 1), and the **【Delay On Time】** is set to 2 seconds.

2. Operations: after input "start", "run" the output signal is valid, begin **【delay on time】**, valid until 2 s delay on time after the logic output signal output port 1, until the "stop or pause" and effective "run" after the output signal is invalid, logic output signal port 1 void.

● When select delay on \geq or \leq weight value trigger, operation is as follows:


1. Set the corresponding threshold weight, logic output port is defined as 1 (it can be seen that the output port 1 of the I/O Module is shown as the auxiliary logical output 1), and the **【Delay ON Time】** is set to 2 seconds.

2. Operation: when weight value \geq or \leq logic 1 threshold weight is set to valid, starts **【Delay ON Time】**, It will remain in valid until the delay time 2s is over, logic output signal port 1 outputs valid, Port 1 of logic output signal is not valid until the current weight $<$ or $>$ logic 1 threshold weight is set.




Delay OFF

Relevant parameters : type selections【Delay OFF】, choose【Trigger Type】, set【Trigger input port】, 【Logic output port define】, 【Delay OFF Time】. Operations refer to “Delay ON”. Output functions as below:




Delay on and delay off

Relevant parameters : type selections 【Delay ON&OFF】, choose 【Trigger Type】, set 【Trigger input port】, 【Logic output port define】, 【Delay on】, 【Delay off】. Operations refer to “Delay on”. Output functions as below:




ON Edge Trigger

Relevant parameters : type selections 【ON Edge Trigger】, choose 【Trigger Type】, set 【Trigger input port】, 【Logic output port define】, 【Delay on】.Operations refer to “Delay on”. Output functions as below:



OFF Edge Trigger

Relevant parameters : type selections **【OFF Edge Trigger】**, choose **【Trigger signal】**, set **【Trigger input port】**, **【Logic output port define】**, **【Delay on】**. Operations refer to “Delay on”. Output functions as below:



4.4.5 Reset

Administrators and system administrators can restore and backup data through the restore factory in "Maintenance".

| | |
|-------------------------------------|---|
| 1. Reset All(Except Calibration) | Click this item to restore all parameters of the meter (except calibration parameters) to factory setting values. |
| 2. Reset All | Click this item to restore all parameters of the controller to factory setting values. |
| 3. Reset Calibration | Click this item to restore the calibration parameter value to factory setting value. |
| 4. Reset Weight And Scale Structure | Click this item to restore the property parameters of weighing and weighing body to the factory setting value. |
| 5. Reset Recipe | Click this item to restore formula parameter value as factory setting value. |
| 6. Reset Communication | Click this item to restore communication setting parameter value is factory setting value. |
| 7. Reset Peripherals Parameter | Click this item to restore peripheral parameter values and peripheral switch to factory setting values. |
| 8. Reset Motor Parameter | Click this item to restore motor parameter value to factory setting value. |
| 9. Reset I/O Function | Click this item to restore switch value definition parameter value as factory setting value. |
| 10. Reset User Logic | Click this item to restore logic programming parameter values to factory setting values. |
| 11. Parameter Backup | Click this meter to backup the current parameter setting values. |
| 12. Recovery From Backup | Click this meter to restore the parameter value to the latest backup value. |
| 13. Delete Parameter Backup | Click this meter to delete the backup parameters. |

4.4.6 Hardware Test

This can check whether the output and input interfaces of the controller are normally connected with external devices through IO test. Before I/O test, I/O test switch on, and then I/O test.

Output Test: under the IO test interface, start the output test, that is, after clicking the corresponding output port button, the color of the interface port will light up. The output state of the corresponding external connection should be valid. If it is invalid, it indicates abnormal connection.

Input Test: in the IO test interface, when the external input signal is valid, the corresponding input port color under the interface will be lit up to green. When the external input is valid, the interface has no response, indicating abnormal connection. Check the power input and wiring of the I/O Module, etc.

4.4.7 Display Style

| | | |
|---------------|-----------------------------|---|
| Display Style | 1. Screen Save Time | Can set the time to turn off the screen. Default: Always ON; can choose Always ON, 60s, 10min, 30s, 5 min, 30 min. |
| | 2. MainPage Style | Optional: Easy Data Style and Easy Test Style. Default: Easy Data Style. |
| | 3. Permission Auto Log-out | Permission exit time setting. can choose 5 min, 10 min, 20 min, 30 min. |
| | 4. Multiple User Login | Enable multi-user login function to set the number of users logged in |
| | 5. Number Of Users | The multi-user login switch is turned on to set the number of users logging in |
| | 6. Backlight Switch | The screen goes out when the backlight is turned on. |
| | 7. Backlight Length of Time | Turn on the backlight and set the backlight time. When the time is over, the screen goes out. Click the screen to re-light up. Initial value: 15s; Range: 15~1800.(s) |
| | 8. Clear Sum | Clear accumulated rights. Initial value: Operator; Operator, Technician, Administrator. |

4.5 Peripheral Parameter

Click the **【Peripheral】** menu bar in the main interface (Note: the corresponding peripheral switch in system maintenance parameters is turned on, and the corresponding peripheral parameters can only be seen)

| Parameter | Description |
|---|---|
| Patting (Pat bag parameters setting) | |
| 1. Patting Mode | Pat bag after hold value; (The peripheral switch mode of this item is: the following parameters can only be used after the set value) |
| 2. Patting PreDelay Timer | When start to pat bag, output is valid after this delay time.. Initial value: 0.5 range: 0.0 to 99.9s. |
| 3. Patting ON Timer | Pat bag effective time through a cycle. Initial value: 0.5, range: |

| | |
|-----------------------------------|---|
| | 0.0 to 99.9 s. |
| 4. Patting OFF Timer | Pat bag ineffective time through a cycle. Initial value: 0.5, range: 0.0 to 99.9 s. |
| 5. Patting Times (HOLD) | Pat bag times setting after valuing. Initial value: 4, range: 0 ~ 99. |
| 6. Extra Patting Timer | Only applied in no hopper mode. One extra ON timer will be added when patting completed. Initial value: 0.Range: 0.0~99.9s. (Note: After patting bag, bag unlocked delay timer should be longer than extra ON timer to ensure bag unlocked after patting bag.) |
| 7. Start-Up Weight | Start to pat bag once value reach initial weight. Initial value: 0, range: 0~full capacity. |
| 8. Patting Times (Filling) | The number of pats corresponding to the weight of the pats is valid in the no-bucket mode. The number of pats is set as a parameter in feeding. If set to 0, no pats are allowed.(Note: When the feeding process enters slow feeding, force the end of the punching bag in feeding, no matter whether the punching bag is completed or not) Initial value: 0, range: 0 ~ 99. |
| Sewing/Conveyor Parameters | |
| 1. Sewing ON/OFF | Set to "ON",start sewing function |
| 2. Sewing Start Delay Timer | After sewing input valid, delay this time, sewing output valid. Initial value:0.5s range 0.0~99.9s |
| 3. Sewing ON Timer | Sewing output valid time. Initial value: 4.0s Range: 0.0~99.9s |
| 4. Cutter Start Delay Timer | Cutter output valid time. Initial value: 0.5s Range:0.0~99.9s After sewing ON Timer is over,starts Cutter Start Delay Timer.Initial value 0.5s range 0.0~99.9s |
| 5. Cutter ON Timer | Cutter output valid timer Initial value:0.5s Range: 0.0~99.9 (s) |
| 6. Sewing Stop Delay Timer | Cutter work finished, sewing starts, when Sewing Stop Delay is over, it stops. Initial value: 0.5s Range:0.0~99.9s |
| 7. Sewing Delay Timer | Prevent the abnormal operation of the sewing machine caused by the photoelectric jitter of the machine starting.During the de-shaking time, the photoelectric jitter of the baling machine, but at this time, the output of the baling machine is still valid Initial value: 0.3 Range: 0.0~99.9 (s) |
| 8. Conveyor ON/OFF | ON/OFF. With conveyor output function if set ON. Initial value: OFF. Valid in no hopper mode. |
| 9. Conveyor 1 Start Delay | In no hopper mode, Conveyor start completed after this delay |

| | |
|--|--|
| Timer | timer. Initial value: 0.5 , range: 0~99.9s . |
| 10. Conveyor 1 Running Timer | In no hopper mode, conveyor running time setting. Initial value: 4.0 range: 0 - 99.9s . |
| 11. Conveyor 2&3 Max Run Time | 2/3 of the running time of the conveyor. Conveyor 2/3 running time=Conveyor 3 running time, Conveyor 2 running time=Conveyor 2/3 running time - Conveyor 1 running time Initial value: 30.0 range: 0 - 99.9s . |
| 12. Scale B Traffic void Delay | In A+B NoneHopper and A+B Dual Clampers mode, there is a delay in filling to scale B, which in order to prevent the immediate filling of the bag after bag locked and causing the bag below to withstand the filling bag. Initial value: 2.0 range: 0 - 99.9s . |
| Coding/ DISC Shaking Parameters | |
| 1. Coding ON/OFF | ON/OFF. Controller has coding output function if set ON. Initial value: OFF. |
| 2. Coding Start Delay Timer | Bag locked completed, coding output is valid after this delay. Initial value: 0.5 , range: 0.0 ~ 99.9s . |
| 3. Coding Timer | Coding output effective time. Initial value: 0.5 , range: 0.0 ~ 99.9s . |
| 4. Disable Fill/Discharge When Coding | ON/OFF. Not allow to filling output (no hopper mode) or discharging output (with hopper mode) in coding process. Initial value: OFF. |
| 5. DISC Shaking ON/OFF | When set to "ON", when discharge starts shaking function |
| 6. DISC ON Timer | Discharge patting is on; the valid discharge time is the time from the output discharge signal to the discharge completion when the discharge delay is started. After discharge exceeds the valid time of discharge, discharging patting is started. Initial valid:2.0s, Range: 0.0~9.9s |
| 7. DISC Shaking ON Timer | Initial value: 0.5s, Range:0.0~9.9s (s) |
| 8. DISC Shaking OFF Timer | Initial value: 0.5s, Range:0.0~9.9s (s) |
| 9. DISC Shaking Times | Initial value: 10 , Range: 0~99 |
| Auxiliary Pulse | |
| 1. Auxiliary Pulse ON/OFF | When set to "ON", Auxiliary pulse start |
| 2. Auxiliary Pulse 1 Execute Time | Total execution time of auxiliary pulse 1. If it's 0, it loops forever, Initial Value 0, range 0.0~999.9s (s) |
| 3. Auxiliary Pulse 1 ON Time | Initial value:10.0s, Range:0.0~999.9s (s) |
| 4. Auxiliary Pulse 1 OFF Time | Initial value:10.0s, Range:0.0~999.9s (s) |

| | |
|------------------------------------|--|
| 5. Auxiliary Pulse 2 Execute Time | Total execution time of auxiliary pulse 2. If it's 0, it loops forever, Initial Value 0, range 0.0~999.9s (s) |
| 6. Auxiliary Pulse 2 ON Time | Initial value:10.0s, Range:0.0~999.9s (s) |
| 7. Auxiliary Pulse 2 OFF Time | Initial value:10.0s, Range:0.0~999.9s (s) |
| 8. Auxiliary Pulse 3 Execute Time | Total execution time of auxiliary pulse 3. If it's 0, it loops forever, Initial Value 0, range 0.0~999.9min (min) |
| 9. Auxiliary Pulse 3 ON Time | Initial value:10.0s, Range:0.0~999.9s (min) |
| 10. Auxiliary Pulse 2 OFF Time | Initial value:10.0s, Range:0.0~999.9s (min) |
| 11. Auxiliary Pulse 4 Execute Time | Total execution time of auxiliary pulse 4. If it's 0, it loops forever, Initial Value 0, range 0.0~999.9min (min) |
| 12. Auxiliary Pulse 4 ON Time | Initial value:10.0 min, Range:0.0~999.9min (min) |
| 13. Auxiliary Pulse 4 OFF Time | Initial value:10.0 min, Range:0.0~999.9min (min) |
| Overtime Alarm | |
| 1.Fill&DICS Monitor ON/OFF | Fill, DICS overtime ON/OFF When turn on, starts judging, initial value: OFF |
| 2.A:Co-Fill Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 3.A:Me-Fill Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 4.A:Fi-Fill Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 5.A: DISC Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 6.B:Co-Fill Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 7.B:Me-Fill Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 8.B:Fi-Fill Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 9.B: DISC Overtime | Initial value 5.0,Range 0.0~99.9 (s) |
| 10.Fill Timeout Handle | Initial value: Alarm And Finish Fill, Range: 0~2; 0:Only Alarm .The alarm persists and needs to be manually cleared 1:Alarm And Stop . The instrument automatically enters a stop state and outputs a feeding timeout alarm. Continuous output requires manual release of the alarm. 2:Alarm And Finish Fill .End feeding and start unloading. When the feeding time exceeds the set feeding timeout, regardless of whether it is currently in fast or slow feeding, the instrument outputs a feeding timeout alarm and automatically ends feeding to enter the subsequent process. |
| 11.Fill Timeout Lower Limit | Initial value: 0 , Range: 0~ full capacity; After the filling starts, if the current weight is lower than this value after the |

| | |
|-------------------------|--|
| | feeding timeout, the feeding timeout processing will not be executed, and the fast feeding state will continue to be maintained; Otherwise, the feeding timeout will be processed. (If set to 0, the feeding timeout processing will not be executed directly) |
| 12. Disc Timeout Handle | Initial value: Alarm And Finish Disc, Range:0~2; 0: Only Alarm . The alarm persists and needs to be manually cleared 1: Alarm And Stop . When the unloading time exceeds the set unloading timeout, the instrument automatically enters a stop state and outputs an unloading timeout alarm. The alarm persists and needs to be manually cleared 2: Alarm And Finish Disc . End unloading and start feeding. When the unloading exceeds the limit, the instrument outputs an unloading timeout alarm and automatically ends unloading and enters the next scal |

4.6 Motor Parameter

System maintenance parameters scale "Fill Gate Driver," Clamper mode" and " DISC mode" are set to the motor, the following parameters can be seen.

- ◆ Right side is motor group, can swift

| Parameter | Description | |
|--|---|--|
| Filler | | |
| 1. Gate Driver | 0:Air Driven, 1: Step Motor, 2: Motor mode. (Note: Select the corresponding feeding motor mode and set the corresponding parameters) | |
| 2. Gate Pos. Signal | ON:If Closed Positive logic (If input is valid, gate closed ready). OFF: If Closed(If input is invalid, gate closed ready). | |
| 3. Motor Linker | Set receipt ID relate to Motor ID | |
| 4. Close Overtime | Default value: 4.0, range: 0.0~99.9. (s) | |
| 5.Step Motor Config(Scale A Filler/Scale B Filler) | a. Filler Motor Freq | Filling motor frequency Default value: 12000, range: 1~50000. (Hz) |
| | b. Power-On Go 0 Pos. Freq | Power-On Go, Feeding motor returns to the origin at this frequency. Initial value: 2000 ; range: 1~50000 (Hz) |
| | c. Motor Steps(Fi-F) | Fine Flow pulse quantity .Default value: 1800, range: 1 ~ 60000. |
| | d. Motor Steps(Me-F) | Medium Flow pulse quantity .Default value: 4300, range: 1 ~ 60000. |
| | e. Motor Steps(Co-F) | Coarse Flow pulse quantity .Default value: 7750, range: 1~60000. |
| | f.Fi-F,Me-F, Co-F Test Button | Test shortcut key, check the opening status of the controller, and is beneficial to quickly adjust the pulse number |
| | g. Start Freq | A Motor Start Freq Default value: 2000, range: 1~50000 (Hz) |

| | | |
|--|---------------------------------|---|
| | | (this value can't bigger than A Motor Start Freq) |
| | h. ACC Time | A Motor ACC Time Default value: 100 , range: 0~9999 (ms) |
| | i. DEC Time | A Motor DEC Time. Default value: 50 , range: 0~9999 (ms) |
| | j. Filler Gate DIR Type | Filler Gate DIR Type OFF:Gate Open Direction: when the feeding door is opened, the rotation direction signal output of the feeding stepper motor is invalid, and the direction signal output is effective when the closing action is closed ON:Gate Open Direction: when the feeding door is opened, the rotation direction signal output of the feeding stepper motor is effective, and the direction signal output is invalid when the closing action is closed |
| | k.Motor Steps For Closed | The addition of materials in the scale structure does not require the signal switch to be turned on. The closing of the door requires multiple pulses. Default value: 100 , range: 1-60000 |
| 6. Motor Config(Scale A/Scale B Filler) | a. Fi-Fill Gate Open Time | Fi-Fill Gate Open Time .Default value: 0.2 , range: 0~99.99 (s) |
| | b. Me-Fill Gate Open Time | Me-Fill Gate Open Time.Default value: 0.4 , range: 0~99.99 (s) |
| | c. Co-Fill Gate Open Time | Co-Fill Gate Open Time.Default value: 0.8 , range: 0~99.99 (s) |
| | d. Fi-F, Me-F, Co-F Test Button | Test shortcut key, check the opening status of the controller, and is beneficial to quickly adjust the pulse number |
| Clamper | | |
| 1. Driver | | Air Drived,Step Motor,Normal Motor(Two Pos.Signal), Normal Motor(One Pos.Signal) (Note: Select the corresponding bag clamping mode and set the corresponding parameters) |
| 2. Pos. Signal | | Clamper Pos. Signal Type . ON:If Closed: Is ON, The Filler Gate Closed Firmly OFF:If Closed:Is OFF, The Filler Gate Closed Firmly |
| 3. Close Overtime | | Default value: 3.0 , range: 0.0~99.9 (s) It can be set in both motor two Pos. signal and one Pos. signal modes. |
| 4. Open Overtime | | Default value: 3.0 , range: 0.0~99.9 (s) It can be set in both step motor and two Pos. signal modes. |
| 5.Step Motor Config (A:Clamper/B: Clamper) | a. Clamper Lock Freq | Default value: 30000 , range: 1~50000 (Hz) |
| | b. Clamper Un-lock Freq | Default value: 20000 , range: 1~50000 (Hz) |
| | c. Motor Steps(Bag Lock) | Number of pulse clips in the clamper . Default value: 12000 , range: 1~60000 |
| | d. Power-On Go | Power-On Go, Feeding motor returns to the origin at |

| | | |
|---|--|---|
| | 0 Pos. Freq | this frequency. Initial value: 2000; range: 1~50000 (Hz) |
| | e. Start Freq | Default value: 2000 , range: 1~ 50000 (Hz) (this value can't bigger than A Motor Start Freq) |
| | f. ACC Time | Default value: 200, range: 0.0~9999 (ms) |
| | g. DEC Time | Default value: 50 , range: 0.0~9999 (ms) |
| | h. Clamper DIR Signal Type | Motor direction signal state when bag clamping action of bag clamp ON:If Clamper Open Direction: When the bag is clamped by the bag loosening mechanism, the rotation direction signal output of the stepper motor of the bag loosening mechanism is invalid, while the direction signal output is effective when the bag is clamped OFF:If Clamper Open Direction:: When the bag is clamped by the bag loosening mechanism, the rotation direction signal output of the stepper motor for the bag loosening mechanism is effective, but the direction signal output is invalid when the bag is loosening |
| | i. A:Clamper/B:Clamper Test Button | Shortcut key for clamping clamper bag, which is used to detect the condition of clamping loose bag equipment |
| j. Steps For Clamper Open | Loose bag does not require a signal switch to open, execute multiple pulse counts to close the loose bag. Default value: 100 , range: 1-60000 | |
| 6. Two Pos. Signal parameters (A:Clamper/B:Clamper) | a. A:Clamper/B:Clamper Test Button | Shortcut key for clamping clamper bag, which is used to detect the condition of clamping loose bag equipment |
| 7. One Pos. Signal parameters (A:Clamper/B:Clamper) | a. Clamper Open Time | The effective time of loosening the bag for ordinary motors. Default value: 0.5 , range: 0~99.99 (s) |
| | b. A:Clamper/B:Clamper Test Button | Shortcut key for clamping clamper bag, which is used to detect the condition of clamping loose bag equipment |
| DISC Parameters (Applicable in Net Weigher and bulk modes) | | |
| 1. Gate Driver | Air Driven, Step Motor, Normal Motor (One Pos. Signal), Normal Motor (Two Pos. Signal), Normal Motor Rotating (Note: Select the corresponding discharge motor mode and set the corresponding parameters) | |
| 2. Close Overtime | Default value: 3.0 range: 0.0~99.9 (s) | |
| 3. Gate Pos. Signal | ON:If Closed: Is OFF, The Filler Gate Closed Firmly OFF:If Closed: Is OFF, The Filler Gate Closed Firmly | |
| 4. DISC Gate Pos. Detect | Set to "off", the controller does not need to detect the unloading signal in place all the time, but only needs to detect once when starting filling in each operation. Once the limit signal is detected, there is no need to | |

| | | |
|---|------------------------------|--|
| | | detect the limit signal again. Set to "on", real-time detection of discharge motor is in the limit, if not the limit, shielding feeding output, and alarm prompt, until the limit is detected before resuming filling. |
| 5. Step Motor Config (A:DISC/ B:DISC) | a.DISC Gate Open Freq | Default value: 30000 , range: 1~50000 (Hz) |
| | b. DISC Gate Close Freq | Default value: 20000 , range: 1~50000 (Hz) |
| | c.Motor Steps (DISC) | Number of discharge door pulses.Default value: 12000 , range: 1~60000 |
| | d. Power-On Go 0 Pos. Freq | Power-On Go, Feeding motor returns to the origin at this frequency. Initial value: 2000; range: 1~50000 (Hz) |
| | e. Start Freq | Default value: 2000 range: 1~50000 (Hz) (this value can't bigger than A Motor Start Freq) |
| | f. ACC Time | Default value: 200 , range: 0~9999 (ms) |
| | g. DEC Time | Default value: 50 , range: 0~9999 (ms) |
| | h. DISC Gate DIR Signal Type | Discharging motor from close the door to open the motor direction signal state OFF:If DISC Gate Open Direction: when unloading mechanism opens the door, the rotation direction signal output of unloading stepper motor is invalid, and the direction signal output is effective when closing the door ON:If DISC Gate Open Direction:: when unloading mechanism opens the door, the output of rotation direction signal of unloading stepper motor is effective, and the output of direction signal is invalid when closing the door |
| | i.A:DISC /B:DISC Test Button | A:DISC /B:DISC Test shortcut key |
| 6. Normal Motor(One Pos. Signal) DISC Config (A:DISC/B:DISC) | a.DISC Open Time | A/ B DISC motor door opened signal output timer Default value: 1.00, range: 0.00~99.99 (s) |
| | b.A:DISC /B:DISC Test Button | A:DISC /B:DISC Test shortcut key |
| 7. Normal Motor (Two Pos. Signal) DISC Config (A:DISC/B:DISC) | a.Open Overtime | Default value: 3.0 , range: 0.0~99.9 (s) |
| | b.A:DISC /B:DISC Test Button | A:DISC /B:DISC Test shortcut key |
| 8. Normal Motor Rotating DISC Config (A:DISC/B:DISC) | a.DISC Open Time | A/ B DISC motor door opened signal output timer Default value: 1.00, range: 0.00~99.99 (s) |
| | b.A:DISC /B:DISC Test Button | A:DISC /B:DISC Test shortcut key |

4.7 Statistic

In the main interface, click **【Statistic】** to enter the interface. Under the "Statistic " parameter, the user can view the total accumulation/batch, recipe accumulation, user accumulation, history record and carry out clearing, printing and other operations.

- ◆ Under **【Total ACUM/ Batch】** interface, user can view the total accumulated value , batch times, stock ACUM, permanent CUM and set the stock total. If the serial port is set to print, click **【Data Edit】** to print the total ACUM, export the total ACUM by U-disk, clear the total ACUM and the batch information.
- ◆ In **【total ACUM and Batch】** interface can set batch in net weigher /gross weigher mode and set the stock total in bulk mode. After finish set batch number and the stock total controller in the main interface prompts "Batch Completed" alarm or Delivery and receipt completed " alarm, wait for the user processing, when the "alarm" input signal valid, or press "clear alarm", controller will clear the alarm, or enter stop back to stop state also can clear alarm. (Note: if the total quantity of delivery set to 0, it is the receiving mode , otherwise it's shipping mode)
- ◆ Under **【Recipe ACUM】** , check all receipt ID's ACUM PCS and ACUM weight, press interface right side to swift receipt No. **1-8、9-16、17-24、25-32、33-40**, press **【Data Edit】** to clear all recipe ACUM, print all recipe ACUM, print present recipe ACUM , choose receipt print and export recipe ACUM data by U-disk.
- ◆ Under **【Recipe ACUM】** interface, click on the cumulative recipe you want to delete to delete the cumulative content of the selected recipe.
- ◆ Under **【User ACUM】** interface, to check all users' ACUM PCS and weight, press **【Data Edit】** to clear all users' ACUM data , print all users' ACUM, print present users' ACUM, choose user to print and export user ACUM data by U-disk etc.
- ◆ Under **【User ACUM】** interface, click on the user to be deleted to delete the cumulative content of the selected user.
- ◆ Under **【History Data】** interface, can refer history record, click **【Data Edit】** can export history record by U-disk, can delete history data.

4.8 I/O Module

GM9907-LD has equipped with 12 input ports and 16 output ports if with expansion board to connect with other devices. Click **【IO test】** , Check whether the output and input interfaces of the controller are normally connected with external devices.

The initialization definition of I/O as following, (Output ports **1-16** matches with OUT1~OUT16, Input ports 1-12 matches with IN1~IN12) . Particularly, OUT12, OUT13, OUT14, OUT15, OUT16 is motor control output.

Net Weigher mode:

| Output | | Input | |
|--------|--------------------------------|-------|---|
| OUT01 | Running | IN01 | Start |
| OUT02 | Stopped | IN02 | E-Stop(Emergency stop) |
| OUT03 | A:Co-Fill(Scale A Coarse Flow) | IN03 | A :ZERO |
| OUT04 | A:Me-Fill(Scale A Medium Flow) | IN04 | B :ZERO |
| OUT05 | A:Fi-Fill(Scale A Fine Flow) | IN05 | A: Manual DISC |
| OUT06 | B:Co-Fill(Scale B Coarse Flow) | IN06 | B: Manual DISC |
| OUT07 | B:Me-Fill(Scale B Medium Flow) | IN07 | Bag :Lock/Unlock Request |
| OUT08 | B:Fi-Fill(Scale B Fine Flow) | IN08 | Clear Alarm |
| OUT09 | A :Result Waiting | IN09 | A: Manual Fi-F (Scale A manual Fine Flow) |
| OUT10 | B:Result Waiting | IN10 | B: Manual Fi-F (Scale B manual Fine Flow) |
| OUT11 | A: DISC | IN11 | Change Recipe |

| | | | |
|------------|-------------|------|------|
| OUT12(PWM) | B: DISC | IN12 | Stop |
| OUT13(PWM) | A: Lock Bag | | |
| OUT14(PWM) | A: Patting | | |
| OUT15(PWM) | Alarm | | |
| OUT16(PWM) | Over | | |

Gross Weigher mode:

| Output | | Input | |
|------------|--------------------------------|-------|---|
| OUT01 | Running | IN1 | Start |
| OUT02 | Stopped | IN2 | E-Stop(Emergency stop) |
| OUT03 | A:Co-Fill(Scale A Coarse Flow) | IN3 | Stop |
| OUT04 | A:Me-Fill(Scale A Medium Flow) | IN4 | A :ZERO |
| OUT05 | A:Fi-Fill(Scale A Fine Flow) | IN5 | B :ZERO |
| OUT06 | B:Co-Fill(Scale B Coarse Flow) | IN6 | Bag :Lock/Unlock Request |
| OUT07 | B:Me-Fill(Scale B Medium Flow) | IN7 | B:Bag :Lock/Unlock Request |
| OUT08 | B:Fi-Fill(Scale B Fine Flow) | IN8 | A: Manual Fill (LS) |
| OUT09 | A :Result Waiting | IN9 | B: Manual Fill (LS) |
| OUT10 | B:Result Waiting | IN10 | A: Manual Fi-F (Scale A manual Fine Flow) |
| OUT11 | A: Lock Bag | IN11 | B: Manual Fi-F (Scale B manual Fine Flow) |
| OUT12(PWM) | B: Lock Bag | IN12 | Clear alarm |
| OUT13(PWM) | A:Patting Bag | | |
| OUT14(PWM) | B: Patting Bag | | |
| OUT15(PWM) | Alarm | | |
| OUT16(PWM) | Over | | |

Bulk scale mode:

| Output | | Input | |
|------------|--------------------------------|-------|---|
| OUT01 | Running | IN1 | Start |
| OUT02 | Stopped | IN2 | E-Stop(Emergency stop) |
| OUT03 | A:Co-Fill(Scale A Coarse Flow) | IN3 | Stop |
| OUT04 | A:Me-Fill(Scale A Medium Flow) | IN4 | A :ZERO |
| OUT05 | A:Fi-Fill(Scale A Fine Flow) | IN5 | B :ZERO |
| OUT06 | B:Co-Fill(Scale B Coarse Flow) | IN6 | A: Manual DISC |
| OUT07 | B:Me-Fill(Scale B Medium Flow) | IN7 | B: Manual DISC |
| OUT08 | B:Fi-Fill(Scale B Fine Flow) | IN8 | A: Manual Fill (LS) |
| OUT09 | A :Result Waiting | IN9 | B: Manual Fill (LS) |
| OUT10 | B:Result Waiting | IN10 | A: Manual Fi-F (Scale A manual Fine Flow) |
| OUT11 | A: DISC | IN11 | B: Manual Fi-F (Scale B manual Fine Flow) |
| OUT12(PWM) | B: DISC | IN12 | Clear alarm |

| | | |
|------------|-----------------|--|
| OUT13(PWM) | Batch Completed | |
| OUT14(PWM) | Over/Under | |
| OUT15(PWM) | Last Feed | |
| OUT16(PWM) | Alarm | |

4.8.1 Output port & input port definition

The output port and the input port can be defined according to the application content.

Modify the definition of input and output I/O module paracontrollers through the menu interface I/O module paracontrollers. Each I/O module corresponds to a code, as follows:

I/O module description

| Output | | |
|------------|------------------|---|
| Code | Content | Explanation |
| O0 | None | Undefined if output port is O0. |
| O1 | Running | The output signal is defined valid in run status. |
| O2 | Stopped | The output signal is defined valid in stop status. |
| O3 | A:Co-Fill | To control large discharge opening of scale A filling system. If present weight value<target value –scale A Coarse Flow leading quantity in filling process, output signal is effective. |
| O4 | A:Me-Fill | To control medium discharge opening of scale A filling system. If present weight value<target value –scale A Medium Flow leading quantity in filling process, output signal is effective. |
| O5 | A:Fi-Fill | To control slow discharge opening of scale A filling system. If present weight value<target value –scale A Fine Flow leading quantity in filling process, output signal is effective. |
| O6 | B:Co-Fill | To control large discharge opening of scale B filling system. If present weight value<target value –scale B Coarse Flow leading quantity in filling process, output signal is effective. |
| O7 | B:Me-Fill | To control medium discharge opening of scale B filling system. If present weight value<target value –scale B Medium Flow leading quantity in filling process, output signal is effective. |
| O8 | B:Fi-Fill | To control slow discharge opening of scale B filling system. If present weight value<target value –scale B Fine Flow leading quantity in filling process, output signal is effective. |
| O9 | A: Lock Bag | To control bag locked. Effective signal: bag locked. Ineffective signal: bag unlocked. |
| O10 | A:Result Waiting | Used to indicate scale A filling completed. During Fine Flow complete and material discharge (with hopper mode) or before pat bag (no hopper), output signal is effective. |
| O11 | A: DISC | To control hopper discharge gate. Output signal is effective when start discharging material from hopper A to bag. |
| O12 | B: Lock Bag | To control bag locked system. Effective signal: bag locked. Ineffective signal: bag unlocked. Only effective in no hopper mode. |
| O13 | A:Result Waiting | Used to indicate scale B filling completed. During Fine Flow complete and material discharge (with hopper mode) or before pat bag (no hopper), output signal is effective. |
| O14 | B: DISC | To control hopper discharge gate. Output signal is effective when start discharging material from hopper B to bag. |
| O15 | A:Patting Bag | Used to control pat bag machine. The pulse width and times are controllable. |
| O16 | B: Patting Bag | Used to control pat bag machine. The pulse width and times are controllable. (Only for no hopper mode.) |
| O17 | A:Cutting | Output is effective only during scale A filling period. |

| | | |
|-----|---------------------|--|
| | Gate Open | |
| O18 | B:Cutting Gate Open | Output is effective only during scale B filling period. |
| O19 | FILL Supplement | To control the filling system. When the low material level input defined invalid, the output is effective. When the upper material level defined valid, the output is ineffective. |
| O20 | Supplement Empty | When the low material level input defined invalid, the output is effective. When the upper material level defined valid, the output is ineffective. |
| O21 | A:NearZero | Output port defined effective if scale A current weight is smaller than near-zero value. |
| O22 | B:NearZero | Output port defined effective if scale B current weight is smaller than near-zero value. |
| O23 | Alarm | Output port defined effective if Over/Under or batch times are over. |
| O24 | Batch Completed | Output port defined effective if batch completed. |
| O25 | Over | Signal is effective when over. |
| O26 | Under | Signal is effective when under. |
| O27 | Over/Under | Signal is effective when over or under. |
| O28 | Conveyor Start | To control conveyor starts and stop in gross weigher mode. Effective signal: start. Ineffective signal: stop. |
| O29 | Coding / A Coding | Output this signal when coding delay over and bag locked output is effective. |
| O30 | B Coding | Output this signal when coding delay over and bag locked output is effective. Only for no hopper mode. |
| O31 | A:Filler Gate PWM | When the filling mode is set to a stepping motor controlled fill gate ON/OFF, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT12~OUT16 |
| O32 | A:Filler Gate DIR | When the filling mode is set to a stepping motor controlled fill gate ON/OFF, the output signal is a direction signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT11. |
| O33 | B:Filler Gate PWM | When the filling mode is set to a stepping motor controlled fill gate ON/OFF, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT12~OUT16. |
| O34 | B:Filler Gate DIR | When the filling mode is set to a stepping motor controlled fill gate ON/OFF, the output signal is a direction signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT11. |
| O35 | A:Clamper PWM | When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT12~OUT16. |
| O36 | A: Clamper DIR | When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a direction signal fed to the scale A stepper motor driver to control the motor |

| | | |
|-----|---------------------|---|
| | | rotation. Note: This function can only be defined on one of the port to OUT1~OUT11. |
| O37 | B:Clamper PWM | When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. (Only for no hopper mode) Note: This function can only be defined on one of the port to OUT12~OUT16. |
| O38 | B: Clamper DIR | When the bag lock mode is set to a stepping motor controlled bag locked or bag unlocked, the output signal is a direction signal fed to the scale B stepper motor driver to control the motor rotation. (Only for no hopper mode) Note: This function can only be defined on one of the port to OUT1~OUT11. |
| O39 | A:DISC Gate PWM | When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT12~OUT16. |
| O40 | A:DISC Gate DIR | When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale A stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT11. |
| O41 | B:DISC Gate PWM | When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT12~OUT16. |
| O42 | B:DISC Gate DIR | When the discharge mode is set to a stepping motor controlled discharging, the output signal is a pulse signal fed to the scale B stepper motor driver to control the motor rotation. Note: This function can only be defined on one of the port to OUT1~OUT11. |
| O43 | A:Filler Gate Open | When the filling mode is set normal filling motor controlled the discharge gate, used to control large discharge gate opening of scale A. This signal is valid in filling process and the valid time can be set in the motor parameters. |
| O44 | B:Filler Gate Open | When the filling mode is set normal filling motor controlled the discharge gate, it used to control large discharge gate opening of scale B. This signal is valid in filling process and the valid time can be set in the motor parameters. |
| O45 | A:Filler Gate Close | When the filling mode is set normal filling motor controlled the discharge gate used to control large discharge gate opening of scale A. This signal is valid in the end of Coarse/Medium/Fine Flow until filling limit is effective and the valid time can be set in the motor parameters. |
| O46 | B:Filler Gate Close | When the filling mode is set normal filling motor controlled the discharge gate used to control large discharge gate opening of scale B. This signal is valid in the end of Coarse/Medium/Fine Flow until filling limit is effective and the valid time can be set in the motor parameters. |
| O47 | A:Bag Unlock | When bag locked mode is set normal motor control bag locked/unlocked. Effective signal: bag unlocked. Ineffective signal: bag locked. |
| O48 | B:Bag Unlock | When bag locked mode is set normal motor control bag |

| | | |
|------------|--------------------|--|
| | | locked/unlocked. Effective signal: bag unlocked. Ineffective signal: bag locked. |
| O49 | A:DISC Gate Close | When the discharge mode is set to discharge with a common motor reversing controlling so as to control scale A discharge gate closing. Effective signal: discharge gate closed after discharging. Ineffective signal: stop closing. |
| O50 | B: DISC Gate Close | When the discharge mode is set to discharge with a common motor reversing controlling so as to control scale B discharge gate closing. Effective signal: discharge gate closed after discharging. Ineffective signal: stop closing. |
| O51 | Sewing | Sewing input valid, after the start delay of sewing ends, sewing output is valid. |
| O52 | String Cut | Sewing output valid time ends, this output is valid, The valid time is the output valid time of the cutter |
| O53 | Aux. pulse O1 | Auxiliary pulse 1 input valid, output pulse signal (valid time is auxiliary pulse 1 valid time, invalid time is auxiliary pulse 1 invalid time), stop output when the total execution time is up (If the total execution time is set to 0, the pulse output is always pressed) . |
| O54 | Aux. pulse O2 | Auxiliary pulse 2 input valid, output pulse signal (valid time is auxiliary pulse 2 valid time, invalid time is auxiliary pulse 2 invalid time), stop output when the total execution time is up (If the total execution time is set to 0, the pulse output is always pressed) . |
| O55 | Aux. pulse O3 | Auxiliary pulse 3 input valid, output pulse signal (valid time is auxiliary pulse 3 valid time, invalid time is auxiliary pulse 3 invalid time), stop output when the total execution time is up (If the total execution time is set to 0, the pulse output is always pressed) . |
| O56 | Aux. pulse O4 | Auxiliary pulse 4 input valid, output pulse signal (valid time is auxiliary pulse 4 valid time, invalid time is auxiliary pulse 4 invalid time), stop output when the total execution time is up (If the total execution time is set to 0, the pulse output is always pressed) . |
| O57 | A:DISC Shaking | It is used in the function of discharging patting. Under the running state, the function of starting patting under the condition of incomplete discharge can discharge the material completely. |
| O58 | B:DISC Shaking | It is used in the function of discharging patting. Under the running state, the function of starting patting under the condition of incomplete discharge can discharge the material completely. |
| O59 | User Logic O1 | The output signal of the auxiliary logic output 1 |
| O60 | User Logic O2 | The output signal of the Auxiliary logic output 2 |
| O61 | User Logic O3 | The output signal of the Auxiliary logic output 3 |
| O62 | User Logic O4 | The output signal of the Auxiliary logic output 4 |
| O63 | User Logic O5 | The output signal of the Auxiliary logic output 5 |
| O64 | User Logic O6 | The output signal of the Auxiliary logic output 6 |
| O65 | A:Hanger Up/Down | Metering Hanger Up/Down A output |

| | | |
|------------|------------------------|--|
| O66 | B: Hanger Up/Down | Metering Hanger Up/Down B output |
| O67 | Over /Under | When A exceeds or underranges, the output signal is defined as valid. |
| O68 | B:Over /Under | When B exceeds or underranges, the output signal is defined as valid. |
| O69 | Last Feed | When the signal is valid, the current is the last feed. |
| O70 | Tractor Output | Connect the peripheral tractor. |
| O71 | A:Weight OK | After the calibration of scale A is completed, this signal is valid, but it is invalid during unloading |
| O72 | B:Weight OK | After the calibration of scale B is completed, this signal is valid, but it is invalid during unloading |
| O73 | DISC State | Both scales A and B are effective when unloading from the machine. When any one of the 6 scales under the host is weighed properly, it is valid |
| O74 | Allow Slave1 DISC | Dedicated for unloading interlock host, controlling the allowable unloading of slave machine 1 |
| O75 | Allow Slave2 DISC | Dedicated for unloading interlock host, controlling the allowable unloading of slave machine 2 |
| O76 | DISC Request | Both scales A and B are effective when unloading from the machine. When any one of the 6 scales under the host is weighed properly, it is valid |
| O77 | Lifting Hook | Used to control the bag lifting mechanism, this signal effectively achieves bag lifting; If the signal is invalid, release the hook. (The lifting bag cannot be loosened during the feeding process. The lifting bag can only be loosened after the pre feeding and weighing processes are completed. If the lifting bag is not defined, the lifting bag signal will not be judged.) |
| O78 | Conveyor 2 | Control conveyor 2 to output effectively. |
| O79 | Conveyor 3 | Control conveyor 3 to output effectively. |
| O80 | Conveyor 1 Reverse Run | Control conveyor 1 to reverse output effectively. |
| O81 | Blowing | Used to control the operation of the blowing device. |
| O82 | Return Valve | Used to control the operation of the return valve, this signal is valid when the blowing is completed. |
| O83 | Multifunction Hanger | Used for integrated control bracket and bag. When not performing bag tapping: This switch value is the same as the upward (O65) state of the A measuring bracket. When executing bag tapping: This switch is opposite to the status of bag tapping A (O15). The effective bracket for the bag is invalid, and the bracket for the bag is invalid. |
| O84 | DISC Completed | After the unloading delay of the bucket scale ends, it will output a signal for a period of time, indicating that the unloading is completed. |
| O85 | OUT1 Direct Control | Control switch output 1 through serial port |
| O86 | OUT2 Direct Control | Control switch output 2 through serial port |
| O87 | OUT3 Direct Control | Control switch output 3 through serial port |
| O88 | OUT4 Direct Control | Control switch output 4 through serial port |

| | | |
|--------------|---------------------------|---|
| O89 | OUT5 Direct Control | Control switch output 5 through serial port |
| Input | | |
| I0 | None | Undefined if input port is 00 |
| I1 | Start(PS) | This signal is valid in running status. (Pulse input signal) |
| I2 | E-Stop(PS) | Return to stop state if signal is valid. (Pulse input signal) |
| I3 | Stop(PS) | Finish current package and then return to stop status. (Pulse input signal) |
| I4 | A :ZERO | Clear zero of scale A if signal is effective. (Pulse input signal) |
| I5 | B :ZERO | Clear zero of scale B if signal is effective. (Pulse input signal) |
| I6 | Bag Lock/Unlock Request | To control bag locked/unlocked. Bag locked when first input this signal; bag unlocked if input the signal again. |
| I7 | B:Bag Lock/Unlock Request | To control bag locked/unlocked. Scale B bag locked when first input this signal; scale B bag unlocked if input the signal again. Only for no hopper. |
| I8 | Clear Total ACUM | To clear accumulated weight and times. Accumulated recipes and users total are cleared at the same time. |
| I9 | A :Manual DISC(PS) | Used to manually clear the material in the hopper. Scale A discharge output is valid when input signal is valid, but invalid if again. |
| I10 | B :Manual DISC(PS) | Used to manually clear the material in the hopper. Scale B discharge output is valid when input signal is valid, but invalid if again. |
| I11 | A :Manual Fi-F(PS) | Scale A slow output is valid when first input this signal, invalid if input again. |
| I12 | B :Manual Fi-F (PS) | Scale B slow output is valid when first input this signal, invalid if input again. |
| I13 | A:Manual Fill (PS) | Combination filling mode: Scale A Coarse /Medium /Fine Flow output is valid when first time input the signal. Invalid if input again. Solo filling mode: Scale A Coarse Flow output is valid when first time input the signal. Invalid if input again. |
| I14 | B :Manual Fill (PS) | Combination filling mode: Scale B Coarse /Medium /Fine Flow output is valid when first time input the signal. Invalid if input again. Solo filling mode: Scale B Coarse Flow output is valid when first time input the signal. Invalid if input again. |
| I15 | Change Recipe | Only valid once. Recipe changes to next one which target value is not zero. |
| I16 | Clear Alarm | Clear alarm output. (Pulse input signal) |
| I17 | Supplement Full | To connect upper level of the hopper. (Level input) |
| I18 | Supplement NotEmpty | To connect under level of the hopper. (Level input) Lack materials if invalid.Unlock materials if valid. |
| I19 | Start/E-Stop(LS) | Enter running status if signal is valid, return to stop status if invalid. This is level signal. |
| I20 | Start/Stop(LS) | Enter running status if signal is valid, return to stop status if invalid. This is level signal. |
| I21 | A :Manual DISC(LS) | Manually clear the materials in the hopper. Scale A discharge output is valid if input is effective. |
| I22 | B :Manual DISC(LS) | Manually clear the materials in the hopper. Scale B discharge output is valid if input is effective. |
| I23 | Bag Locked | If the input is defined, valid means ready, invalid means not |

| | | |
|-----|---------------------------|--|
| | | <p>ready.</p> <p>With hopper mode: If bag locked in the running process, the controller will begin to discharge when bag locked ready. In discharge process, will not check the effectivity of signal.</p> <p>No hopper mode: If bag locked in the running process, the controller will begin to fill when bag locked ready. In filling process, will not check the effectivity of signal.</p> <p>This is level input.</p> |
| I24 | B:Bag Locked | <p>If input signal is valid, means bag locked ready and invalid means bag locked not ready.</p> <p>No hopper mode: The controller starts to fill once detect bag locked ready is valid. In filling process, will not check the effectivity of signal.</p> <p>This is level input.</p> |
| I25 | A : DISC Gate Closed Pos. | <p>If the signal is valid, means scale A gate closed ready. If discharge real time detection set ON and detect invalid signal, will shield filling output and alarm, the output controller light will be off. If detect valid signal and have to fill, it will clear alarm automatically and continue to fill. If discharge real time detection set OFF and discharge gate closed not ready, it will alarm. Once detect valid signal, starting to fill.</p> |
| I26 | B : DISC Gate Closed Pos. | <p>If the signal is valid, means scale B gate closed ready. If discharge real time detection set ON and detect invalid signal, will shield filling output and alarm, the output controller light will be off. If detect valid signal and have to fill, it will clear alarm automatically and continue to fill. If discharge real time detection set OFF and discharge gate closed not ready, it will alarm. Once detect valid signal, starting to fill.</p> |
| I27 | A :Manual Fi-F(LS) | <p>Effective signal: Scale A manual Fine Flow output is valid.</p> <p>Ineffective signal: Scale A manual Fine Flow output is invalid.</p> |
| I28 | B :Manual Fi-F (LS) | <p>Effective signal: Scale B manual Fine Flow output is valid.</p> <p>Ineffective signal: Scale B manual Fine Flow output is invalid.</p> |
| I29 | A :Manual Fill (LS) | <p>Combination filling mode: Scale A Coarse/Medium/Fine Flow output are valid if effective input.</p> <p>Solo filling mode: Scale A Coarse Flow output is valid if effective input.</p> |
| I30 | B:Manual Fill (LS) | <p>Combination filling mode: Scale B Coarse/Medium/Fine Flow output are valid if effective input.</p> <p>Solo filling mode: Scale B Coarse Flow output is valid if effective input.</p> |
| I31 | A:Filler Gate Closed Pos. | <p>When stepping motor controls filling gate ON/OFF, it is limit digit input signal for scale A filling gate closed ready.</p> <p>When normal motor controls filling gate ON/OFF, it is limit digit input signal for scale A filling gate closed ready.</p> <p>(Note: this signal is determined by the digit signal type. Positive logic: The filling gate is closed if signal is valid. Negative logic: The filling gate is closed if signal is invalid.)</p> |
| I32 | B:Filler Gate Closed Pos. | <p>When stepping motor controls filling gate ON/OFF, it is limit digit input signal for scale B filling gate closed ready.</p> <p>When normal motor controls filling gate ON/OFF, it is limit digit input signal for scale B filling gate closed ready.</p> <p>(Note: this signal is determined by the digit signal type. Positive logic: The filling gate is closed if signal is valid. Negative logic: The filling gate is closed if signal is invalid.)</p> |
| I33 | A:Bag Released | <p>It is a limit input signal of bag unlocked ready when stepping motor and motor double limit digit controlling bag locked/unlocked.</p> |

| | | |
|-----|--------------------------|---|
| | | (Note: this signal is determined by the digit signal type. Positive logic: Bag unlocked ready if signal is valid. Negative logic: Bag unlocked ready if signal is invalid.) |
| I34 | B:Bag Released | It is a limit input signal of bag unlocked ready when stepping motor and motor double limit digit controlling bag locked/unlocked. (Note: this signal is determined by the digit signal type. Positive logic: Bag unlocked ready if signal is valid. Negative logic: Bag unlocked ready if signal is invalid.) |
| I35 | A:DISC Gate Closed Pos. | When material discharged is controlled by normal motor reversible double limit, it is a signal of discharge gate opening ready and discharge gate open. |
| I36 | B: DISC Gate Closed Pos. | When material discharged is controlled by normal motor reversible double limit, it is a signal of discharge gate opening ready and discharge gate open. |
| I37 | Sewing Start(LS) | When this I/O Module input is valid, start sewing valid output (pulse signal). |
| I38 | Sewing E-Stop t(LS) | When this I/O Module input is valid, sewing stop output (level signal). |
| I39 | Aux. pulse 1 Ctrl | The input is valid, the auxiliary pulse 1 output is valid, the second input is valid, and the auxiliary pulse 1 output is invalid |
| I40 | Aux. pulse 2 Ctrl | The input is valid, the auxiliary pulse 2 output is valid, the second input is valid, and the auxiliary pulse 2 output is invalid |
| I41 | Aux. pulse 3 Ctrl | The input is valid, the auxiliary pulse 3 output is valid, the second input is valid, and the auxiliary pulse 3 output is invalid |
| I42 | Aux. pulse 4 Ctrl | The input is valid, the auxiliary pulse 4 output is valid, the second input is valid, and the auxiliary pulse 4 output is invalid |
| I43 | User Logic 1 Trigger | Custom trigger input signal for auxiliary logic 1. |
| I44 | User Logic 2 Trigger | Custom trigger input signal for auxiliary logic 2. |
| I45 | User Logic 3 Trigger | Custom trigger input signal for auxiliary logic 3. |
| I46 | User Logic 4 Trigger | Custom trigger input signal for auxiliary logic 4. |
| I47 | User Logic 5 Trigger | Custom trigger input signal for auxiliary logic 5. |
| I48 | User Logic 6 Trigger | Custom trigger input signal for auxiliary logic 6. |
| I49 | Fill Permission (LS) | Filling allowed input: if filling allowed input is defined in the I/O Module, judge whether filling allowed input is effective before filling flow. If it is effective, the filling flow will be started. If it is not, wait. |
| I50 | DISC Permission (LS) | DISC allow input is only for with hopper mode, if Disc allowed input is defined in the I/O Module, judge whether Disc allowed input is effective after waiting. If it is effective, the Disc flow will be started. If it is not, wait. |
| I51 | B:Fill Permission (LS) | Filling allowed input: if B filling allowed input is defined in the I/O Module, judge whether B filling allowed input is effective before filling flow. If it is effective, the filling flow will be started. If it is not, wait. |

| | | |
|------------|------------------------------|--|
| I52 | B:DISC Permissoin (LS) | DISC allow input is only for with hopper mode, if B Disc allowed input is defined in the I/O Module, judge whether B Disc allowed input is effective after waiting. If it is effective, the Disc flow will be started. If it is not, wait. |
| I53 | A:Manual Hanger Ctrl | When this input is valid, A Metering hanger upward is valid |
| I54 | B: Manual Hanger Ctrl | When this input is valid, B Metering hanger upward is valid |
| I55 | Slave 1 DISC Request | Unloading interlock host specific, used to obtain unloading requests from slave 1. |
| I56 | Slave 2 DISC Request | Unloading interlock host specific, used to obtain unloading requests from slave 2. |
| I57 | Slave DISC State | Unloading interlock host specific, used to determine whether the slave is unloading. |
| I58 | Blocking | When the congestion input is valid in the bulk accumulation mode, unloading cannot be performed. |
| I59 | Lifting Bag Request | Used to control the action of the bag lifting mechanism. |
| I60 | Conveyor 1 Forward Run | In the stopped state, manually control the conveyor to start and rotate forward. (When the emergency stop signal is valid, the forward rotation output of conveyor 1 is invalid). |
| I61 | Conveyor 1 Reverse Run | Control the conveyor to start and reverse. When the emergency stop signal is valid, the reverse output of conveyor 1 is invalid. |
| I62 | Limit Position Of Conveyor 2 | Conveyor 2 in position signal. |
| I63 | Limit Position Of Conveyor 3 | Conveyor 3 in position signal. |
| I64 | Manual End | In running, the signal input is valid, the instrument automatically enters the result waiting, and the running state to a slow stop state. |
| I65 | No Level De-tection | If the signal is valid once, the instrument will shield the material level function. If it is valid again, the instrument will release the material level shielding. |
| I66 | IN1(Read By COM) | When the input is valid, there will be corresponding valid states in the communication, mainly opening the switch input state for use |
| I67 | IN2(Read By COM) | When the input is valid, there will be corresponding valid states in the communication, mainly opening the switch input state for use |
| I68 | IN3(Read By COM) | When the input is valid, there will be corresponding valid states in the communication, mainly opening the switch input state for use |
| I69 | IN4(Read By COM) | When the input is valid, there will be corresponding valid states in the communication, mainly opening the switch input state for use |
| I70 | IN5(Read By COM) | When the input is valid, there will be corresponding valid states in the communication, mainly opening the switch input state for use |
| I71 | Start/E-Stop(RF) | If the signal is valid, the instrument will enter the running state, and if it is invalid, it will return to the stopping state. This input is an edge detection signal. |
| I72 | Start/Stop RF) | If the signal is valid, the instrument will enter the running state. If it is invalid, it will return to the stopped state after completing the |

| | | |
|--|--|--|
| | | current packaging process. This input is an edge detection signal. |
|--|--|--|

Note: DISC Permissoin description: When working mode is with hopper AB dual scales, dual hopper dual clip bag AB individual, dual hopper dual clip bag AB comb, no hopper AB individual, no hopper AB comb, if define filling/disc flow allow input, then works as follow.

When scale A undefine filling / DISC permission, scale B define filling/disc allow.

Scale A filling/disc is not controlled, run as formal process, scale B need filling/disc allow signal to control.

When scale A define filling/disc allow, scale B undefined filling/disc allow. Scale B filling/disc uncontrolled run as normal process, scale A need filling/disc allow signal to control.

When dual AB both define filling/DISC permission, scale A and scale B need separate filling/dics allow signal to control.

4.9 COM Master mode

Host mode can communicate with slave to send commands. When using host mode, pay attention to the following points:

- ◆ The communication parameters of serial port 2 are fixed in host mode. Only when the communication mode is Modbus-RTU mode can host mode be used, otherwise it is prohibited.
- ◆ In host mode, the starting address is fixed to 1.
- ◆ Successful write will return successful send; Write data failure returns send failure; when there is no return for a long time, the return send timeout.
- ◆ In host mode, changing the high and low bytes of serial port 2 will change the storage order of the data sent to the slave. The high and low bits correspond to each other and can be used when the data length is double word.

| | |
|------------------|--|
| 1. Slave COM ID | Initial value: 1 ; 1 ~99 optional. |
| 2. Data length | Initial value: Word. Word/Dword is optional |
| 3. Start address | Initial value: 1 ; 1~65535 optional, start at 0X0001 by default. |
| 4. Data To Send | Initial value: 0 ; 0 ~ 999999 optional. |

5. Function Description

5.1 Setting the operating mode

1. Scale structure is Net Weigher mode, in each working mode:

| Working Mode | A/B Hopper | A Hopper | B Hopper | A/B Dual Clampers | A+B Dual Clampers |
|-----------------------------------|---|--|--|--|--|
| Individual Target Mode set to OFF | 1) Set the target value to be greater than the hopper capacity of a single bucket, and the target value of a single scale will be automatically converted; 2) Set the target value to be less than or equal to the hopper capacity of a single bucket, and the target value for a single scale to be the target value; | | | | |
| Individual Target Mode set to ON | Set A/B target value to be less than or equal to the hopper capacity of a single bucket | Set the target value of A to be less than or equal to the hopper capacity of a single bucket | Set the target value of B to be less than or equal to the hopper capacity of a single bucket | The target values for A and B can only be set to be less than or equal to the hopper capacity of a single bucket | The target values for A and B can only be set to be less than or equal to the hopper capacity of a single bucket |

Attention: 1) Dual bucket dual bag independent mode. The dual bucket dual bag combination mode has two bag clamping mechanisms, and when started, the dual scales will simultaneously start feeding.

2) The bucket mode generally uses the dual scale working mode, while the other modes are the fault operation mode.

2. Scale structure is Gross Weigher mode

| Working Mode | Target value setting |
|---------------|--|
| A/B NoneHpper | Individual Target Mode set to OFF, AB all use the total target values. |
| | Individual Target Mode set to ON, AB uses A/B target values respectively |
| A+B NoneHpper | Individual Target Mode set to OFF, AB all use the total target values. |
| | Individual Target Mode set to ON, AB uses A/B target values respectively |

5.2 Batch

Batch is used for packaging frequency reminder, when automatic operation is completed and set batch is reached, controller show batch reach, alarm and shutdown, waiting for user to process, batch reach and alarm is valid, user can press **【Clear Alarm】** Key or to "clear alarm" input signal is valid, controller clears alarm. The batch number is zero, and then batch number judgment is not operated.

Batch range is 0~9999.initial default value is 0 (No batch judgment) .

5.3 Filling Level Control

Depending on application difference, controller material tank's level gage mounting has two ways: Dual Supplement (Supplement Full, Supplement Empty), Single Supplement (Supplement Empty) and no filling level control.

5.3.1 Dual Supplement

Supplement full and Supplement NotEmpty are defined, corresponding to the case of dual level. In this situation, controller include filling control function,which control principle is: when Supplement full and Supplement NotEmpty input are invalid, controller filling output is valid, when Supplement full input is valid, filling output is invalid. Meanwhile, before filling (coarse flow, medium flow,fine flow), controller detect supplement empty

if is valid,if invalid wait for signal,only this signal is valid then start filling process.In the filling procession, controller do not detect Supplement NotEmpty signal if is valid.

5.3.2 Single Supplement

Supplement NotEmpty is defined; supplement full is undefined, corresponding to the case of signal level, controller do not contain filling control function, detect supplement empty before filling,waiting for the signal when Supplement NotEmpty is invalid ,only the signal is valid, then start filling process.controller do not detect Supplement NotEmpty signal if is valid when filling.

Supplement NotEmpty and supplement full are undefined, corresponding to the no material level editor. Controller do not control filling, do not detect Supplement NotEmpty signal if is valid when filling.

5.4 Quick Setup

In stop mode, quick modify recipe data stored in real time.

Modification of runtime data, a zero value is stored in real-time, other parameters after exiting the quick setup interface, automatic updates are operated (combined mode need to unlock bags , start to run the next scale then target value is updated) when the next scale started.

Finished modifying the recipe parameters when running, but not yet reached the next scale update, the emergency stop signal is input into the controller, controller in stop mode, recipe update immediately.

The recipe value and advance value can be modified when communicating in modbus protocol.

5.5 U disk update software

5.5.1 Foreground update process

| | |
|----|--|
| 1. | Plug the USB drive containing the upgrade kit "tpcbakup" into the controller |
| 2. | Click "Yes" to enter the system setting interface and start the comprehensive feature pack. Click "No" to exit. "Click" Yes "to pop up the" User Project Update Button " |
| 3. | After clicking the "User Project Update" button, select the project to download |
| 4. | After download will restart automatically |

5.5.2 Background update process

| | |
|----|---|
| 1. | Insert U disk to computer, creat new folder "GM9907 - LD" in the U dish; |
| 2. | Save “GM9907-L-Upload.gm” to folder “GM9907-LD” |
| 3. | Plug the USB disk into the controller, switch to the administrator authority, to the Maintenance – Firmware Update interface, long press the blank in the lower right corner of 5S, and the " Update " button pops up, jump to the upgrade interface, click " Update ", click " Update " again, and the words " Updating " appear, controller is upgrading the background |
| 4. | When the progress bar is finished, the upgrade will be successful after the count-down of 10s and the login interface will be switched to. |

5.6 U disk update boot interface

| | |
|----|---|
| 1. | Save the image file (resolution 800*480, format.bmp) into the root directory of U disk containing the project package (tpcbakup)(Note: the upgrade kit "tpcbakup" is different from this tpcbakup) |
| 2. | Insert U disk to controller |
| 3. | Controller pops up the display of 【USB disk kit】 , and select “Update startup |


| | |
|----|---|
| | bitmap". |
| 4. | Enter the LOGO selection interface, select the picture to be upgraded, and click OK. It will prompt you to restart after successful bitmap update |

5.7 Sewing control

The function of sewing machine involves I/O Module: "Sewing ON ", " Cutter Work ", " Sewing Start ", " Sewing Stop ".

Mode 1 (Sewing ON Timer not 0): Sewing Start (Pulse) signal valid, sewing working process begin, first start is Sewing Start Delay Timer, delay timer finish, sewing starts, then sewing on, Sewing ON Timer finish, starts Sewing Stop Delay, meanwhile starts Cutter Start Delay Timer, Sewing Stop Delay finish sewing output invalid, when cutter Start Delay Timer finish, cutter starts to work, work time is Cutter Work Timer, Cutter Work Timer finish, cutter stop working. Process is finish.

Mode 2 (Sewing ON Timer is 0): Sewing Start (Level Signal) signal is valid, starts Sewing Start Delay Timer, timer finish re-test Sewing Start signal if is valid, if invalid, Sewing ON signal is off, delay timer finish, sewing starts to work, continuous output time is Sewing ON Timer, when Sewing ON Timer is finish, starts Sewing Stop Delay timer, meanwhile starts Cutter Start Delay Timer. Sewing continue work, continuous output time is Sewing Stop Delay timer. Cutter Start Delay timer, when Cutter Start Delay time is finish, cutter starts to work, work time is cutter work timer, cutter work timer finish, cutter stop working.



5.8 DISC Shaking

Individual Shaking:

Example of using the unloading vibration A scale function: Set the DISC shaking mode is individual shaking. When the equipment starts unloading in running state, it starts timing. When the DISC ON Timer exceeds the DISC shaking on timer and the weight of the measured material has not returned to the zero zone, the A:DISC shaking output is valid (this output is a pulse, the effective time is the DISC shaking time, and the invalid time is the DISC shaking OFF timer). After the DISC shaking times is reached, if the current weight of the measuring bucket has not fallen below the zero zone, the instrument will output DISC overtime alarm and return to the stop state. When the DISC shaking times has not reached or just ended, and the weight of the material in the measuring hopper is less than the zero zone value, the DISC delay time is activated. After the delay, the weighing process ends.

DISC Shaking:

Example of using the unloading vibration A scale function: Set the DISC shaking mode is DISC shaking. At this point, the output of the switch quantity to control the discharge door should be selected as A:DISC shaking(the discharge vibration output at this point controls both the discharge door output and the discharge vibration (by opening and closing the discharge door to achieve vibration function)). In running state, when the equipment starts unloading, the "DISC shaking output" is effective and starts timing. When the DISC ON Timer exceeds the set DISC shaking on timer and the weight of the material in the measurement has not returned to the zero zone, the unloading vibration A output is effective (this output is a pulse, the effective time is the DISC shaking time, and the invalid time is the DISC shaking OFF timer). After the DISC shaking times is reached, if the current weight of the measuring bucket has not fallen below the zero zone, the instrument will output an unloading timeout alarm and return to the stop state. When the DISC shaking times has not reached or just ended, and the weight of the material in the measuring hopper is less than the zero zone value, the DISC delay time is activated. After the delay, the weighing process ends.

5.9 Overtime Alarm of filling and discharge function

Take scale A coarse flow filling overtime function for example: turn on the fill&DISC monitor function, in the running state, when Scale A starts coarse flow, starts timing, if scale A coarse flow time exceeds A:Co-fill time, controller output alarm, and back to stop state.

Take scale A discharge overtime function for example: turn on the fill&DISC monitor function, in the running state, when Scale A begins discharge, starts timing, if scale A discharge time exceeds A:Co-fill time, controller output alarm, and back to stop state.

5.10 Auxiliary pulse function

When controller in stop or operate state, I/O module input I39 (Aux. Pulse 1 Ctrl) is valid, then I/O Module output O53 (Aux. pulse O1) starts output, the valid time of continuous output is the valid time of auxiliary pulse 1 output, when time is up, stop output, after waiting for the invalid output time of auxiliary pulse 1 to arrive, the output starts again. Stop output until the total operation time of auxiliary pulse 1 reaches, and input I39 Aux. Pulse 1 Ctrl is invalid. If auxiliary pulse 1 operation total time is set to 0, then the auxiliary pulse output process will continue to loop.

If auxiliary pulse operate process I/O module input I39 (Aux. Pulse 1 Ctrl) is valid, then auxiliary pulse 1 output (O53) will stop output.

5.11 Adaptive function

The adaptive function omits the steps of manual adjustment and can automatically adjust the filling speed and accuracy. After this function is process, it will automatically adjust the parameters of Coarse Flow Remains, Medium Flow Remains, Fine Flow Remains, COMP. Inhibit Timer(Co-F), COMP. Inhibit Timer(Me-F), COMP. Inhibit Timer(Fi-F) and so on in the process of filling, so as to achieve the optimal filling speed and accuracy.(after the is turned on, controller will display the current modified parameters in real time.)

Adaptive use:

Mode 1: set all the advance parameters (set the advance parameters, only roughly accurate), controller will be on the basis of the current advance, according to the changes in the warehouse pressure, etc., constantly modify the advance parameters, to achieve an optimal state.(this method is recommended)

Mode 2: if all the current remains are 0, when the first scale starts, controller will control the scale body and automatically find the corresponding remains. The first scale may be inaccurate, but after a few times of work, will find the corresponding accurate amount to reach an optimal state.

Note:

1. It is suggested to add material level ON/OFF to ensure the stability of material flow. Controller also has the function of judging whether the material flow is stable, but not all of

them can be judged successfully.

2. If drop correction and adaptive function are opened at the same time, the drop correction function will be forcibly closed.


3. In the normal filling process, if there is an occasional overshoot, it can be considered to increase the adaptive level.

5.12 Hanger up control function

In the gross weigher mode, start the controller, controller up signal output, wait for after the up delay, began to tare (net weight), if the patting mode is enabled, the up signals with pat bags for output (patting bag when output is invalid, up, patting bags output is valid, the upside is invalid), when hold after patting bag is the same. When the hanger up signal is invalid, the hanger up delay starts. When the hanger up delay ends, the bag starts to unlock. When the controller is in the stop state, when the hanger up signal is valid, the hanger up; when the up signal is invalid, the hanger down.

5.13 DISC interlock function

Diagram of I/O connections between instruments:



Master: When the master DISC interlock switch is turned on, it is the host, control the discharging from the machine. Define the clamping bag for the host and handle the clamping bag logic.

Slave: When the master DISC interlock switch is turned off, it becomes a slave machine. The clamp bag input is not defined, and the discharging input is defined to control the discharging. When any scale in the interlocking system is weighed, the discharging request output of the host is valid. At this time, an external host bag clamping signal is input. After the bag clamping is completed, only one scale among the weighed scales will unload, and the rest of the scales will continue to wait. After discharging is completed, the host performs a bag loosening action, and continues to wait for the bag to be clamped before discharging another package.


5.14 Binyes multi-scale function

Scale Structure: Net Weigher; Working Mode: A/Bhopper/A hopper/B hopper, and the total target value is greater than the hopper capacity of a single bucket;

Start the instrument, filling to the result waiting, give the instrument bag clamping signal, and then give the instrument bag hanging signal. The instrument bracket has an effective upward output, and wait for the upward delay before reaching the desired position. The instrument begins discharging (the bracket must be in place before discharging). After discharging, the weight returns to the zero zone, and the second scale is used for feeding. When the last scale unloads, the

instrument bag clamp output is invalid, and the bracket begins to descend (the bracket upward output is invalid). After waiting for the downward delay to end, the hanging bag output is invalid. After the downward delay is completed, continue to disconnect the hook upward delay, and when the bracket ascends, the bracket output is valid. The packaging process of the Douduo scale has ended.



5.15 Conveyor 3 level function



The level 3 conveyor currently only supports the binyes multi-scale mode: 3 conveyors are placed under the scale, and the conveyor 1 is placed under the scale, after a bag of materials is decoupled, it is placed on the conveyor 1. Conveyor 2 is behind conveyor 1. Conveyor 3 is behind conveyor 2. The ends on conveyors 2 and 3 respectively have a limit switch (proximity switch).

- 1) After the decoupling upstream process is completed, start the conveyor 1. When material 1 is transferred to conveyor 2, conveyor 2 is started, and the upper limit switch (proximity switch) of conveyor 2 is effective, conveyor 1 is still running and conveying.
- 2) When the material is transported to the conveyor 3, the upper limit switch of the conveyor 3 (proximity switch), when effective, the conveyor 3 stops running and waits for the forklift to shovel the material 1.
- 3) Before starting, when there are materials on conveyor 3 and conveyor 2, that is, when the limit switches of conveyor 2 and conveyor 3 are both effective, conveyor 1, conveyor 2 and conveyor 3 will not rotate, and the materials of conveyor 3 will be shoveled away by the forklift, that is, when the limit switches of conveyor 3 are invalid, conveyor 3 will run. After starting, conveyor 2 limit, conveyor 3 limit no material, conveyor 1 run until the completion of conveyor 1 running time.

Each time you prepare to loosen the bag, determine whether to start conveyor 1, conveyor 2, conveyor 3.



6. Serial port communication

GM9907-LD It provides two serial port, and serial port 1 and 2 can be selected in a continuous manner, Modbus mode, print, Re-ContA and Re-ContB protocol. The controller for the first serial port is RS-232, the second is RS-485. The network port communication is fixed over Modbus-TCP, and the instrument can be cascaded.

6.1 Printing method

When serial port parameter port 1 or 2 choose print mode, corresponding to the serial port can be connected to a serial printer to print the contents accumulated by implementation-dependent.

Print mode communication parameters refer to serial port parameters, need to note:

- 1) **Baud Rate**——parameters need to consist with connected printer.
- 2) **Communication format**——parameters need to consist with connected printer.

Note: When printing options for Chinese language, can not use the data bits to 7 formats, otherwise there will be printing error.

- 3) **Print format**——Peripheral parameters can be setted by print format of 24 or 32 formats. Besides by peripherals parameters printing language is Chinese or English.

6.1.1 Auto Print

In printing mode, the parameters of the peripheral automatically print ON/OFF is set to open. So after each weighing is completed, controller automatically prints the weighing result of this times.

In net weigher and gross weigher mode, the format as follow:

English 24 print formats are as follows:

Packing list

Unit: kg

Recipe Number: 20

The total cumulative number of results

| | |
|---|------|
| 1 | 5.50 |
| 2 | 5.50 |

English 32 print formats are as follows:

Packing list

Unit: kg

Recipe Number: 20

| Total ACUM PCS | target value | result |
|----------------|--------------|--------|
|----------------|--------------|--------|

| | | |
|---|------|------|
| 3 | 5.60 | 5.50 |
| 4 | 6.00 | 5.80 |

In bulk scale mode, the format as follow:

English 24 print formats are as follows:

&

Receipt and delivery list

Scale No.: **1** Recipe ID: 1

Total: 0.00

Time: 2022/01/21 13:30

Unit: kg

| ACUM PCS | Results |
|----------|---------|
| 12 | 13.58 |
| 13 | 13.58 |
| 14 | 13.58 |
| 15 | 13.58 |

English 32 print formats are as follows:

&

Receipt and delivery list

Scale No.: **1** Recipe ID: 20

Total: 0.00

Time: 2022/01/21 13:31

Unit: kg

| ACUM PCS | Results | Total receipt/delivery |
|----------|---------|------------------------|
| 21 | 13.58 | 240.40 |
| 22 | 13.58 | 253.98 |
| 23 | 13.58 | 267.56 |

6.1.2 Total ACUM print

In printing mode, stop, press shortcut key, and enter ACUM and Batch interface, press Print total ACUM.

In bucket scale and no hopper scale mode, the format as follow:

English 24 print formats are as follows:

Total ACUM Report

Time: 2018/6/19 13:28

Unit: kg

Total ACUM PCS: 18

Total ACUM WT: 84.16

English 32 print formats are as follows:

Total ACUM Report

Time: 2018/6/19 13:36

Unit: kg

Total ACUM PCS: 24

Total ACUM WT: 129.40

In bulk scale mode, the format as follow:

English 24 print formats are as follows:

Total ACUM Report

Scale No.: 1 Recipe ID: 1

Total: 0.00

Time: 2022/01/21 13:30

Flow rate:257.30t/h

Total receipt/delivery: 471.26kg

Total ACUM: 471.26kg

English 32 print formats are as follows:

Scale No.: 1 Recipe ID: 1

Total: 0.00

Time: 2022/01/21 13:31

Flow rate:257.30t/h

Total receipt/delivery: 471.26kg

Total ACUM: 471.26kg

6.1.3 Recipe ACUM print

In printing mode, stop, press **【Statistic】** shortcut key, and enter interface. Under the **【Recipe ACUM】** interface, click **【Data Edit】** and select **【Print Select Recipe ACUM Data】** in the pop-up box, then choose the corresponding recipe to print.

Press Print All recipe ACUM, to print all formulations (1 to 40) is accumulated, the

meter will automatically skip the target value 0 is not printed formulations. Format is as follows:

English 24 print formats are as follows:

Recipe ACUM Report
 Time: 2018/6/19 13:29
 Unit: kg

 Recipe ID: 20
 Rec. ACUM PCS: 18
 Rec. ACUM WT: 84.16

English 32 print formats are as follows:

Recipe ACUM Report
 Time: 2018/6/19 13:36
 Unit: kg

 Recipe ID: 20
 Rec. ACUM PCS: 24
 Rec. ACUM WT: 129.40

6.1.4 User ACUM print

In printing mode, stop, press **【Statistic】** shortcut key, and enter interface. Under the **【User ACUM】** interface, click **【Data Edit】** and select **【Print Select User ACUM Data】** in the pop-up box, then choose the corresponding user to print.

Press Print All user ACUM, to print all users (1 to 9) is accumulated, the controller will automatically skip the user's cumulative user 0 is not printed. Format is as follows:

English 24 print formats are as follows:

User ACUM Report
 Time: 2018/6/19 13:29
 Unit: kg

 User ID: 9
 User ACUM PCS: 16
 User ACUM WT: 72.26

English 32 print formats are as follows:

User ACUM Report
 Time: 2018/6/19 13:37
 Unit: kg

 User ID: 9
 User ACUM PCS: 22
 User ACUM WT: 117.50

6.2 Continuous mode

A continuous manner, the meter sends the meter serial port results in outward selected serial communication port 1 or 2 selected.

6.2.1 Continuous mode data frame format is as follows:

| | | | | | | | | | | | |
|------------|-----------|----------|----------|-----------|-----------|------------|---|-------------|------------|-----------|-----------|
| STX | Scale No. | R | T | SP | SP | ACUM Times | , | ACUM Weight | CRC | CR | LF |
|------------|-----------|----------|----------|-----------|-----------|------------|---|-------------|------------|-----------|-----------|

Among them:

R —— **52H**

T —— **54H**

SP —— **20H**

ACUM Times --9 bytes 00000000 to 99999999

ACUM Weight --10 bytes containing the decimal point

Controller such as issue data (in hexadecimal form):

02 30 31 52 54 20 20 20 20 20 20 20 20 20 31 30 30 2C 20 20 20 20 30 2E 35 30 30 30 32 39 0D 0A

It said: # 1 scale, the current cumulative number of 100 times, the cumulative

weight of 0.5000.

6.3 Modbus-RTU protocol

In the serial communication port 1 or 2 is selected Modbus-RTU mode.

6.3.1 Function code and abnormal code

◆ Controller function codes supported:

| Function code | name | Explanation |
|---------------|--------------------------|--|
| 03 | Read register | Up to 125 single read registers |
| 06 | Write Single Register | |
| 16 | Write Multiple Registers | The controller supports a write command is only double register, the address must be aligned, not allowed writing only a portion of the double register is written, allowing read-only portion read out. |
| 01 | Read coil | Note that this is the bit length units |
| 05 | Write coil | |

Note: The controller only supports MODBUS function code above, will not be the controller response function code to other controllers.

◆ MODBUS exception code in response to

| Code | name | Meaning |
|------|----------------------------------|---|
| 02 | Illegal Data Address | For this controller, the data representing the address of the error code is an address not allowed. |
| 03 | Illegal data value | And writing the data portion of the permitted range. |
| 04 | Slave failure | When the controller is attempting to perform the requested operation, resulting in unrecoverable error. |
| 07 | Unsuccessful programming request | For controllers, the the received command can not be executed under the current conditions. |

6.3.2 MODBUS transmission mode

The transmission mode is MODBUS RTU mode.

When communication with the RTU mode, information of each 8-bit byte is divided into two 4-bit transmission character hexadecimal.

Data Format: **8** Data bits, **1Stop** bit, even parity (**8-E-1**)

8 Data bits, **1Stop** bits, no parity (**8-N-1**)

Baud rate: **9600/19200/38400/57600/115200**(Choose one)

Code: RTU

6.3.3 MODBUS address assignment

| Protocol address | PLC address | Meaning | Description | |
|---------------------------|-------------------|------------------------------|--|--|
| Read only register | | | | |
| 0000-0001 | 40001-40002 | Scale A present weight | The weight of scale A on the controller is shown | |
| 0002-0003 | 40003-40004 | Scale A present weight state | Bit | |
| | | | Instructions | |
| | | | D0 | Unstable weight: 0. Stable: 1. |
| | | | D1 | Non-zero:0. Zero: 1. |
| | | | D2 | Symbol of present weight: +/- Positive: 0. Negative: 1. |
| D3 | Overflow | | | |
| D4 | Positive overflow | | | |

| | | | | |
|-----------|----------------|---------------------------------|--|--|
| | | | D5 | Negative overflow |
| | | | D6 | Load cell positive overflow |
| | | | D7 | Load cell negative overflow |
| | | | D8 | Stable millivolt: 1. Unstable: 0. |
| | | | D9~ 31 | Reserve |
| 0004-0005 | 40005-40006 | Scale B present weight | The weight of scale B on the controller is shown | |
| 0006 | 40007 | Scale B present weight state | D0 | Unstable weight: 0. Stable: 1. |
| | | | D1 | Non-zero:0. Zero: 1. |
| | | | D2 | Symbol of present weight: +/- Positive: 0. Negative: 1. |
| | | | D3 | Overflow |
| | | | D4 | Positive overflow |
| | | | D5 | Negative overflow |
| | | | D6 | Load cell positive overflow |
| | | | D7 | Load cell negative overflow |
| | | | D8 | Stable millivolt: 1. Unstable: 0. |
| | | | D9~ 31 | Reserve |
| 0008-0009 | 40009-40010 | Scale A & Scale B control state | D0 | 0: Stop. 1: Run. |
| | | | D1 | Alarm |
| | | | D2 | Batch completed |
| | | | D3 | Bag locked |
| | | | D4 | Upper level |
| | | | D5 | Under Level |
| | | | D6 | Filling material |
| | | | D7 | Lack material |
| | | | D8 | Patting bag |
| | | | D9 | Conveyor output (no hopper) |
| | | | D10 | Coding output |
| | | | D11 | Sewing machine output |
| | | | D12 | cutting machine output |
| | | | D13 | Auxiliary pulse 1 |
| | | | D14 | Auxiliary pulse 2 |
| | | | D15 | Auxiliary pulse 3 |
| | | | D16 | Auxiliary pulse 4 |
| | | | D17 | Relay output 1 |
| | | | D18 | Relay output 2 |
| | | | D19 | Relay output 3 |
| | | | D20 | Relay output 4 |
| | | | D21 | Relay output 5 |
| | | | D22 | Relay output 6 |
| | | | D23 | In the suspension |
| | | | D24 | Metering Hanger Up A |
| | | | D25 | Metering Hanger Up B |
| | | | D26 | Last Feed |
| D27 | Blocking | | | |
| D28 | Lifting Hook | | | |
| D29 | DISC Completed | | | |
| | | | D30- 31 | Reserve |
| 0010-0011 | 40011-40012 | Scale A control state | D0 | Before scale A filling |
| | | | D1 | Scale A Coarse Flow |
| | | | D2 | Scale A Medium Flow |
| | | | D3 | Scale A Fine Flow |
| | | | D4 | Scale A value |
| | | | D5 | Scale A discharge |
| | | | D6 | Scale A zero zone |
| | | | D7 | Scale A overlimit |

| | | | | |
|-----------|-------------|---|---|--------------------------------|
| | | | D8 | Scale A underlimit |
| | | | D9 | Scale A qualified |
| | | | D10 | Scale A over/under pause |
| | | | D11 | Scale A bag locked (no hopper) |
| | | | D12 | Scale A patting bag |
| | | | D13 | Scale A coding output |
| | | | D14 | 0:Gross weight, 1:Net weight |
| | | | D15 | A: DISC Shaking |
| | | | D16 | A:Weight OK |
| | | | D17 | A:DISC Completed |
| | | | D18~ 31 | Reserve |
| 0012-0013 | 40013-40014 | Scale B control state | Referring to Scale A control state | |
| 0014-0015 | 40015-40016 | Total accumulated weight (0~999999999) | | |
| 0016-0017 | 40017-40018 | Total accumulated bags (0~999999999) | | |
| 0018-0019 | 40019-40020 | The current recipe cumulative weight (0~999999999) | | |
| 0020-0021 | 40021-40022 | The current recipe cumulative bags (0~999999999) | | |
| 0022-0023 | 40023-40024 | User accumulated weight (0~999999999) | | |
| 0024-0025 | 40025-40026 | User cumulative bags (0~999999999) | | |
| 0026-0027 | 40027-40028 | Scale A previous weight value | | |
| 0028-0029 | 40029-40030 | Scale B previous weight value | | |
| 0030 | 40031 | Scale A alarm information | <ul style="list-style-type: none"> 0. No alarm 1. Unable to start for unreasonable recipe setting. 2. Unable to start as the maximum capacity of the hopper is 0. 3. Weight value exceeds zero range when zeroing; 4. Weighing value is unstable when zeroing. 5. Over/Under alarm. 6. The target value of single scale can not be set as 0 or the full capacity is too large. 7. The target value is bigger than maximum capacity value. 8. Weight value or load cell is over-limit when start. 9. Discharge gate is separated from limit digit. 10. Not bag locked. 11. Zeroing in the process of running. 12. Zeroing over range in the process of running. 13. Zeroing is not unstable in the process of running. 14. The motor parameters is unreasonable (normal motor) 15. Reserve | |
| 0031 | 40032 | Scale B alarm information | | |
| 0032-0033 | 40033-40034 | Normal alarm information (Need to be manually cleared) (changes to the high and low bytes do not affect the status bit) | <ul style="list-style-type: none"> 0- No alarm; 1- Batch completed; 2- Scale A Over/Under pause 3- Scale B Over/Under pause 4- Motor filling gate of scale A closed over time alarm 5- Motor filling gate of scale B closed over time alarm 6- Scale A bag locked over time alarm | |

| | | | |
|------|-------|---|---|
| | | | <ul style="list-style-type: none"> 7- Scale B bag locked over time alarm 8- Scale A bag unlocked over time alarm 9- Scale B bag unlocked over time alarm 10- Scale A discharge gate closed over time alarm 11- Scale B discharge gate closed over time alarm 12- Scale A discharge gate opened over time alarm 13- Scale B discharge gate opened over time alarm 14- Scale A fill gate not closed in place alarm. 15- Scale B fill gate not closed in place alarm. 16- Scale A discharge gate not closed in place alarm. 17- Scale B discharge gate not closed in place alarm. 18- The communication is abnormal of main board and addition board. 19- Scale A coarse filling overtime alarm 20- Scale B coarse filling overtime alarm 21- Scale A medium filling overtime alarm 22- Scale B medium filling overtime alarm 23- Scale A fine filling overtime alarm 24- Scale B fine filling overtime alarm 25- Scale A discharge overtime alarm. 26- Scale B discharge overtime alarm 27- Scale A discharge patting over-time alarm 28- Scale B discharge patting over-time alarm |
| 0034 | 40035 | Scale A & Scale B calibration alarm(changes to the high and low bytes do not affect the status bit) | <ul style="list-style-type: none"> 0- No alarm 1- Maximum range is too small 2- Maximum range is too large 3- Zero voltage is too high 4- Zero voltage is too low 5- Unstable zero point 6- Gain voltage is too large 7- Gain voltage is too small 8- Scale platform is unstable 9- Weight value input is error 10-Resolution is low after calibration. 11-Manual Coarse Flow then Manual Discharge(material calibrate alarm) 12:Reserve |
| 0035 | 40036 | A Previous scale Coarse Flow Timer Unit: s | |

| | | | |
|--------------------------------|-------------|--|--|
| 0036 | 40037 | A Previous scale Medium Flow Unit: s | |
| 0037 | 40038 | A Previous scale Fine Flow Unit: s | |
| 0038 | 40039 | A Previous scale WAIT Timer Unit: s | |
| 0039 | 40040 | A Previous scale Discharge Timer Unit: s | |
| 0040 | 40041 | A Previous scale Total Timer Unit: s | |
| 0041 | 40042 | B Previous scale Coarse Flow Timer Unit: s | |
| 0042 | 40043 | B Previous scale Medium Flow Unit: s | |
| 0043 | 40044 | B Previous scale Fine Flow Unit: s | |
| 0044 | 40045 | B Previous scale WAIT Timer Unit:s | |
| 0045 | 40046 | B Previous scale Discharge Timer Unit: s | |
| 0046 | 40047 | B Previous scale Total Timer Unit: s | |
| 0047 | 40047 | Scale A packing finish signal | Initial value: 0, 0~9999(this data will not be saved) |
| 0048 | 40048 | Scale B packing finish signal | Initial value: 0, 0~9999(this data will not be saved) |
| 0049 | 40050 | Reserve | |
| Allow to read & write register | | | |
| Calibration parameter | | | |
| 0050 | 40051 | Unit | Initial value: 1;0-g, 1-kg, 2-t, 3-lb |
| 0051 | 40052 | Decimal point | Initial value: 2 0-0 , 1-0.0, 2-0.00, 3-0.000, 4-0.0000. |
| 0052 | 40053 | Division | Initial value: 1, (1/2/5/10/20/50) |
| 0053-0054 | 40054-40055 | Maximum range | Initial value: 10000. The write range (maximum range value ≤ minimum division*100000, not more than 999999.) |
| 0055-0056 | 40056-40057 | Scale A calibration with weights | Zero calibration with weights If write in 1, the present weight will be set as zero point, which is allow to write in when weigher platform is stable. Return to present zero voltage when read. |
| 0057-0058 | 40058-40059 | | Gain calibration with weights Input standard weight value(≤ maximum range); Read relative zero millivolt of present load cell. |
| 0059-0060 | 40060-40061 | Scale A calibration without weights | Zero calibration without weights Write millivolt value which is calibrated as zero. Return to present zero millivolt when reads. |
| 0061-0062 | 40062-40063 | | Gain calibration with weights (gain millivolt value) Write in millivolts of gain weight and save it. Returns to absolute millivolt of present weight when reads. (If present millivolt is too small or too large can not be calibrated then returns 0XFFFF.). |
| 0063-0064 | 40064-40065 | | Gain calibration without weights (gain weight value) Write in weight value of gain millivolt, user must write in gain millivolt before write in this value. Return to 0000H when reads. |
| 0065-0066 | 40066-40067 | Scale B calibration with weights | Referring to Scale A zero calibration with weights. |
| 0067-0068 | 40068-40069 | | Referring to Scale A gain calibration with weights |
| 0069-0070 | 40070-40071 | Scale B calibration without weights | Referring to Scale A zero calibration without weights |
| 0071-0072 | 40072-40073 | | Referring to Scale A gain calibration without |

| | | | |
|---|-------------|------------------------------------|--|
| | | | weights (gain millivolt value) |
| 0073-0074 | 40074-40075 | | Referring to Scale A gain calibration without weights (gain weight value) |
| 0075-0076 | 40076-40077 | Manual Filling Timer | Initial Value: 0 Range:0.0~9.9 |
| 0077-0078 | 40078-40079 | A Material Calibration | Click the manual discharge in the material calibration, input the corresponding weight, and read it as 0 (note: it can only be used in the material calibration). |
| 0079-0080 | 40080-40081 | B Material Calibration | Click the manual discharge in the material calibration, input the corresponding weight, and read it as 0 (note: it can only be used in the material calibration). |
| 0081-0099 | 40082-40100 | Reserve | |
| Other parameters | | | |
| 0100 | 40101 | Recipe No. | Initial value: 1, range:1-40 |
| 0101 | 40102 | Batches | Initial value: 0, range: 0~9999 |
| 0102 | 40103 | Accumulative batches | Read-only |
| 0103 | 40104 | Controller locked | 0- unlocked; 1- locked |
| 0104 | 40105 | Year | 0-99 |
| 0105 | 40106 | Month | 1-12 |
| 0106 | 40107 | Day | 1-31 |
| 0107 | 40108 | Time | 0-23 |
| 0108 | 40109 | Minute | 0-59 |
| 0109 | 40110 | Second | 0-59 |
| 0110~0119 | Reserve | | |
| Recipe parameters-Filling Values | | | |
| 0120-0121 | 40121-40122 | Total target value | Weight value writing range: \leq Maximum range |
| 0122-0123 | 40123-40124 | Scale A target | With hopper: Weight value writing range: \leq The maximum capacity of single hopper No hopper: Weight value writing range: \leq The maximum full capacity |
| 0124-0125 | 40125-40126 | Scale B target | |
| 0126-0127 | 40127-40128 | Scale A Coarse Flow Remain | |
| 0128-0129 | 40129-40130 | Scale A Medium Flow Remain | |
| 0130-0131 | 40131-40132 | Scale A free fall | |
| 0132-0133 | 40133-40134 | Scale B Coarse Flow Remain | |
| 0134-0135 | 40135-40136 | Scale B Medium Flow Remain | |
| 0136-0137 | 40137-40138 | Scale B free fall | |
| 0138-0139 | 40139-40140 | Zero zone value | |
| Recipe parameters-Filling Timer | | | |
| 0140 | 40141 | Filling PreDelay Timer | Initial value: 0.5s; Range: 0.0~99.9s. |
| 0141 | 40142 | Scale A Coarse Flow inhibit timer | Initial value: 0.9s ; Range: 0.0~99.9s |
| 0142 | 40143 | Scale A Medium Flow inhibit timer | Initial value: 0.9s ; Range: 0.0~99.9s |
| 0143 | 40144 | Scale A fine filling inhibit timer | Initial value: 0.9s ; Range: 0.0~99.9s |
| 0144 | 40145 | Scale B Coarse Flow inhibit timer | Initial value: 0.9s ; Range: 0.0~99.9s |
| 0145 | 40146 | Scale B Medium Flow inhibit timer | Initial value: 0.9s ; Range: 0.0~99.9s |
| 0146 | 40147 | Scale B Fine Flow inhibit timer | Initial value: 0.9s ; Range: 0.0~99.9s |
| 0147 | 40148 | Over/Under Check Timer | Initial value: 0.5s; Range: 0.0~99.9s. |
| 0148 | 40149 | Result Waiting Timer | Initial value: 0.5s; Range: 0.0~99.9s. |
| 0149 | 40150 | Discharge delay timer | Initial value: 0.5s; Range: 0.0~ |

| | | | |
|--|-------------|--|---|
| | | | 99.9s. |
| 0150 | 40151 | Discharge interlock timer | Initial value: 0.5s; Range: 0.0~99.9s. |
| 0151 | 40152 | Bag locked delay timer | Initial value: 0.5s; Range: 0.0~99.9s. |
| 0152 | 40153 | Unlocked Bag PreDelay timer | Initial value: 0.5s; Range: 0.0~99.9s. |
| 0153 | 40154 | Discharge end delay | Initial value: 0.5s; Range: 0.0~99.9s. |
| Recipe parameters-Over/Under Parameters | | | |
| 0154 | 40155 | Over/Under ON/OFF | Initial value : 0, 1: ON 0: OFF |
| 0155 | 40156 | Over/Under pause ON/OFF | Initial value : 0, 1: ON 0: OFF |
| 0156-0157 | 40157-40158 | Over value | Weight value writing in range ≤ maximum range |
| 0158-0159 | 40159-40160 | Under value | |
| 0160 | 40161 | Under supplementary ON/OFF | Initial value: 0; 1: ON. 0: OFF |
| 0161 | 40162 | Under supplementary times | Range: 1 ~ 99. Initial value: 1 |
| 0162 | 40163 | Effective filling time | Initial value: 0.5s. ; Range: 0.0~99.9s |
| 0163 | 40164 | Ineffective filling time | Initial value: 0.5s. ; Range: 0.0~99.9s |
| Recipe parameters - free fall correction controlling parameters | | | |
| 0164 | 40165 | Free fall correction ON/OFF | Initial value: 0, 1: ON. 0: OFF |
| 0165 | 40166 | Free fall correction times | Range: 1 ~ 99. Initial value: 1. |
| 0166 | 40167 | Free fall correction range | Range: 2.0, range: 0.0~9.9, unit:% |
| 0167 | 40168 | Free fall correction percentage | Initial value: 1. 0--100% correction; 1--50% correction; 2-25% correction. |
| 0168 | 40169 | Adaptive parameters real-time refresh ON/OFF | Initial Value: 0 0: dis-refresh 1: refresh in realtime |
| 0169 | 40170 | Hanger up delay timer | Initial Value:5.5, range:0-99.9 |
| 0170 | 40171 | Hanger down delay timer | Initial Value:5.5, range:0-99.9 |
| 0171 | 40172 | Fast Mode ON/OFF | Initial Value :0,1:ON;0:OFF |
| 0172 | 40173 | Fast Mode Timer | Initial Value:0, range:0-1000ms |
| 0173-0174 | 40174-40175 | Fast Mode Weight A | Initial Value:0, range:0.0- Full capacity |
| 0175 | 40176 | Fast Mode Correction | Initial Value:5, range:0-10 |
| 0176 | 40177 | Stabilization | Initial Value:100,range:0.0-1000 |
| 0177-0178 | 40178-40179 | Fast Mode Weight B | Initial Value:0,range:0.0-Full capacity |
| 0179 | 40180 | Discharge End Delay | Initial Value:0,range:0.0-99.9 |
| 0180 | 40181 | Binyes Multi-Scale ON/OFF | Initial Value:0,1:ON;0:OFF |
| 0181 | 40182 | Blowing Mode | Initial Value:0, range : 0-1 0: Air Blow Before Up Delay 1: Air Blow After Up Delay |
| 0182 | 40183 | Return Valve | Initial Value:0, range:0-1 0: Close Return Valve After Fill, 1: Close Return Valve After Unlock Bag |
| 0183 | 40184 | Air Blow Timer | Initial Value:0.5,range:0.0-99.9 |
| 0184 | 40185 | Lifting Hook Reset Delay | Initial Value:0.0,range:0.0-99.9 |
| 0185 | 40186 | Hook Up For Release | Initial Value:0,1:ON;0:OFF |
| 0186 | 40187 | Pre-delay of Hook Up | Initial Value:0.0,range:0.0-99.9 |
| 0187 | 40188 | Hook Up Time | Initial Value:0.0,range:0.0-99.9 |
| 0188 | 40189 | Hook Up Pause Time | Initial Value:0.0, range:0.0-99.9 |
| Weighing parameter 1 | | | |
| 0200 | 40201 | Power up auto-zero ON/OFF | Initial value: 0, 1: ON, 0: OFF |
| 0201 | 40202 | Zero range | Initial value: 50, range: 1-99 |
| 0202 | 40203 | STAB range | Initial value: 2, stable range: 0 ~ |

| | | | |
|---|-------------|---|---|
| | | | 99d optional |
| 0203 | 40204 | STAB time | Initial value: 0.3s; range: 0.1~9.9 (s) |
| 0204 | 40205 | TrZero range | Initial value: 0, range: 0-9 (d) |
| 0205 | 40206 | TrZero time | Initial value: 2.0; range: 0.1~99.9s |
| 0206 | 40207 | Digital filtering Strength | Initial value: 7, range: 0-9 |
| 0207 | 40208 | Bynamic Filter ON/OFF | Initial value: 1, 1: ON, 0: OFF. |
| 0208 | 40209 | AD sample rate | Initial value: 1。 0:120; 1:240; 2:480; 3:960 |
| 0209~0214 | 40210~40215 | Reserve | |
| Weighing parameter 2 | | | |
| 0215 | 40216 | PreFill Zero Interval | Initial value: 0, range: 0-99. To enter zeroing after several packagings completed. |
| 0216 | 40217 | Result Check Mode | Initial value: 0 (range: 0, 1.) 0: stable and value. 1: value delay. |
| 0217 | 40218 | Weight value holding with hopper ON/OFF | Initial value: 0; range: 0-1 (0: OFF; 1: ON) |
| 0218 | 40219 | Manual discharge accumulated ON/OFF | Initial value: 0; range: 0-1 (0: OFF; 1: ON) |
| 0219 | 40220 | Manual discharge bag locked adjustment ON/OFF | Initial value: 0; range: 0-1 (0: OFF; 1: ON) |
| 0220 | 40221 | Discharge real-time detection ON/OFF | Initial value: 0; range: 0-1 (0: OFF; 1: ON) |
| 0221 | 40222 | Gross/Net weight packaging mode (no hopper) | Initial value: 1 (NW) 0: Gross weight packaging mode-no hopper(filling after bag locked) 1: Net weight packaging mode-no hopper(stable and tare after bag locked, then enter filling) |
| 0222 | 40223 | Dynamic filter ON/OFF | Initial value: 1; range: 0-1 (0: OFF; 1: ON) Parameters are valid when set ON. |
| 0223 | 40224 | Filling filter parameters | Initial value: 4, range: 1~9 |
| 0224 | 40225 | Value filter parameters | Initial value: 7, range: 1~9 |
| 0225 | 40226 | Discharge filter parameters | Initial value: 3, range: 1~9 |
| 0226 | 40227 | Adaptive Level | Initial value: 3, range: 1~5 |
| 0227 | 40228 | Adaptive ON/OFF | Initial value : 0; range: 0~2 Optional 0: OFF; 1: 2-Speed Fill ; 2: 3-Speed Fill |
| 0228~0229 | 40229~40230 | Reserve | |
| Maintenance parameters - structure | | | |
| 0230 | 40231 | Scale structure | Initial value: 0 0: with hopper, 1: no hopper |
| 0231 | 40232 | Working mode | Initial value: 0 0: Dual AB with hopper 1: scale A with hopper, 2: scale B with hopper, 3: Dual hopper dula clip bag AB seprate 4: Dual hopper dula clip bag AB comb 5: AB seprate no hopper 6: AB comb no hopper 7: Bulk single hopper A 8: Bulk single hopper B, 9: Bulk scale AB independent |

| | | | |
|--|----------------|--|---|
| | | | 10: Bulk scale AB Interlock; with hopper write 0-4, no hopper write 5-6, bulk scale write 7-10 |
| 0232 | 40233 | Scale A & Scale B target value setting separately | Initial value: OFF. OFF: same target value ON: different target value |
| 0233 | 40234 | Filling mode | Initial value: 1 0: Single Ctrl ; 1:Combo Ctrl |
| 0234 | 40235 | Dual scale bag unlocked mode (no hopper) | Initial value :: 0 0: closed; 1: bag unlocked simultaneously normal mode 2. bag unlocked simultaneously fast mode |
| 0235-0236 | 40236-40237 | Hopper Capacity | The written range of weight val- ues: ≤ maximum range |
| 0237~0240 | 40238~40241 | Reserve | |
| 0241 | 40242 | Manual Unlock Bag | Initial value :0; range: 0: OFF; 1:ON |
| 0242 | 40243 | Disable Unlock Bag When Running | Initial value :0; range:0: OFF; 1:ON |
| 0243 | 40244 | Master DISC Lock Switch | Initial value :0; range:0:OFF ; 1:ON |
| 0244 | 40245 | Run Zero Nums | Initial value :0 ;range:0~9. |
| 0245 | 40246 | Delay Before Zero | Initial value :0s,range:0.0~9.9s. |
| 0246~0249 | Reserve | | |
| Peripheral parameters-patting bag parameters(1) | | | |
| 0250 | 40251 | Patting bag mode | Initial value: 0. With hopper: 0/2. No hopper: 0/1/2/3. When multiple scales in bucket mode are turned on, select 0/1/2. 0: Closed. 1: Patting bag When filling. 2: Patting bag When Hold 3: All time |
| 0251 | 40252 | Patting times (filling) | Initial value: 0, range: 00-99 |
| 0252 | 40253 | Patting times (Hold) | Initial value: 4, range: 00-99 |
| 0253 | 40254 | Patting PreDelay Timer | Initial value: 0.5s. Range: 0.0 - 99.9s |
| 0254 | 40255 | Patting ON Timer | Initial value: 0.5s. Range: 0.0 to 99.9s. Pat bag output effective time in the meantime. |
| 0255 | 40256 | Patting OFF Timer | Initial value: 0.5s. Range: 0.0 to 99.9s. Pat bag output ineffective time in the meantime. |
| 0256 | 40257 | Extra Patting timer | Initial: 0.0, range: 0.0 to 99.9s |
| 0257-0258 | 40258-40259 | Starte-Up weight | Weight value written range: ≤ maximum capacity |
| Peripheral parameters - coding parameter (2) | | | |
| 0259 | 40260 | Code ON/OFF | Initial value: 0; range: 0-1 (0: OFF; 1: ON) |
| 0260 | 40261 | Coding start delay timer | Initial value: 0.5s, range: 0.0 to 99.9s |
| 0261 | 40262 | Coding timer | Initial value: 0.5s, range: 0.0 to 99.9 s |
| 0262 | 40263 | Disable Fill/Discharge When Coding | Initial value: 0 0 : Allow to enter discharging |

| | | | |
|--|-------------|--|---|
| | | | output or filling output in coding. 1: Not allow to enter discharging output or filling output in coding. |
| Peripheral parameters — Hopper dual clampers, None-Hopper mode conveyer parameter (3) | | | |
| 0263 | 40264 | Conveyor ON/OFF | Initial value :0; range: 0:OFF; 1:ON |
| 0264 | 40265 | Conveyor 1 start delay timer | Initial value:0.5s,range :0-99.9 |
| 0265 | 40266 | Conveyor 1 running timer | Initial value:4.0s,range :0-99.9 |
| 0266 | 40267 | Scale B Traffic avoid delay (None hopper) | Initial value:2.0s,range: 0-9.9 |
| Communication parameters-print parameters (4) | | | |
| 0267 | 40268 | Auto print ON/OFF | Initial value: 0. 1: ON, 0: OFF |
| 0268 | 40269 | Print format | Initial value: 0;Range: 0: 24 lines 1: 32 lines |
| 0269 | 40270 | Print language | Initial value: 0.1: English: 0: Chinese |
| 0270 | 40271 | Print Empty Line Nos | Initial value: 3, 0-9 |
| Peripherals Parameter—sewing parameter (5) | | | |
| 0271 | 40272 | sewing start delay timer | 0.0~99.9s; default: 0.5 |
| 0272 | 40273 | sewing on timer | 0.0~99.9s; default: 0.5 |
| 0273 | 40274 | cutter on timer | 0.0~99.9s; default: 0.5 |
| 0274 | 40275 | Sewing stop delay timer | 0.0~99.9s; default: 0.5 |
| Peripherals Parameter—discharge shaking parameter (6) | | | |
| 0275 | 40276 | discharge shaking ON/OFF | 0:OFF; 1:individual shak- ing;2:DISC shaking ;default: 0 |
| 0276 | 40277 | discharge on timer | 0.0~9.9, default 2.0s |
| 0277 | 40278 | discharge shaking on timer | 0.0~9.9, default 0.5s |
| 0278 | 40279 | discharge shaking off timer | 0.0~9.9, default 0.5s |
| 0279 | 40280 | discharge shaking times | 0~99, default 10 |
| Peripherals Parameter—Filling/Discharge Overtime ON/OFF (7) | | | |
| 0280 | 40281 | Filling/Discharge Monitor | 0~1; default 0 |
| 0281 | 40282 | A:Coarse Flow Overtime | 0.0~99.9s; default 5.0s |
| 0282 | 40283 | A:Medium Flow Overtime | 0.0~99.9s; default 5.0s |
| 0283 | 40284 | A:Manual Fine Overtime | 0.0~99.9s; default 5.0s |
| 0284 | 40285 | A:Discharge Overtime | 0.0~99.9s; default 5.0s |
| 0285 | 40286 | B:Coarse Flow Overtime | 0.0~99.9s default 5.0s |
| 0286 | 40287 | B:Medium Flow Overtime | 0.0~99.9s; default 5.0s |
| 0287 | 40288 | B:Manual Fine Overtime | 0.0~99.9s; default 5.0s |
| 0288 | 40289 | B:Discharge Overtime | 0.0~99.9s; default 5.0s |
| 0289 | 40290 | Cutter Start Delay Timer | 0.0~99.9s; default 0.5s |
| 0290 | 40291 | Sewing ON/OFF | Initial value:0, 1:ON, 0:OFF |
| 0291 | 40292 | Sewing delay timer | Initial value:0.3, 0~99.9s |
| 0292 | 40293 | Tractor ON.OFF | Initial value:0; 0:OFF, 1:ON |
| 0293 | 40294 | Fill timeout handle | Initial value:2; range:0~2; 0:Only Alarm,1:Alarm and Stop; 2:Alarm and finish fill |
| 0294-0295 | 40295-40296 | Fill timeout lower limit | Initial value:0; range:0 ~full capacity |
| 0296 | 40297 | DISC timeout handle | Initial value:2; range:0~2; 0:Only Alarm,1:Alarm and Stop; 2:Alarm and finish fil; |
| 0297 | 40298 | Conveyor 2&3 Max Run Time | Initial value:30.0; range:0-99.9s |
| 0298~0299 | 40299~40300 | Reserve | |
| Communication parameters - serial port1 parameters (1) | | | |
| 0300 | 40301 | Slave COM ID | Scale number. Initial value: 1; range:1-99. |
| 0301 | 40302 | Protocol | Initial value: Modbus-RTU 0: Modbus-RTU;1: Print; 2: Continuous |

| | | | |
|--|----------------|--------------------------|---|
| | | | Send 3: Re-ContA; 4: Re-ContB |
| 0302 | 40303 | Baud rate | Range: 0: 9600; 1: 19200; 2: 38400; 3: 57600; 4: 115200; Default: 2 (38400) |
| 0303 | 40304 | Data format | Range 0: 8-E-1; 1: 8-N-1; 2: 7-E-1; 3: 7-N-1) Default :0 (8-E-1) |
| 0304 | 40305 | Dword Fomat | MODBUS double word register storing order. Range: 0-1 (0: AB-CD; 1: CD-AB) Default: 0 (AB-CD) |
| Communication parameters – serial port 2 parameters (2) | | | |
| 0305 | 40306 | ID | Scale number. Initial value: 1; range: 1-99. |
| 0306 | 40307 | Protocol | Initial value: Modbus-RTU 0: Modbus-RTU; 1: Print; 2: Continuous Send; 3: Re-ContA; 4: Re-ContB |
| 0307 | 40308 | Baud rate | range: 0: 9600; 1: 19200; 2: 38400; 3: 57600; 4: 115200 default: 2 (38400) |
| 0308 | 40309 | Data format | Range: 0: 8-E-1; 1: 8-N-1; 2: 7-E-1; 3: 7-N-1) Default: 0 (8-E-1) |
| 0309 | 40310 | Dword Fomat | MODBUS double word register storing order. Range: 0-1 (0: AB-CD; 1: CD-AB) Default: 0 (AB-CD) |
| Cumulative print | | | |
| 0310 | 40311 | Print accumulated | Read 0.; Write 1, print accumulated. |
| 0311 | 40312 | Print recipe accumulated | Read 0. Write 0: print present recipe accumulated Write 1-40 print the corresponding accumulated recipes Write 41, print all accumulated recipes |
| 0312 | 40313 | Print user accumulated | Read 0. Write 100, print current user accumulated. Write 0-9, print corresponding user accumulated. Write 101, print all user accumulated. |
| 0313-0319 | Reserve | | |
| Reset | | | |
| 0320 | 40321 | Reset | 8800 All parameters restore factory settings 8801 Calibration recovery 8802 Recovery weighing parameters 8803 Recovery formula 8804 IO definition of recovery 8805 Perform backups 8806 Implementation of recovery Read returns 0 |
| I/O Module test Parameter | | | |
| 0321 | 40322 | Start/Stop I/O test | Write 1 Start I/O module test Write 0 ESC I/O module test state, stop state can write in Read: Return current I/O module test ON/OFF's state |
| 0322 | 40323 | Input I/O module test | Write: not allowed. Read: IN1~12 matches with Lo-Hi. 1: valid input, 0: invalid input. |
| 0323-0324 | 40324-40325 | Output I/O module test | Write: OUT1~16 matches with Lo-Hi, could be written when set ON. 1: valid output, 0: invalid output. Read: return to I/O module state, OUT1~16 matches with Lo-Hi. 1: valid output, 0: invalid output. |

| | | | |
|---|----------------|--------------------------------|--|
| 0325-0349 | Reserve | | |
| I/O Module user-defined Parameters | | | |
| 0350 | 40351 | Input port 1 is defined. | Write: Write function corresponding to the value. If defined IN as running, user has to write 1 in according register of IN. Read: Returns to I/O module state. (Refer to the definition of switch quantity in Section 4.8 for the meaning of function code) |
| 0351 | 40352 | Input port 2 is defined. | |
| 0352 | 40353 | Input port 3 is defined. | |
| 0353 | 40354 | Input port 4 is defined. | |
| 0354 | 40355 | Input port 5 is defined. | |
| 0355 | 40356 | Input port 6 is defined. | |
| 0356 | 40357 | Input port 7 is defined. | |
| 0357 | 40358 | Input port 8 is defined. | |
| 0358 | 40359 | Input port 9 is defined. | |
| 0359 | 40360 | Input port 10 is defined. | |
| 0360 | 40361 | Input port 11 is defined. | |
| 0361 | 40362 | Input port 12 is defined. | |
| 0362 | 40363 | Output port 1 is defined. | Write: Write function corresponding to the value. If defined OUT as running, user has to write 1 in according register of OUT. Read: Returns to I/O module state. (Refer to the definition of switch quantity in Section 4.8 for the meaning of function code) |
| 0363 | 40364 | Output port 2 is defined. | |
| 0364 | 40365 | Output port 3 is defined. | |
| 0365 | 40366 | Output port 4 is defined. | |
| 0366 | 40367 | Output port 5 is defined. | |
| 0367 | 40368 | Output port 6 is defined. | |
| 0368 | 40369 | Output port 7 is defined. | |
| 0369 | 40370 | Output port 8 is defined. | |
| 0370 | 40371 | Output port 9 is defined. | |
| 0371 | 40372 | Output port 10 is defined. | |
| 0372 | 40373 | Output port 11 is defined. | |
| 0373 | 40374 | Output port 12 is defined. | |
| 0374 | 40375 | Output port 13 is defined. | |
| 0375 | 40376 | Output port 14 is defined. | |
| 0376 | 40377 | Output port 15 is defined. | |
| 0377 | 40378 | Output port 16 is defined. | |
| 0378-0399 | Reserve | | |
| Target value of 40 recipes parameters (read and write) | | | |
| 0400-0401 | 40401-40402 | Target value of recipe 1 | Initial value: 0 |
| 0402-0403 | 40403-40404 | Target value of recipe 2 | Initial value: 0 |
| 0404-0405 | 40405-40406 | Target value of recipe 3 | Initial value: 0 |
| 0406-0407 | 40407-40408 | Target value of recipe 4 | Initial value: 0 |
| ... | | | |
| 0478-0479 | 40479-40480 | Target value of recipe 40 | Initial value: 0 |
| 0480-0499 | Reserve | | |
| Scale A target value parameters of 40 recipes (read and write) | | | |
| 0500-0501 | 40501-40502 | Target value of recipe 1A | Initial value: 0 (Read only) |
| 0502-0503 | 40503-40504 | Target value of recipe 2A | Initial value: 0 |
| 0504-0505 | 40505-40506 | Target value of recipe 3A | Initial value: 0 |
| 0506-0507 | 40507-40508 | Target value of recipe 4A | Initial value: 0 |
| ... | | | |
| 0578-0579 | 40579-40580 | Target value of recipe 40A | Initial value: 0 |
| 0580-0599 | Reserve | | |
| Scale B target value parameters of 40 recipes (read and write) | | | |
| 0600-0601 | 40601-40602 | Target value of recipe 1B | Initial value: 0 |
| 0602-0603 | 40603-40604 | Target value of recipe 2B | Initial value: 0 |
| 0604-0605 | 40605-40606 | Target value of recipe 3B | Initial value: 0 |
| 0606-0607 | 40607-40608 | Target value of recipe 4B | Initial value: 0 |
| ... | | | |
| 0678-0679 | 40679-40680 | Target value of recipe 40B | Initial value: 0 |
| 0680-0699 | Reserve | | |
| Accumulated weight parameters of 40 recipes. | | | |
| 0700-0701 | 40701-40702 | Accumulated weight of recipe 1 | |
| 0702-0703 | 40703-40704 | Accumulated weight of recipe 2 | |
| 0704-0705 | 40705-40706 | Accumulated weight of recipe 3 | |

| | | |
|--|----------------|---|
| 0706-0707 | 40707-40708 | Accumulated weight of recipe 4 |
| 0000 | | 0000000000000000 |
| 0778-0779 | 40779-40780 | Accumulated weight of recipe 40 |
| 0780-0799 | Reserve | |
| Accumulated bags parameters of 40 recipes. | | |
| 0800-0801 | 40801-40802 | Accumulated bags of recipe 1(Written 0 to clear accumulated weight and bags of the recipe.) |
| 0802-0803 | 40803-40804 | Accumulated bags of recipe 2(Written 0 to clear accumulated weight and bags of the recipe.) |
| 0804-0805 | 40805-40806 | Accumulated bags of recipe 3(Written 0 to clear accumulated weight and bags of the recipe.) |
| 0806-0807 | 40807-40808 | Accumulated bags of recipe 4(Written 0 to clear accumulated weight and bags of the recipe.) |
| 0000 | | 0000000000000000 |
| 0878-0879 | 40879-40880 | Accumulated bags of recipe 40(Written 0 to clear accumulated weight and bags of the recipe.) |
| 0880-0899 | Reserve | |
| 10 users cumulative weight | | |
| 0900-0901 | 40901-40902 | User 0 accumulated weight (Written 0 to clear accumulated weight and bags of the user.) |
| 0902-0903 | 40903-40904 | User 1 accumulated weight (Written 0 to clear accumulated weight and bags of the user.) |
| 0904-0905 | 40905-40906 | User 2 accumulated weight (Written 0 to clear accumulated weight and bags of the user.) |
| 0906-0907 | 40907-40908 | User 3 accumulated weight (Written 0 to clear accumulated weight and bags of the user.) |
| 0908-0909 | 40909-40910 | User 4 accumulated weight (Written 0 to clear accumulated weight and bags of the user.) |
| 0000 | | 0000000000 |
| 0918-0919 | 40919-40920 | User 9 accumulated weight (Written 0 to clear accumulated weight and bags of the user.) |
| 0920-0949 | Reserve | |
| 10 users cumulative number of times | | |
| 0950-0951 | 40951-40952 | User accumulated times 0 (Written 0 to clear accumulated weight and bags of the user.) |
| 0952-0953 | 40953-40954 | User accumulated times 1 (Written 0 to clear accumulated weight and bags of the user.) |
| 0954-0955 | 40955-40956 | User accumulated times 2 (Written 0 to clear accumulated weight and bags of the user.) |
| 0000 | | 0000000000 |
| 0968-0969 | 40969-40970 | User accumulated times 9 (Written 0 to clear accumulated weight and bags of the user.) |
| 0970-0999 | 40971-41000 | Reserve |
| Motor Parameters | | |
| 1000 | 41001 | Filling mode: 0: air driven(default); 1: Step Motor; 2:Motor |
| 1001 | 41002 | Motor group: 0 (default); range: 0-4 optional |
| 1002 | 41003 | Filling stepper motor frequency of scale A Range:1-50000; initial value: 12000Hz |
| 1003-1004 | 41004-41005 | A filling close to Motor Steps For Fi-Flow Range: 1-60000; initial value: 1800 |
| 1005-1006 | 41006-41007 | A filling close to Motor Steps For Me -Flow Range: 1-60000; initial value: 4300 |
| 1007-1008 | 41008-41009 | A filling close to Motor Steps For Co -Flow Range: 1-60000; initial value: 7750 |
| 1009 | 41010 | The motor rotation direction signal of scale A fill gate Range:0:OFF:Gate Open Direction;1: ON:Gate Open Direction,; initial value:0 |
| 1010 | 41011 | Filling stepper motor frequency of scale B Range:1-50000 ; initial value : 12000Hz |
| 1011-1012 | 41012-41013 | B filling close to Motor Steps For Fi-Flow Range: 1-60000; initial value: 1800 |

| | | | |
|-----------|-------------|--|--|
| 1013-1014 | 41014-41015 | B filling close to Motor Steps For Me -Flow | Range: 1-60000; initial value: 4300 |
| 1015-1016 | 41016-41017 | B filling close to Motor Steps For Co -Flow | Range: 1-60000; initial value: 7750 |
| 1017 | 41018 | The motor rotation direction signal of scale B fill gate | Range:0:OFF:Gate Open Direction;1: ON:Gate Open Direction;; initial value:0 |
| 1018 | 41019 | Scale A filling motor start frequency | Range:1-50000; initial value: 2000Hz |
| 1019 | 41020 | Scale A filling motor acceleration time | Range:0~9999(ms); initial value:200ms |
| 1020 | 41021 | Scale A filling motor deceleration time | Range:0~9999(ms); initial value: 50ms |
| 1021 | 41022 | Scale B filling motor start frequency | Range:1-50000Hz; initial value: 2000Hz |
| 1022 | 41023 | Scale B filling motor acceleration time | Range:0~9999(ms); initial value:200ms |
| 1023 | 41024 | Scale B filling motor deceleration time | Range:0~9999(ms); initial value:50ms |
| 1024 | 41025 | The running time of scale A filling gate opens to Coarse Flow. (Normal motors) | Range:0~99.9(s); initial value: 0.8s |
| 1025 | 41026 | The running time of scale A filling gate opens to Medium Flow. | Range:0~99.9(s); initial value: 0.4s |
| 1026 | 41027 | The running time of scale A filling gate opens to Fine Flow. | Range:0~99.9(s); initial value: 0.2s |
| 1027 | 41028 | The running time of scale B filling gate opens to Coarse Flow. | Range:0~9999(ms); initial value: 50ms |
| 1028 | 41029 | The running time of scale B filling gate opens to Medium Flow. | Range:0~99.9(s); initial value: 0.8s |
| 1029 | 41030 | The running time of scale B filling gate opens to Fine Flow. | Range:0~99.9(s); initial value: 0.4s |
| 1030 | 41031 | Filling gate closed timeout | Range:0~99.9(s); initial value: 0.2s |
| 1031 | 41032 | Motor filling gate opened anti | logically |
| 1032 | 41033 | Bag locked mode | 0: Air Driven;1: Step Motor;2: Normal Motor(Two Pos. Signal); 3: Normal Motor(One Pos. Signal); |
| 1033 | 41034 | Bag locked frequency of scale A (Stepper motor) | Range:1-50000Hz; initial value:30000Hz |
| 1034 | 41035 | Bag unlocked frequency of scale A | Range:1-50000Hz; initial value: 20000Hz |
| 1035-1036 | 41036-41037 | Pulses quantity required that state of bag unlocked state turns to bag locked state of scale A motor | Range:1~60000; initial value: 12000 |
| 1037 | 41038 | The motor rotation direction signal of scale A bag locked | initial value: 0; Optional: 0: OFF:If Clamper Open Direction: 1: ON:If Clamper Open Direction: 8 |
| 1038 | 41039 | Motor frequency of scale B bag locked | Range:1-50000Hz; initial value: 30000Hz |
| 1039 | 41040 | Motor frequency scale B bag unlocked | Range:1-50000Hz; initial value: 20000Hz |
| 1040-1041 | 41041-41042 | Pulses quantity required that state of bag unlocked turns to bag locked of scale B | Range:1~60000; initial value: 12000 |

| | | motor | |
|-----------|-------------|--|--|
| 1042 | 41043 | The motor rotation direction signal of scale B bag locked | Initial value: 0 ; Optional: 0 : OFF:If Clamper Open Direction: 1 : ON:If Clamper Open Direction: |
| 1043 | 41044 | Scale A bag locked motor start frequency | Range: 1-50000 Hz; initial value: 2000 Hz |
| 1044 | 41045 | Scale A bag locked motor acceleration time | Range: 0~9999 (ms); initial value: 200 ms |
| 1045 | 41046 | Scale A bag locked motor deceleration time | Range: 0~9999 (ms); initial value: 50 ms |
| 1046 | 41047 | Scale B bag locked motor start frequency | Range: 1-50000 Hz; initial value: 2000 Hz |
| 1047 | 41048 | Scale B bag locked motor acceleration time | Range: 0~9999 (ms); initial value: 200 ms |
| 1048 | 41049 | Scale B bag locked motor deceleration time | Range: 0~9999 (ms); initial value: 50 ms |
| 1049 | 41050 | Bag unlocked time (Normal motor) | Range: 0~99.9 (s); initial value: 0.5 s |
| 1050 | 41051 | Bag unlocked timeout | Range: 0~99.9 (s); initial value: 3.0 s |
| 1051 | 41052 | Bag locked timeout | Range: 0~99.9 (s); initial value: 3.0 s |
| 1052 | 41053 | Clamper position signal type | Initial value: 0 ; Optional: 0 : ON:If Closed; 1 :OFF:If Closed; |
| 1053 | 41054 | Discharge mode | 0 : Air Dived; 1 : Step Motor; 2 : Normal Motor(One Pos. Signal); 3 : Normal Motor(Two Pos. Signal); 4 :Normal Motor Rotating |
| 1054 | 41055 | Scale A discharge gate opened motor frequency | Range: 1-50000 Hz; initial value: 30000 Hz |
| 1055 | 41056 | Scale A discharge gate closed motor frequency | Range: 1-50000 Hz; initial value: 20000 Hz |
| 1056-1057 | 41057-41058 | Pulses quantity required that state of closed turns to opened of scale A motor | Range: 1~60000 ; initial value: 12000 |
| 1058 | 41059 | The signal of motor rotation direction of scale A discharge gate opened | initial value: 0 ; Optional: 0 : ON:If Closed; 1 :OFF:If Closed; |
| 1059 | 41060 | The motor frequency of scale B discharge gate opened | Range: 1-50000 Hz; initial value: 30000 Hz |
| 1060 | 41061 | The motor frequency of scale B discharge gate closed | Range: 1-50000 Hz; initial value: 20000 Hz |
| 1061-1062 | 41062-41063 | Pulses quantity required that state of closed turns to opened of scale B motor | Range: 1~60000 ; initial value: 12000 |
| 1063 | 41064 | The signal of motor rotation direction of scale B discharge gate opened | Initial value: 0 ; Optional: 0 : ON:If Closed; 1 :OFF:If Closed; |
| 1064 | 41065 | Scale A discharge motor started frequency | Range: 1-50000 Hz; initial value: 2000 Hz |
| 1065 | 41066 | Scale A discharge motor acceleration time | Range: 0~9999 (ms); initial value: 200 ms |
| 1066 | 41067 | Scale A discharge motor deceleration time | Range: 0~9999 (ms); initial value: 50 ms |
| 1067 | 41068 | Scale B discharge motor started frequency | Range: 1-50000 Hz; initial value: 2000 Hz |
| 1068 | 41069 | Scale B discharge motor acceleration time | Range: 0~9999 (ms); initial value: 200 ms |

| | | | |
|--|-------------|--|---|
| 1069 | 41070 | Scale B discharge motor deceleration time | Range: 0~9999(ms) ; initial value: 50ms |
| 1070 | 41071 | Scale A discharge motor gate opened signal output time (Normal motors) | Range: 0.0~99.9(s) ; initial value: 1.0s |
| 1071 | 41072 | Scale B discharge motor gate opened signal output time | Range: 0.0~99.9(s) ; initial value: 1.0s |
| 1072 | 41073 | Discharge gate closed timeout | Range: 0.0~99.9(s) ; initial value: 3.0s |
| 1073 | 41074 | Discharge gate opened timeout | Range: 0.0~99.9(s) ; initial value: 3.0s |
| 1074 | 41075 | Motor discharge ON/OFF anti logically | |
| 1075 | 41076 | Discharge limit digit real-time detection ON/OFF | Range: OFF, ON , initial value: OFF |
| 1076 | 41077 | Motor group no. of present recipe | Initial value: 0 ;Range: 0~4 |
| Peripherals Parameter—Auxiliary Pulse Parameter (8) | | | |
| 1079 | 41080 | Auxiliary Pulse ON/OFF | Initial value: 0, 1: ON 0: OFF |
| 1080 | 41081 | Auxiliary Pulse 1 Execute Total Timer | 0.0~999.9s default 0(If it's 0, it keeps operating) |
| 1081 | 41082 | Auxiliary Pulse 1 On Timer | 0.0~999.9s default 10.0s |
| 1082 | 41083 | Auxiliary Pulse 1 Off Timer | 0.0~999.9s default 10.0s |
| 1083 | 41084 | Auxiliary Pulse 2 Execute Total Timer | 0.0~999.9 s default 0(If it's 0, it keeps operating) |
| 1084 | 41085 | Auxiliary Pulse 2 On Timer | 0.0~999.9s default 10.0s |
| 1085 | 41086 | Auxiliary Pulse 2 Off Timer | 0.0~999.9s default 10.0s |
| 1086 | 41087 | Auxiliary Pulse 3 Execute Total Timer | 0.0~999.9 min default 0(If it's 0, it keeps operating) |
| 1087 | 41088 | Auxiliary Pulse 3 On Timer | 0.0~999.9 min default 10.0 min |
| 1088 | 41089 | Auxiliary Pulse 3 Off Timer | 0.0~999.9 min default 10.0 min |
| 1089 | 41090 | Auxiliary Pulse 4 Execute Total Timer | 0.0~999.9 min default 0(If it's 0, it keeps operating) |
| 1090 | 41091 | Auxiliary Pulse 4 On Timer | 0.0~999.9 min default 10.0 min |
| 1091 | 41092 | Auxiliary Pulse 4 Off Timer | 0.0~999.9 min default 10.0 min |
| Ethernet port parameter | | | |
| 1100 | 41101 | Dword Format | Initial value 0. range: 0: AB-CD (Hi ahead); 1: CD-AB (Lo ahead) |
| 1101 | 41102 | Socket | Initial value : 502. range 1~65535 |
| 1102~1105 | 41103~41106 | IP1~IP4 | Initial value:192.168.101.246,range 0.0.0.0~255.255.255.255 |
| 1106~1111 | 41107~41112 | MAC Address | MAC1~ MAC6, Only read |
| User Logic Program 1 | | | |
| 1150 | 41151 | User Logic Type | Initial Value:0; range 0~5 |
| | | | 0: OFF |
| | | | 1: Delay Connect |
| | | | 2: Delay disconnect |
| | | | 3: Delay connect and delay disconnect |

| | | | |
|-----------------------------|-------------|-------------------------|---|
| | | | 4: invalid-valid trigger |
| | | | 5: valid-invalid trigger |
| 1151 | 41152 | Trigger Type | Initial value: 0 ; range: 0~64 Optional customization trigger input, fix I/O Module input 1~12 , I/O Module output define, weight value trigger |
| 1152 | 41153 | Trigger Function Input | Initial value: 0 ; range: 0~12 Select the signal corresponding to the I/O Module input port 0~12, input port-0 stands for do not define this function. |
| 1153 | 41154 | Trigger Function Output | Initial value: 0 ; range: 0~16 Select the signal corresponding to the I/O Module input port 0~16, input port-0 stands for do not define this function. |
| 1154 | 41155 | Delay ON Time | Initial value: 0 ; range: 0~99.9s |
| 1155 | 41156 | Delay OFF Time | Initial value: 0 ; range: 0~99.9s |
| 1156 | 41157 | Output ON Timer | Initial value: 0 ; range: 0~99.9s |
| 1157-1158 | 41158~41159 | Logic Trigger Weight | Initial value: 0 ; range: 0~full capacity |
| 1159~1169 | 41160~41170 | Reserve | |
| User Logic Program 2 | | | |
| 1170 | 41171 | User Logic Type | Initial Value:0; range 0~5 |
| | | | 0: OFF |
| | | | 1: Delay Connect |
| | | | 2: Delay disconnect |
| | | | 3: Delay connect and delay disconnect |
| | | | 4: invalid-valid trigger |
| 1171 | 41172 | Trigger Type | Initial value: 0 ; range: 0~64 Optional customization trigger input, fix I/O Module input 1~12 , I/O Module output define, weight value trigger |
| | | | Initial value: 0 ; range: 0~12 Select the signal corresponding to the I/O Module input port 0~12, input port-0 stands for do not define this function. |
| | | | Initial value: 0 ; range: 0~16 Select the signal corresponding to the I/O Module input port 0~16, input port-0 stands for do not define this function. |
| | | | Initial value: 0 ; range: 0~99.9s |
| | | | Initial value: 0 ; range: 0~99.9s |
| | | | Initial value: 0 ; range: 0~99.9s |
| 1177-1178 | 41178~41179 | Logic Trigger Weight | Initial value: 0 ; range: 0~full capacity |
| | | | Initial value: 0 ; range: 0~99.9s |
| | | | Initial value: 0 ; range: 0~99.9s |
| | | | Initial value: 0 ; range: 0~99.9s |
| | | | Initial value: 0 ; range: 0~99.9s |
| | | | Initial value: 0 ; range: 0~99.9s |
| 1179~1189 | 41180~41190 | Reserve | |
| User Logic Program 3 | | | |
| 1190 | 41191 | User Logic Type | Initial Value:0; range 0~5 |
| | | | 0: OFF |
| | | | 1: Delay Connect |
| | | | 2: Delay disconnect |

| | | | |
|---------------------------------|--------------|-------------------------|---|
| | | | 3: Delay connect and delay disconnect |
| | | | 4: invalid-valid trigger |
| | | | 5: valid-invalid trigger |
| 1191 | 41192 | Trigger Type | Initial value: 0 ; range: 0~64 Optional customization trigger input, fix I/O Module input 1~12 , I/O Module output define, weight value trigger |
| 1192 | 41193 | Trigger Function Input | Initial value: 0 ; range: 0~12 Select the signal corresponding to the I/O Module input port 0~12, input port-0 stands for do not define this function. |
| 1193 | 41194 | Trigger Function Output | Initial value: 0 ; range: 0~16 Select the signal corresponding to the I/O Module input port 0~16, input port-0 stands for do not define this function. |
| 1194 | 41195 | Delay ON Time | Initial value: 0 ; range: 0~99.9s |
| 1195 | 41196 | Delay OFF Time | Initial value: 0 ; range: 0~99.9s |
| 1196 | 41197 | Output ON Timer | Initial value: 0 ; range: 0~99.9s |
| 1197~1198 | 41198~41199 | Logic Trigger Weight | Initial value: 0; range: 0~full capacity |
| 1199~1209 | 41200~41210 | Reserve | |
| User Logic Program 4 | | | |
| 1210 | 41211 | User Logic Type | Initial Value:0; range 0~5 |
| | | | 0: OFF |
| | | | 1: Delay Connect |
| | | | 2: Delay disconnect |
| | | | 3: Delay connect and delay disconnect |
| | | | 4: invalid-valid trigger |
| 5: valid-invalid trigger | | | |
| 1211 | 41212 | Trigger Type | Initial value: 0 ; range: 0~64 Optional customization trigger input, fix I/O Module input 1~12 , I/O Module output define, weight value trigger |
| 1212 | 41213 | Trigger Function Input | Initial value: 0 ; range: 0~12 Select the signal corresponding to the I/O Module input port 0~12, input port-0 stands for do not define this function. |
| 1213 | 41214 | Trigger Function Output | Initial value: 0 ; range: 0~16 Select the signal corresponding to the I/O Module input port 0~16, input port-0 stands for do not define this function. |
| 1214 | 41215 | Delay ON Time | Initial value: 0 ; range: 0~99.9s |
| 1215 | 41216 | Delay OFF Time | Initial value: 0 ; range: 0~99.9s |
| 1216 | 41217 | Output ON Timer | Initial value: 0 ; range: 0~99.9s |
| 1217~1218 | 41218~41219 | Logic Trigger Weight | Initial value: 0; range: 0~full capacity |
| 1219~1229 | 41220~41230 | Reserve | |
| User Logic Program 5 | | | |
| 1230 | 41231 | User Logic Type | Initial Value:0; range 0~5 |
| | | | 0: OFF |
| | | | 1: Delay Connect |

| | | | |
|-----------------------------|-------------|--|---|
| | | | 2: Delay disconnect 3: Delay connect and delay disconnect 4: invalid-valid trigger 5: valid-invalid trigger |
| 1231 | 41232 | Trigger Type | Initial value: 0 ; range: 0~64 Optional customization trigger input, fix I/O Module input 1~12 , I/O Module output define, weight value trigger |
| 1232 | 41233 | Trigger Function Input | Initial value: 0 ; range: 0~12 Select the signal corresponding to the I/O Module input port 0~12, input port-0 stands for do not define this function. |
| 1233 | 41234 | Trigger Function Output | Initial value: 0 ; range: 0~16 Select the signal corresponding to the I/O Module input port 0~16, input port-0 stands for do not define this function. |
| 1234 | 41235 | Delay ON Time | Initial value: 0 ; range: 0~99.9s |
| 1235 | 41236 | Delay OFF Time | Initial value: 0 ; range: 0~99.9s |
| 1236 | 41237 | Output ON Timer | Initial value: 0 ; range: 0~99.9s |
| 1237-1238 | 41238~41239 | Logic Trigger Weight | Initial value: 0; range: 0~full capacity |
| 1239~1249 | 41240~41250 | Reserve | |
| User Logic Program 6 | | | |
| 1250 | 41251 | User Logic Type | Initial Value:0; range 0~5 0: OFF 1: Delay Connect 2: Delay disconnect 3: Delay connect and delay disconnect 4: invalid-valid trigger 5: valid-invalid trigger |
| 1251 | 41252 | Trigger Type | Initial value: 0 ; range: 0~64 Optional customization trigger input, fix I/O Module input 1~12 , I/O Module output define, weight value trigger |
| 1252 | 41253 | Trigger Function Input | Initial value: 0 ; range: 0~12 Select the signal corresponding to the I/O Module input port 0~12, input port-0 stands for do not define this function. |
| 1253 | 41254 | Trigger Function Output | Initial value: 0 ; range: 0~16 Select the signal corresponding to the I/O Module input port 0~16, input port-0 stands for do not define this function. |
| 1254 | 41255 | Delay ON Time | Initial value:0; range: 0~99.9s |
| 1255 | 41256 | Delay OFF Time | Initial value:0; range: 0~99.9s |
| 1256 | 41257 | Output ON Timer | Initial value:0; range: 0~99.9s |
| 1257-1258 | 41258~41259 | Logic Trigger Weight | Initial value:0; range: 0~full capacity |
| 1259~1299 | 41260~41300 | Reserve | |
| 1300 | 41301 | A feeding motor returns to zero frequency (Initial value:2000; range: 1~50000) | |
| 1301 | 41302 | B feeding motor returns to zero frequency (Initial value:2000; | |

| | | | |
|---|--------------------|---|---|
| | | range:1~50000) | |
| 1302 | 41303 | A Clamper motor returns to zero frequency (Initial value:2000; range:1~50000) | |
| 1303 | 41304 | B Clamper motor returns to zero frequency (Initial value:2000; range:1~50000) | |
| 1304 | 41305 | A DICS motor returns to zero frequency (Initial value:2000; range:1~50000) | |
| 1305 | 41306 | B DICS motor returns to zero frequency (Initial value:2000; range:1~50000) | |
| 1306 | 41307 | No position signal for fill gate | Range: OFF, ON , Initial value: OFF |
| 1307 | 41308 | No position signal for clamper | Range: OFF, ON , Initial value: OFF |
| 1308 | 41309 | No position signal for DISC gate | Range: OFF, ON , Initial value: OFF |
| 1309-1310 | 1310-1311 | Scale A filler:Motor steps for closed | Range:1~60000; Initial value: 100; |
| 1311-1312 | 1312-1313 | Scale B filler:Motor steps for closed | Range:1~60000; Initial value: 100; |
| 1313-1314 | 1314-1315 | Scale A clamper: Steps for clamper open | Range:1~60000; Initial value: 100; |
| 1315-1316 | 1316-1317 | Scale B filler: Steps for clamper open | Range:1~60000; Initial value: 100; |
| 1317-1318 | 1318-1319 | Scale A DISC: Discharge Steps for closed | Range:1~60000; Initial value: 100; |
| 1319-1320 | 1320-1321 | Scale B DISC: Discharge Steps for closed | Range:1~60000; Initial value: 100; |
| 1321~1999 | 41322~42000 | Reserve | |
| Statistic Parameters | | | |
| 2000-2001 | 42001-42002 | Total cumulative weight is 6 digits | |
| 2002-2003 | 42003-42004 | The total cumulative weight low 9 | |
| 2004-2005 | 42005-42006 | Total accumulative times | |
| 2006-2007 | 42007-42008 | the current formula accumulation is 6 digits higher | |
| 2008-2009 | 42009-42010 | the current formula accumulation is 9 digits lower | |
| 2010-2011 | 42011-42012 | Accumulative number of current formulation | |
| 2012-2013 | 42013-42014 | the accumulations of current users is 6 digits higher | |
| 2014-2015 | 42015-42016 | the accumulations of current users is 9 digits lower | |
| 2016-2017 | 42017-42018 | Total number of current user counts | |
| 2018-2019 | 42019-42020 | Formula 1 cumulative weight is 6 digits high | |
| 2020-2021 | 42021-42022 | Formulation 1 cumulative weight low 9 | |
| 2022-2023 | 42023-42024 | Formula 1 cumulative count | |
| (Read the formula cumulative value sequentially) | | | |
| 2252-2253 | 42253-42254 | Formulation 6 High 40 cumulative weight | |
| 2254-2255 | 42255-42256 | Formulation 40 cumulative weight low 9 | |
| 2256-2257 | 42257-42258 | Formula 40 cumulative times | |
| 2258-2259 | 42259-42260 | User 1 cumulative weight is 6 digits high | |
| 2260-2261 | 42261-42262 | User 1 cumulative weight is 9 digits lower | |
| 2262-2263 | 42263-42264 | User 1 cumulative times | |
| (Read the accumulated user values in sequence) | | | |
| 2312-2313 | 42313-42314 | User 10 cumulative weight is 6 digits high | |
| 2314-2315 | 42315-42316 | User 10 cumulative weight is 9 digits lower | |
| 2316-2317 | 42317-42318 | User 10 cumulative times | |
| 2318 | 42319 | Clear All Recipes ACUM | Write 1 clear total accumulation |
| 2319 | 42320 | Clear recipe ACUM | Write 1-20 to clear the Recipe ID ACUM; Write 100 to Clear Choose Recipe ACUM; Write 101 to Clear All Recipe ACUM. |
| 2320 | 42321 | Clear user ACUM | Read as 0 . |

| | | | |
|---|-------------------------------|--|---|
| | | | Write 0-9 to clear the user ID ACUM ; Write 100 to clear choose user ACUM ; Write 101 to clears all user ACUM. |
| 2321~2999 9 | 42322~4300 0 | Reserve | |
| 3000-3001 | 43001-43002 | Current flow | |
| 3002 | 43003 | Flow calculation window length | Range:1 ~ 6 |
| 3003 | 43004 | Current flow unit | Read only: 0: g/h;1 kg/h.2: t/h;3: lb/h. |
| 3004 | 43005 | Current flow point | Read only: 0:0 bits;1:1 bits;2:2 bits;3:3 bits;Four to four. |
| 3005-3006 | 43006-43007 | Total quantity delivered Hi 6 bits | Range: 0~999999 |
| 3007-3008 | 43008-43009 | Total quantity delivered low 9 bits | Range: 0~999999999 |
| 3009-3010 | 43010-43011 | Cumulative times of receipt and delivery | Range: 0~999999999 |
| 3011-3012 | 43012-43013 | Cumulative weight of receipt and delivery Hi 6 bits | Range: 0~999999 |
| 3013-3014 | 43014-43015 | Cumulative weight of receipt and delivery low 9 bits | Range: 0~999999999 |
| 3015-3016 | 43016-43017 | Total cumulative times of the system | Range: 0~999999999 |
| 3017-3018 | 43018-43019 | Total cumulative weight of the system is Hi 6 bits | Range: 0~999999 |
| 3019-3020 | 43020-43021 | Permanent cumulative low 9 bits | Range: 0~999999999 |
| 3021~3999 | 43022-44000 | Reserve | |
| 16-bit status message address (used to match touch screen) | | | |
| 4000-4001 | 44001-44002 | Scale A present weight | The weight of scale A on the controller is shown |
| 4002 | 44003 | Scale A present weight state | Bit Instructions |
| | | | D0 Unstable weight: 0. Stable: 1. |
| | | | D1 Non-zero:0. Zero: 1. |
| | | | D2 Symbol of present weight: +/- Positive: 0. Negative: 1. |
| | | | D3 Overflow |
| | | | D4 Positive overflow |
| | | | D5 Negative overflow |
| | | | D6 Load cell positive overflow |
| | | | D7 Load cell negative overflow |
| D8 Stable millivolt: 1. Unstable: 0. | | | |
| D9~15 | Reserve | | |
| 4003 | Reserve | | |
| 4004-4005 | 44005-44006 | Scale B present weight | The weight of scale B on the controller is shown |
| 4006 | 44007 | Scale B present weight state | Referring to Scale A present weight state |
| 4008 | 44009 | Scale A & Scale B control | D0 0: Stop. 1: Run. |
| | | | D1 Alarm |
| | | | D2 Batch completed |

| | | | | |
|-----------|------------------------------|--|-------------------------------------|---------------------------------|
| | | state 1 | D3 | Bag locked |
| | | | D4 | Upper level |
| | | | D5 | Under Level |
| | | | D6 | Filling material |
| | | | D7 | Lack material |
| | | | D8 | Patting bag |
| | | | D9 | Conveyor output (Gross weigher) |
| | | | D10 | Coding output |
| | | | D11 | Sewing machine output |
| | | | D12 | cutting machine output |
| | | | D13 | Auxiliary pulse 1 |
| | | | D14 | Auxiliary pulse 2 |
| | | | D15 | Auxiliary pulse 3 |
| 4009 | 44010 | Scale A & Scale B control state 2 | D0 | Auxiliary pulse 4 |
| | | | D1 | Relay output 1 |
| | | | D2 | Relay output 2 |
| | | | D3 | Relay output 3 |
| | | | D4 | Relay output 4 |
| | | | D5 | Relay output 5 |
| | | | D6 | Relay output 6 |
| | | | D7 | In the suspension |
| | | | D8 | Hanger Up A |
| | | | D9 | Hanger Up B |
| | | | D10 | Last Feed |
| 4010 | 44011 | Scale A control state 1 | D11-15 | Reserve |
| | | | D0 | Before scale A filling |
| | | | D1 | Scale A Coarse Flow |
| | | | D2 | Scale A Medium Flow |
| | | | D3 | Scale A Fine Flow |
| | | | D4 | Scale A value |
| | | | D5 | Scale A discharge |
| | | | D6 | Scale A zero zone |
| | | | D7 | Scale A overlimit |
| | | | D8 | Scale A underlimit |
| | | | D9 | Scale A qualified |
| | | | D10 | Scale A over/under pause |
| | | | D11 | Scale A bag locked (no hopper) |
| | | | D12 | Scale A patting bag |
| | | | D13 | Scale A coding output |
| D14 | 0:Gross weight, 1:Net weight | | | |
| D15 | A: DISC Shaking | | | |
| 4011 | 44012 | Scale A control state 2 | D0 | A:Weight OK |
| | | | D1 | A:DISC Completed |
| | | | D2~15 | Reserve |
| 4012 | 44013 | Scale B control state1 | Referring to Scale A control state1 | |
| 4013 | 44014 | Scale B control state2 | Referring to Scale A control state2 | |
| 4014-4015 | 44015-44016 | Total accumulated weight (0~999999999) | | |
| 4016-4017 | 44017-44018 | Total accumulated bags (0~999999999) | | |
| 4018-4019 | 44019-44020 | The current recipe cumulative weight (0~999999999) | | |
| 4020-4021 | 44021-44022 | The current recipe cumulative bags (0~999999999) | | |
| 4022-4023 | 44023-44024 | User accumulated weight (0~999999999) | | |
| 4024-4025 | 44025-44026 | User cumulative bags (0~999999999) | | |
| 4026-4027 | 44027-44028 | Scale A previous weight value | | |
| 4028-4029 | 44029-44030 | Scale B previous weight value | | |

| | | | |
|-----------|-------------|---------------------------|---|
| 4030 | 44031 | Scale A alarm information | <ul style="list-style-type: none"> 0- No alarm 1- Unable to start for unreasonable recipe setting. 2- Unable to start as the maximum capacity of the hopper is 0. 3- Weight value exceeds zero range when zeroing; 4- Weighing value is unstable when zeroing. 5- Over/Under alarm. 6- The target value of single scale can not be set as 0 or the full capacity is too large. 7- The target value is bigger than maximum capacity value. |
| 4031 | 44032 | Scale B alarm information | <ul style="list-style-type: none"> 8- Weight value or load cell is overlimit when start. 9- Discharge gate is sepearated from limit digit. 10- Not bag locked.(Manual unloading judgment After the bag is opened, the manual unloading unclamped bag will indicate that there is no bag, and the unclamped bag will not indicate during operation) 11- Zeroing in the process of running. 12- Zeroing over range in the process of running. 13- Zeroing is not unstable in the process of running. 14- The motor parameters is unreasonable (normal motor) 15- Reserve |
| 4032-4033 | 44033-44034 | Normal alarm information | <ul style="list-style-type: none"> 0- No alarm; 1- Batch completed; 2- Scale A Over/Under pause 3- Scale B Over/Under pause 4- Motor filling gate of scale A closed over time alarm 5- Motor filling gate of scale B closed over time alarm 6- Scale A bag locked over time alarm 7- Scale B bag locked over time alarm 8- Scale A bag unlocked over time alarm 9- Scale B bag unlocked over time alarm 10- Scale A discharge gate closed over time alarm 11- Scale B discharge gate closed over time alarm 12- Scale A discharge gate opened over time alarm 13- Scale B discharge gate opened over time alarm 14- Scale A fill gate not closed in place alarm. 15- Scale B fill gate not closed in place alarm. |

| | | | |
|------|-------|-------------------------------------|--|
| | | | <ul style="list-style-type: none"> 16- Scale A discharge gate not closed in place alarm. 17- Scale B discharge gate not closed in place alarm. 18- The communication is abnormal of main board and addition board. 19- Scale A coarse filling overtime alarm 20- Scale B coarse filling overtime alarm 21- Scale A medium filling overtime alarm 22- Scale B medium filling overtime alarm 23- Scale A fine filling overtime alarm 24- Scale B fine filling overtime alarm 25- Scale A discharge overtime alarm. 26- Scale B discharge overtime alarm 27- Scale A discharge shaking overtime alarm 28- Scale B discharge shaking overtime alarm |
| 4034 | 44035 | Scale A & Scale B calibration alarm | <ul style="list-style-type: none"> 1- No alarm 2- Maximum range is too small 3- Maximum range is too large 4- Zero voltage is too high 5- Zero voltage is too low 6- Unstable zero point 7- Gain voltage is too large 8- Gain voltage is too small 9- Scale platform is unstable 10- Weight value input is error 11- Resolution is low after calibration. 12- Manual Coarse Flow then Manual Discharge(material calibrate alarm) 13- Reserve |
| 4035 | 44036 | Scale A & Scale B control state 3 | <ul style="list-style-type: none"> 0- IN1(Read By COM) 1- IN2(Read By COM) 2- IN3(Read By COM) 3- IN4(Read By COM) 4- IN5(Read By COM) 5- Out1 Direct Control 6- Out2 Direct Control 7- Out3 Direct Control 8- Out4 Direct Control 9- Out5 Direct Control 10- Manual Completed 11- No Level Detection 12-15 Reserve |

Compile information (front and back)

| | | | |
|-----------|-------------|-----------------------|---------------------|
| 9000-9001 | 49001-49002 | Logic Version ID | For example: 010000 |
| 9002-9003 | 49003-49004 | Compile Date | For example: 161201 |
| 9004-9005 | 49005-49006 | Compile Time | For example: 130805 |
| 9006-9007 | 49007-49008 | Additional version ID | For example: 100 |
| 9008-9011 | 49009~49012 | Reserve | |

| Coil ON/OFF of GM9907-LD controlling function | | | |
|---|-----------|--|---|
| 0000 | 00001 | PWR-ON Zero | Write 1 on, 0 is written off. Each switching state is read out |
| 0001 | 00002 | Vib-Filter | |
| 0002 | 00003 | Result Hold | |
| 0003 | 00004 | Manual DISC To ACUM ON/OFF | |
| 0004 | 00005 | Bag locked Required(Manual DISC) | |
| 0005 | 00006 | Gross/Net weight in gross weigher | |
| 0006 | 00007 | Dynamic Filter ON/OFF | |
| 0007 | 00008 | Individual target mode ON/OFF | |
| 0008 | 00009 | OVER/UNDER ON/OFF | |
| 0009 | 00010 | OVER/UNDER Pause | |
| 0010 | 00011 | Fill Compensation ON/OFF | |
| 0011 | 00012 | Free Fall Correction ON/OFF | |
| 0012 | 00013 | Coding ON/OFF | |
| 0013 | 00014 | Disable Fill/Discharge When Coding | |
| 0014 | 00015 | Conveyor ON/OFF | |
| 0015 | 00016 | Print ON/OFF | |
| 0016 | 00017 | A Adaptive Pause | |
| 0017 | 00018 | B Adaptive Pause | |
| 0018 | 00019 | Adaptive parameter permanent replace ON /OFF | |
| 0019 | 0020 | Reserve | The address can write in 1 only, read out 0. |
| 0020 | 00021 | Scale A zero | |
| 0021 | 00022 | Scale A manual discharge | |
| 0022 | 00023 | Scale A manual Fine Flow | |
| 0023 | 00024 | Scale A bag locked/unlocked | |
| 0024 | 00025 | Scale A Manual Filling | |
| 0025 | 00026 | Scale A Manual Medium Filling | |
| 0026 | 00027 | A Hanger up | Write 1 ON, write 0 OFF read out is each ON/OFF state |
| 0027 | 00028 | B Hanger up | |
| 0028-0029 | Reserve | | The address can write in 1 only, read out 0. |
| 0030 | 00031 | Scale B zero | |
| 0031 | 00032 | Scale B manual discharge | |
| 0032 | 00033 | Scale B manual Fine Flow | |
| 0033 | 00034 | Scale B bag locked/unlocked | |
| 0034 | 00035 | Scale B manual filling | |
| 0035 | 00036 | Scale B Manual Medium Filling | This address can be written only 1. Read as 0 |
| 0036-0039 | 0037-0040 | Reserve | |
| 0040 | 00041 | Run | |
| 0041 | 00042 | Emergency stop | |
| 0042 | 00043 | Stop | |
| 0043 | 00044 | Change Recipes | |
| 0044 | 00045 | Clear alarm | |
| 0045 | 00046 | Clear present user accumulated | |
| 0046 | 00047 | Clear all users accumulated | |
| 0047 | 00048 | Clear present recipe accumulated | |
| 0048 | 00049 | Clear all recipes accumulated | |
| 0049 | 00050 | Clear accumulated total | |

| | | | |
|--|---------|--|---|
| 0050 | 00051 | All reset | |
| 0051 | 00052 | Calibration reset | |
| 0052 | 00053 | Working parameters reset | |
| 0053 | 00054 | Recipe parameters reset | |
| 0054 | 00055 | Peripheral parameters reset | |
| 0055 | 00056 | I/O module parameters reset | |
| 0056 | 00057 | Execution parameter backup | |
| 0057 | 00058 | Restore backup parameters | |
| 0058 | 00059 | Delete backup parameters | The address can write in 1 to delete backup parameters. If reads out 1, means backup parameter is available. If reads out 0, means without backup parameters. |
| 0059 | 00060 | Motor parameters reset | This address can only write 1. Read to 0 |
| 0060 | 00061 | Sewing Input | |
| 0061 | 00062 | Sewing Emergency Stop | |
| 0062 | 00063 | Auxiliary Pulse 1 | |
| 0063 | 00064 | Auxiliary Pulse 2 | |
| 0064 | 00065 | Auxiliary Pulse 3 | |
| 0065 | 00066 | Auxiliary Pulse 4 | |
| 0066 | 00067 | Auxiliary Logic parameter Reset | |
| 0067 | 00068 | Clear Current Recipe | |
| 0069 | 0070 | Clearing surplus materials | |
| 0070 | 0071 | No Level Detection | Write 1 to set the shielding to be valid, write 0 to set the shielding to be invalid. Read as material level shielding status |
| 0071 | 0072 | Manual Completed | Writing 1 is valid for manual completion and cannot write 0. Read as manual completion status |
| 0072-0079 | Reserve | | |
| Controlling function coil IO test | | | |
| 0080 | 00081 | I/O module test ON/OFF: to enter I/O module test by writing 1, exit by writing 0. Not allow to write when running. | |
| 0081 | 00082 | Read out 1 when input port 1 is valid. If invalid, will read out 0. | Do not take effect during writing. |
| 0082 | 00083 | Read out 0 when input port 2 is valid. If invalid, will read out 0. | |
| 0083 | 00084 | Read out 1 when input port 3 is valid. If invalid, will read out 0. | |
| 0084 | 00085 | Read out 1 when input port 4 is valid. If invalid, will read out 0. | |
| 0085 | 00086 | Read out 1 when input port 5 is valid. If invalid, will read out 0. | |
| 0086 | 00087 | Read out 1 when input port 6 is valid. If invalid, will read out 0. | |
| 0087 | 00088 | Read out 1 when input port 7 is valid. If invalid, will read out 0. | |
| 0088 | 00089 | Read out 1 when input port 8 is valid. If invalid, will read out 0. | |
| 0089 | 00090 | Read out 1 when input port 9 is valid. If invalid, will read out 0. | |
| 0090 | 00091 | Read out 1 when input port 10 is valid. If invalid, will read out 0. | |
| 0091 | 00092 | Read out 1 when input port 11 is valid. If invalid, will read out 0. | |

| | | |
|-------------|--------------|--|
| 0092 | 00093 | Read out 1 when input port 12 is valid. If invalid, will read out 0. |
| 0093 | 00094 | Read out 1 when output port 1 is valid. If invalid, will read out 0. |
| 0094 | 00095 | Read out 1 when output port 2 is valid. If invalid, will read out 0. |
| 0095 | 00096 | Read out 1 when output port 3 is valid. If invalid, will read out 0. |
| 0096 | 00097 | Read out 1 when output port 4 is valid. If invalid, will read out 0. |
| 0097 | 00098 | Read out 1 when output port 5 is valid. If invalid, will read out 0. |
| 0098 | 00099 | Read out 1 when output port 6 is valid. If invalid, will read out 0. |
| 0099 | 00100 | Read out 1 when output port 7 is valid. If invalid, will read out 0. |
| 0100 | 00101 | Read out 1 when output port 8 is valid. If invalid, will read out 0. |
| 0101 | 00102 | Read out 1 when output port 9 is valid. If invalid, will read out 0. |
| 0102 | 00103 | Read out 1 when output port 10 is valid. If invalid, will read out 0. |
| 0103 | 00104 | Read out 1 when output port 11 is valid. If invalid, will read out 0. |
| 0104 | 00105 | Read out 1 when output port 12 is valid. If invalid, will read out 0. |
| 0105 | 00106 | Read out 1 when output port 13 is valid. If invalid, will read out 0. |
| 0106 | 00107 | Read out 1 when output port 14 is valid. If invalid, will read out 0. |
| 0107 | 00108 | Read out 1 when output port 15 is valid. If invalid, will read out 0. |
| 0108 | 00109 | Read out 1 when output port 16 is valid. If invalid, will read out 0. |
| 0109 | 00110 | Reserve |
| 0110 | 00111 | Write 1, the Out 1 direct control is valid. Write 0, the Out 1 direct control is invalid. |
| 0111 | 00112 | Write 1, the Out 2 direct control is valid. Write 0, the Out 2 direct control is invalid. |
| 0112 | 00113 | Write 1, the Out 3 direct control is valid. Write 0, the Out 3 direct control is invalid. |
| 0113 | 00114 | Write 1, the Out 4 direct control is valid. Write 0, the Out 4 direct control is invalid. |
| 0114 | 00115 | Write 1, the Out 5 direct control is valid. Write 0, the Out 5 direct control is invalid. |

6.4 Re-ContA/B protocol

In this way, no need to send any command to the weighing display, display automatically sends the collected data to the computer

Returns a description of the data frame format:

| Status | , | GS/NT | , | +/- | Current Weight | Unit | CR | LF |
|----------------|-----------|---------------------|-----------|--------------|----------------|------------------|-----------|-----------|
| 2 Bytes | 2C | 47 53 /4E 54 | 2C | 2B/2D | 7 Units | g/kg/t/lb | 0D | 0A |

Explain:

Status——2Bytes, OL(Over):4FH 4CH; ST(Stable):53H 54H;US(Unstable):55H 53H

GW/NW——2Bytes, GS/NT: 47 53/4E 54

Display value—— 7Bytes, Contains the decimal point, no decimal point when the high space
Unit ——2Bytes, g: 20 67; kg: 6B 67; t: 20 74; lb: 6C 62

For example:

When weighing the display automatically sends the following frame of data:

53 54 2C 47 53 2C 2B 30 31 31 2E 31 32 30 6B 67 0D 0A

Current status: Stable, data value is positive, display value is 11.120kg

7. Auto packaging process


GM9907-LD controller in the packaged state can be automatically controlled automatic packaging coarse, medium and fine flow, and discharge of all the packaging process. Supports net weigher, gross weigher and bulk scale structure, a variety of modes are available. Scale structure and mode can be selected in the scale structure parameters.

7.1 Dual scale with hopper mode packaging


1) Weigher structure choose net weigher, the mode selection parameter for the scale body is A+B hopper, AB individual target mode set to off, target value is set greater than the hopper capacity, if the target value is a hopper capacity integral multiple of "the number of discharge calculated automatically" as a target value / hopper capacity. Otherwise, "the number of discharge calculated automatically" as a target value / hopper volume +1 single hopper, and single scale target value is target value / unloading times automatically calculated. After starting the main interface can see A, B and the target value, then A, B parallel hopper discharge, who measure who discharge first. A total discharge "Automatic counting of discharge times" unlocks bag only once.

2) Weigher structure choose net weigher, the mode selection parameter for the scale body is A+B hopper, AB individual target mode set to off, single target value is set equal to less than the hopper capacity, then the "number of discharge automatically calculated" is 1, single hopper target is a target value. In this case, A, B are alternately discharge, discharge once unlock bag once.

3) Weigher structure choose net weigher, the mode selection parameter for the scale body is A+B hopper, AB individual target mode set to on, In AB scale independent mode, need to set A or B target value, but single hopper can not exceed the hopper capacity, the hopper capacity can not exceed the full capacity; Do not set target value at this time, even if setted is meaningless. Scale A and scale B respectively complete the quantitative process according to the target value of A or target value of B set respectively, and the unloading process of the two scales is separate, that is, when scale A is unloading, scale B needs to wait for the unloading completion of scale A even if the filling is completed, and then the unloading can be done after the bag is lock again.



Process Description:



1) Start "Filling PreDelay Timer"; 2) zero operation is determined (Auto Zero Interval).

1) Start "A/B COMP Inhibit Timer (Co-F)", no determination for the weight;
 2) Analyzing Weight: The weight of the material \geq single scale target -A / B amount touching scale fast, Co-F closed, Me-F open.

1) Start "A/B COMP Inhibit Timer (Me-F)", no determination for the weight ;
 2) Analyzing Weight: The weight of the material \geq single scale target -A / B amount touching scale fast, Me-F closed, Fi-F open.

1) Start "A/B COMP Inhibit Timer (Fi-F)", no determination for the weight ;
 2) Analyzing Weight: The weight of the material \geq single scale target -A / B scale Free Fall, Fi-F closed, wait open.

1) Two result checking mode: Stability and delay determination (operating parameter selected), the end of the process according to the selected setting mode, from clutch bag to discharge.

1) Analyzing Weight: Material < Near Zero Band; 2) start "discharge delay." 3) To determine the final balance, then enter a "unlock bag" process or a "Filling Start Delay" under start.

※ In stop state, the external "start " input signal is valid, the scale starts to detect whether the set target value and the volume of a single hopper. If set to complete the work properly, otherwise it will prompt "target weight unreasonable" message, not start.

※ **Over/Under ON/OFF:**

When the "OVER/UNDER ON/OFF" turn on, in a packaging process, upon completion of the last weighing process, system will detecting over/under testing , .when the weight is stable, it will output over/under alarm signal.

When over/under is "ON", if this occurs the packaging tolerance over or under, the scale will automatically pause quantitative process, the buzzer sounds, the pop-up window displays the error message "A / B over/under pause" alarm information, the processing waits for the user, then press "enter" key or ON/OFF input "Clear alarm" effectively remove the alarm signal, said alarm clears scale and continue. User can also enter the emergency stop signal back to the stop state.

※ **Unlock bags:**

Controller judge the last scale, "discharge delay" time after closing the discharge at the same time start "unlock bags start delay", after the delay to take the bag if completed will unlock bag if the bag is not completed will wait to unlock bags upon completion of pat bags.

In operation, if stop input is valid, when the scale completes the operation it will unlock bag return to stop state.

7.2 Scale A with hopper mode packing

Weigher structure choose with weighing Hopper, the mode selection parameter for the scale body is single scale with hopper A, since the method is applicable to the case of a mechanical failure or other reasons can only work for a scale.

1) Weigher structure choose with weighing Hopper, the mode selection parameter for the scale body is single scale with hopper A, AB individually set to off target, target value is set Target>Hopper Volume, if the target value is volume of a single hopper integral multiple of "the number of discharge calculated automatically" as a target value / volume of a single hopper. Otherwise, "the number of discharge calculated automatically" as a target value / single hopper volume +1, and the single hopper target is target value / unloading times automatically calculated. Only the scale A work alone, a total of unloading "discharge automatically calculates the number of" unlock bag only once.

2) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale with hopper A, AB individually set to off target, single target value is set equal to less than the hopper volume, then the "number of discharge automatically calculated" is 1, single hopper target is target value. Only scale A work separately at this time, discharge material once and lock the bag once, scale B does not work.

3) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale A with hopper, AB individually set to on target, but can not exceed the volume of hopper, single hopper can not exceed volume; do not set target value at this time, even if you set is meaningless. Scale A completes the quantitative process according to target value A, discharge material once and lock the bag once, scale B does not work.

7.3 Scale B with hopper mode packing


Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is single scale with hopper B, since the method is applicable to the case of a mechanical failure or other reasons can only work for a scale.

1) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is single scale with hopper B, AB individually set to off target, target value is set Target>Hopper Volume, if the target value is volume of a single hopper integral multiple of "the number of discharge calculated automatically" as a target value / volume of a single hopper. Otherwise, "the number of discharge calculated automatically" as a target value / single hopper volume +1, and the single hopper target is target value / unloading times automatically calculated. Only the scale B work alone, a total of unloading "discharge automatically calculates the number of" unlock bag only once.

2) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale with hopper B, AB individually set to off target, single target value is set equal to less than the hopper volume, then the "number of discharge automatically calculated" is 1, single hopper target is target value. Only scale B work separately at this time, discharge material once and lock the bag once, scale A does not work.

3) Weigher structure choose with weighing hopper, the mode selection parameter for the scale body is scale B with hopper, AB individually set to on target, but can not exceed the volume of hopper, single hopper can not exceed volume; do not set target value at this time, even if you set is meaningless. Scale B completes the quantitative process according to target value B, discharge material once and lock the bag once, scale A does not work.

Structure is shown below:



7.4 Dual hopper dual clampe bag AB separate packing mode

The structure of the weighing body is equipped with net weigher mode, and the working mode of the parameters is A/B dual clammers.

1) Weighing body structure should be equipped with with hopper bagging, and the operation mode of the weighing body parameters should be dual hopper dual clip bag AB separate, and the target value of AB should be set as close separately. The target value should be greater than the maximum capacity of a single hopper. If the target value is an integer multiple of the maximum capacity of a single hopper, the "automatically calculated discharge times" should be the target value/maximum capacity of a single hopper. Otherwise, "automatically calculated discharge times" is the target value/the maximum capacity of a single hopper +1, and the single weighing target value is the target value/the automatically calculated discharge times. At this time, A, B scales work separately, A total of discharge "automatically calculated discharge times" only loose the bag once.

2) Weighing body structure should be equipped with with hopper bagging. The operation

mode of the weighing body parameters should be dual hopper dual clip bag AB separate, and the target value of AB should be set as close separately. If the target value is set to be less than or equal to the maximum capacity of the single hopper, then the "number of discharging calculated automatically" is 1, and the target value of the single scale should be the target value. At this time only A, B scale independent work, discharge A loose bag once.

3) Weighing body structure should be equipped with with hopper bagging. The working mode of the parameters of the weighing body should be dual hopper dual clip bag AB separate, and the target value of AB should be set as open separately. The target value of A and B should be set separately, but not exceed the maximum capacity of single hopper, and the maximum capacity of single hopper should not exceed the maximum range. Do not set the target value at this time, even if set also useless. The A scale completes the quantitative process according to the target value of A, discharge the material once and loosening the bag once, while the B scale completes the quantitative process according to the target value of B, discharge the material once and loosening the bag once.

After starting, if A has finished discharge, controller will start the conveyor to start conveying. The same is B scales.

7.5 Dual hopper dual clip bag AB Comb packing mode

The structure of the weighing body is equipped with with hopper mode, and the working mode of the parameters of the weighing body is dual hopper dual clip bag AB comb.

1) Weighing body structure should be equipped with with hopper bagging, and the operation mode of the weighing body parameters should be dual hopper dual clip bag AB comb, and the target value of AB should be set as close separately. The target value should be greater than the maximum capacity of a single hopper. If the target value is an integer multiple of the maximum capacity of a single hopper, the "automatically calculated discharge times" should be the target value/maximum capacity of a single hopper. Otherwise, "automatically calculated discharge times" is the target value/the maximum capacity of a single hopper +1, and the single weighing target value is the target value/the automatically calculated discharge times. At this time, A, B scales work separately, A total of discharge "automatically calculated discharge times" only loose the bag once.


2) Weighing body structure should be equipped with with hopper bagging. The operation mode of the weighing body parameters should be dual hopper dual clip bag AB comb, and the target value of AB should be set as close separately. If the target value is set to be less than or equal to the maximum capacity of the single hopper, then the "number of discharging calculated automatically" is 1, and the target value of the single scale should be the target value. At this time only A, B scale work separately, discharge and loose bag once.

3) Weighing body structure should be equipped with with hopper bagging. The working mode of the parameters of the weighing body should be dual hopper dual clip bag AB comb, and the target value of AB should be set as open separately. The target value of A and B should be set separately, but not exceed the maximum capacity of single hopper, and the maximum capacity of single hopper should not exceed the maximum range. Do not set the target value at this time, even if set also useless. The A scale completes the quantitative process according to the target value of A, discharge the material once and loosening the bag once, while the B scale completes the quantitative process according to the target value of B, discharge the material once and loosening the bag once.

After starting, B scale began to filling materials, A scale also began to filling materials, and wait for A and B are loose bags, controller control conveyor started, the packaging bag filling finished will be transported, and then clip the bag to start the next process.

Note: Dual with hopper bagging adopts two hoppers, two clip bag mechanisms, and the work of AB scale (work of the conveyor, other work will not affect each other).

Structure is shown in the following figure:



7.6 Dual scale no hopper mode packing

No hopper mode, material from the material tank through the filling mechanism filling directly to the bag (coarse, medium, fine flow), controlling weight metering process sampling is complete (processing load cells mounted on the hopper) in a packaging bag. After the completion of metering, controller controls to unlock bag. The difference between no hopper packing and with hopper packing process is that the sensor is mounted on the hopper. After starting, after complete lock bag operation, it starts filling delay process.

Weigher structure choose no hopper packaging, the mode selection parameter choose AB Comb No Hopper. 1) If AB target value is set to Off separately, the target value is the target value of A and B scale; 2) If AB target value is set to On separately, the target values of A and B are respectively the targets of A and B. All are independent of the volume, but can not exceed the volume.

After starting, scale B bag begins to fill, scale A bag begins to fill, and waits for the A and B unlock bags, controller control conveyor started, transport the finished packaging bag, start the next process.


If the bag filling of A is completed and the bag is loosened, and the bag is not clip in B, controller controls the conveyor to start; If the bag is not clip in the scale A, the bag filling is completed and the bag is loosened in the scale B, and controller controls the conveyor to start.

7.7 Dual scale no hopper individual packing

Weigher structure choose no hopper bagging, the mode selection parameter choose AB Separate No Hopper. 1) If AB target value is set to Off separately, the target value is the target value of A and B scales; 2) If AB target value is set to On separately, the target values of A and B are respectively the targets of A and B. All are independent of the volume, but can not exceed the volume.

After start, any scale finish filling then unlock bag, controller will start transporting conveyor.

Structure is shown below:



7.8 Bulk accumulation process


1) Bulk scale AB Interlock: Under the operating state, scale A start to add the material to the weighing tank (coarse, medium and fine), and the weight sampling of the controlling control process is completed in the weighing tank (the weighing load cell is mounted on the weighing tank). After the controlling is completed, the material is discharged through the unloading mechanism on the weighing tank and the weight value is accumulated. When scale A is discharging, scale B starts feeding and carry out the weighing. The weighing units of A and B are interlocked for loading/unloading.


2) Bulk scale AB independent: The two scales can be fed and discharged at the same time, without interlocking.

3) Bulk single hopper A: Only scale A works.

4) Bulk single hopper B: Only scale B works.

Basic process description:





8. Motor Work Process

8.1 Motor Filling Portion

8.1.1 Step Motor Drive Filling

Step motor drive control filling door ON/OFF: I/O Module involved are: **O31 (A:Filler Gate PWM) / O32 (A:Filler Gate DIR) / O33 (B:Filler Gate PWM) / O34 (B:Filler Gate DIR), I31 (A:Filler Gate Closed Pos.)/ I32 (B:Filler Gate Closed Pos.). (I31 / I32-The signal is determined by the type of signal in place).**

Take scale A Coarse flow, Medium flow, Fine flow for example:

- Coarse flow process: controller control O32 (**A:Filler Gate DIR**) to ensure the gate opening direction to the direction of motor rotation, then O31 (**A:Filler Gate PWM**) according to the A: filler motor frequency output pulse to control the stepping motor rotate to the gate opening direction, O31 (**A:Filler Gate PWM**) stop the output pulse after the number reaches the set value, the filler gate stops rotating, this is coarse flow state. Then controller Change O32 (**A:Filler Gate DIR**) output as closing gate direction.
- Medium flow process: O31 (**A:Filler Gate PWM**) according to the A:filler motor frequency output pulse to control the stepping motor rotate to the gate closing direction, O31 (**A:Filler Gate PWM**) stop the output pulse after the number reaches the set value, the filler gate stops rotating, this is medium flow state.
- Fine flow process: O31 (**A:Filler Gate PWM**) according to the A:filler motor frequency output pulse to control the stepping motor continuing rotate to the gate closing direction, O31 (**A:Filler Gate PWM**) stop the output pulse after the number reaches the set value, the filler gate stops rotating, this is fine flow state.
- Filling closing: O31 (**A:Filler Gate PWM**) according to the A:filler motor frequency output pulse to control the stepping motor continuing rotate to the gate closing direction, until detecting I31 (**A:Filler Gate Closed Pos.**) value input, then it stop output pulse signal, the filler gate stops rotating, filling is completely closed.

8.1.2 Motor Drive Filling

Motor drive mode control filler gate ON/OFF: I/O Module involved are: scale A **O43 (A:Filler Gate Open) / O45 (A:Filler Gate Close), I31 (A:Filler Gate Closed Pos.), scale B O44 (B:Filler Gate Open) / O46 (B:Filler Gate Close), I32 (B:Filler Gate Closed Pos.).**

Take scale A Coarse flow, Medium flow, Fine flow for example:

- Coarse flow process: scale A begins filling after a delay time t1. Controller first controls scale A **O43 (A:Filler Gate Open)** signal output valid, the effective time is **A: Co-F, Gate Open Time**, start coarse flow process.
- Medium flow process: weight of the material in the scale A \geq single scale target value-scale A coarse flow remains, scale A **O45(A:Filler Gate Close)** signal output is valid, the valid time is "scale A Coarse flow Gate Open Time – scale A Medium Flow Gate Open Time "
- Fine flow process: weight of the material in the scale A \geq single scale target value-scale A medium flow remains, A **O45(A:Filler Gate Close)** signal output is valid, the valid time is "scale A Medium Flow Gate Open Time – scale A Fine Flow Gate Open Time "
- Flow off: weight of the material in the scale A \geq single scale target value-scale A fine flow remains, scale A **O45(A:Filler Gate Close)** signal output is valid, until detecting **A filler gate limit signal I31 (A:Filler Gate Closed Pos.)**.
- note:in case closing process is longer than the filler gate close overtime, controller has not yet detected I31 (**A:Filler Gate Closed Pos.**),Then the controller will stop O45 (**A:Filler Gate Close**),and alarm scale A filler gate close overtime.

Note: When controller started, it is necessary to detect whether filler gate and discharge gate are in the limit, if not, controller will alarm and can't be started.

8.2 Motor lock Bag Portion

8.2.1 Step Motor Drive lock/unlock bag

Step motor drive controls bag lock/unlock: I/O Module involved are: **O35 (A:Clamper PWM) / O36 (A: Clamper DIR) / O37 (B:Clamper PWM) / O38 (B: Clamper DIR), I33 (A:Bag Released)/ I34 (B:Bag Released)**. (I37/I38 signal is determined by the limited signal type.)

Take binyES with metering hopper mode, bag lock/unlock process for sample:

- Lock bag process: controller control **O36 (A: Clamper DIR)** output, ensure motor rotating direction is lock bag direction, then **O35 (A:Clamper PWM)** according to the **A clutch motor frequency** to output pulse, control lock/unlock step motor rotating to lock bag direction, **O35 (A:Clamper PWM)** number reach setted **scale A clutch pulse number** it will stop output pulse signal, at this time lock/unlock mode is in the lock bag state. Then controller change **O36 (A: Clamper DIR)** output to unlock direction.
- Unlock bag process: **O35 (A:Clamper PWM)** according to the setted **scale A clutch motor frequency** to output pulse, control unlock step motor rotating to unlock direction, until detecting **I33(A:Bag Released)** input valid then stop output pulse signals, this is unlock state. Note: if unlock bag process time more than **Bag Release Overtime**, controller has not yet detected **I33 (A: Bag Released)**, then the controller will stop output **O35 (A:Clamper PWM)**, and alarm **scale A: Bag Unlock overtime**.

8.2.2 Motor Drive Dual-Limit lock/unlock bag

Motor drive dual-limit controls bag lock/unlock: I/O Module involved: **O9 (A: Lock Bag) / O47 (A:Bag Unlock)/ O12 (B:Lock Bag)/ O48 (B:Bag Unlock), I23 (Bag Locked) / I33 (A:Bag Released) / I24 (B:Bag Locked) / I34 (B:Bag :Released)**. (I33/I34 signal is determined by the Limit signal type).

Take binyES with metering hopper mode, bags lock/unlock process for sample:

- Lock bag process: controller output lock bag signal (**O9 A: Lock Bag**) to control Clutch bag motor rotating to lock bag direction, until detecting bag locked signal (**I23 Bag Locked**) input valid then stop output lock bag signal (**O9 A: Lock Bag**), at this time lock bag mode is in the lock state. Note: in case lock bag process time exceeds the setted **Bag Lock Overtime**, controller has not yet detected bag locked signal (**I23 Bag Locked**), then controller stop output lock bag signal (**O9 A: Lock Bag**), and alarm **A Bag Lock Overtime**.
- Unlock bag process: controller output unlock bag signal(**O47 A:Bag Unlock**) to control Clutch bag motor rotating to unlock bag direction, until detecting Clutch Limit Signal Type (**I33 A:Bag Released**)input valid then stop output unlock bag signal(**O47 A:Bag Unlock**), at this time lock/unlock mode is in the unlock state. Note: in case unlock bag process time exceeds the setted **Bag Release Overtime**, controller has not detected bag released signal (**I33 A:Bag Released**), then controller stop output unlock bag signal (**O47 A:Bag Unlock**), and alarm **scale A Bag Release Overtime**.

8.2.3 Motor Drive Single-Limit lock/unlock bag

Motor drive dual-limit controls lock/unlock bags: I/O Module involved: **O9 (A lock bag) / O47 (A unlock bag)/ O12 (B lock bag)/ O48 (B unlock bag), I23 (A Bag Locked) / I24 (B Bag Locked)**

Take binyES with metering hopper mode, bags lock/unlock process for sample:

- Lock bag process: controller control **O9 (A lock bag)** I/O module output signals, output signal until detecting bag locked signal **I23 (Bag Locked)** input is valid, this output signal output is invalid, lock bag.

- Unlock bag process: controller control O47 (**A unlock bag**) I/O module output signals, in order to unlock bag, output signal time of duration is for unlock bag output, this output signal is invalid.

Note: in case lock bag time of duration exceeds setted **Bag Lock Overtime**, controller has not detected A Bag Locked I23 (**A Bag Locked**), then controller will stop output O9 (**A lock bag**), and alarm scale **A Bag Lock Overtime**.

8.3 Motor Discharge Portion

8.3.1 Step Motor Drive Discharge

Step motor control discharge: I/O Module involved are: I25 (A : DISC Gate Closed Pos.) scale **A O39 (A:DISC Gate PWM), O40 (A:DISC Gate DIR)**.

Take scale A discharge for sample:

- Discharge gate opening process: controller control **O40 (A:DISC Gate DIR)** output, to ensure that the motor rotating direction is gate opening direction, then **O39 (A:DISC Gate PWM)** according to the set **Discharge Gate Opened Motor Frequency** output pulse, to control the discharge step motor rotating to discharge opening gate direction, **O39 (A:DISC Gate PWM)** number reaches setted **A discharge pulse needed number's** value then stop output pulse signals, at this time discharge mode is in the open state.
- Discharge gate closing process: after the discharge gate opened, if controller detecting hopper weight lower than **Near Zero Value**, then start the **Discharge Delay Time**, when the discharge delay time is finish, controller change **O40 (A:DISC Gate DIR)** as the closing direction, **O39 (A:DISC Gate PWM)** according to the setted **Discharge Gate Opened Motor Frequency** to output pulse, to control the discharge step motor rotating to closing gate direction, until detecting **I25 (A : DISC Gate Closed Pos.)** input value then stop output pulse signals, at this time is closing gate state. Note: in case closing process time exceeds setted **DISC Gate Close Overtime**, controller has not yet detecting closing gate signal **I25 (A DISC gate closed)**, then controller will stop output **O39 (A:DISC Gate PWM)**, and alarm scale **A discharge gate close overtime**.

8.3.2 Motor Drive Single-Limit Discharge

Motor positive and negative rotation single-limit mode control discharge: I/O Module involved are: **O11 (A: DISC) O14 (B: DISC) O49 (A:DISC Gate Close) O50 (B: DISC Gate Close), I25 (A : DISC Gate Closed Pos.)/ I26 (B : DISC Gate Closed Pos.)**.

Take scale A discharge process for sample:

- Discharge gate open process: when discharge process begin, controller output discharge signal **O11 (A: DISC)** to control discharging motor rotating to discharge gate open direction, and continue setting **scale A discharge gate open output valid time** setted discharge motor open gate signal output time, then close discharge signal **O11 (A: DISC)** output.
- Discharge gate close process: after the discharge gate open, if controller detecting hopper weight lower than **Near Zero Value**, then start the **Discharge Delay Time**, when the discharge delay time is finish, it output discharge gate close signals **O49 (A:DISC Gate Close)** to control discharge motor rotating to discharge gate closing direction, until detecting discharge gate close signal **I25 (A : DISC Gate Closed Pos.)** input valid then stop output discharge gate close signal **O49 (A:DISC Gate Close)**, at this time discharge gate is closed. **Note:** in case discharge gate close process time exceed setted **A Discharge gate close overtime**, controller has not yet detecting discharge gate close signal **I25 (A : DISC Gate Closed Pos.)**, then controller will stop output **O49 (A:DISC Gate Close)**, and alarm scale **A discharge gate close overtime**.

8.3.3 Motor Drive Dual-Limit Discharge

Motor positive and negative rotation dual-limit mode control discharge: I/O Module involved are: **O11 (A: DISC) / O14 (B: DISC) / O49 (A:DISC Gate Close) / O50 (B: DISC Gate Close), I25 (A : DISC Gate Closed Pos.)/ I35 (A:DISC Gate Closed Pos.) /I26 (B : DISC Gate Closed Pos.) / I36 (B: DISC Gate Closed Pos.)**.

Take scale A discharge process for sample:

- Discharge gate open process: when discharge process begin, controller output discharge signal **O11 (A: DISC)** to control discharging motor rotating to discharge gate open direction, until detecting DISC Gate Open **I35 (A:DISC Gate Closed Pos.)** input valid then stop output discharge signal **O11 (A: DISC)**, at this time discharge gate is open state. Note: in case discharge gate open process time exceeds the setted **A discharge gate open overtime**, controller has not yet detected DISC Gate Open **I35 (A:DISC Gate Closed Pos.)**, then controller stop output **O11 (A: DISC)**, and alarm **scale A discharge gate open overtime**.
- Discharge gate close process: After the discharge gate open, if controller detecting hopper weight lower than **Near Zero Value**, then start the Discharge Delay Time, when the discharge delay time is finish, controller output discharge gate close signal **O11 (A: DISC)**, to control the discharge motor rotating to close gate direction, until detecting DISC Gate Close **I25 (A : DISC Gate Closed Pos.)** input value then stop output discharge gate close signal **O11 (A: DISC)**, at this time is discharge gate close state. Note: in case discharge gate close process time exceeds setted **A discharge gate close overtime**, controller has not yet detecting DISC Gate Close signal **I25 (A : DISC Gate Closed Pos.)**, then controller will stop output **O11 (A: DISC)**, and alarm **A discharge gate close overtime**.

8.3.4 Motor Drive Rotating Discharge

Motor drive rotating discharge control discharge: I/O Module involved are: **O11 (A: DISC) / O14 (B: DISC), I25 (A : DISC Gate Closed Pos.)/ I26 (B : DISC Gate Closed Pos.)**.

Take scale A discharge process for sample:

- Discharge gate open process: when discharge process begin, controller output discharge signal **O11 (A: DISC)** to control discharging motor rotating to discharge gate open direction, and continue setting **discharge motor gate open signals output time**, then close discharge signal **O11 (A: DISC)** output.
- Discharge the close process: After the discharge gate open, if controller detecting hopper weight lower than **Near Zero Value**, then start the Discharge Delay Time, when the discharge delay time is finish, controller output discharge signal **O11 (A: DISC)**, to control the discharge motor rotating to discharge gate close direction, until detecting DISC Gate Close **I25 (A : DISC Gate Closed Pos.)** input value then stop output discharge signal **O11 (A: DISC)**, at this time is discharge gate close state.

Note: In case discharge gate close process time exceeds **discharge gate close over time**, controller has not yet detecting DISC Gate Close signal **I25 (A : DISC Gate Closed Pos.)**, then controller will stop output **O11 (A: DISC)**, and alarm **scale A discharge gate close overtime**.

8.4 Motor Debug Function

Motor debug function is to facilitate user's quick determine the door size, coarse flow, medium flow, fine flow, take debug fine flow open gate for example:


Steps as follow:

- Step1: The left side of the interface is the current number of coarse, medium and fine pulses. You can modify the current pulse number of fine flow in the input box.
- Step2: Click "Fi-F Test" button to make the controller output fine flow signal. User determines whether the current pulse number is appropriate by checking the opening

size of the filling door. (note: click " Fi-F Test"" again to close fine flow. Controller can only be in one state, can not in the state of coarse flow and medium flow at the same time).

- Step3: If the pulse number has been modified, press the "save" button to save the modified pulse number. If do not want to save the modified pulse number, exit the motor debugging interface to restore the previous coarse, medium and fine pulse number.

9. Dimension (mm)



Mounting hole size

